# MANUAL

PC User Software

for servo amplifiers (DS, DPC) and battery motor controller (BAMOBIL-D, BAMOCAR)



UNITEK Industrie Elektronik G m b H

Hans-Paul-Kaysser-Straße 1 71397 Leutenbach-Nellmersbach

Tel: 07195 / 92 83 - 0 contact@unitek.eu www.unitek.eu **Edition / Version** 

2023 / V1



# **Table of contents**

1	Basi	asis – Information			
	1.1	History	. 5		
	1.2	More user manuals for UniTek digital devices	. 5		
	1.3	General	. 6		
	1.4	Safety instructions	.6		
	1.5	Operating system	.6		
	1.6	Software – Installation	.7		
2	NDr	rive Design	. 8		
	2.1	NDrive Design – Overview	.8		
	2.2	NDrive Design – Controls	11		
	2.2.	.1 Controls – Input and selection	11		
3	Deta	ails Menu Bar / Help	12		
	3.1	Details Menu Bar / Help – File	12		
	3.2	Details Menu Bar / Help – Communication	13		
	3.3	Details menu bar / Help – Help	14		
4	Com	nmunication with NDrive	15		
	4.1	Communication with NDrive – Hardware	15		
	4.2	Communication with NDrive – Establish connection	16		
	4.2.	.1 Establish connection – Serial RS232	16		
	4.2.	.2 Faulty communication – Serial RS232	16		
	4.2.	.3 Establish connection – CAN Bus	17		
	4.2.	.4 Faulty communication – CAN bus	17		
	4.3	Firmware update	18		
5	Savi	ing and Loading of servo parameters	19		
5.1 Saving and Loading in the servo (Eprom)		Saving and Loading in the servo (Eprom)	19		
	5.1.	.1 Saving in the servo (Eprom)	19		
	5.1.	.2 Loading from the Eprom	19		
	5.2	Save parameter data to and load from PC	20		
	5.2.	.1 Saving parameter data (.urf) on the PC	20		
	5.2.	.2 Loading parameter data (.urf) from the PC	20		
	5.2.	.3 Offline operation of parameter data (.urf) on the PC	20		
6	Basi	ic status information	21		
	6.1	Status information – Speed and current	21		
	6.2	Status information – Inputs and outputs	21		
	6.3	Status information – Status display	22		
	6.4	Status information – Error(s)	23		
	6.5	Status information – Warning(s)	24		
	6.6	Status information – Operating status display on the servo	25		
7	Enal		26		
	7.1	Enable – Hardware Input RUN (FRG) (Enable)	26		
	1.Z	Enable – LOCK and enable via interfaces (CAN bus, RS232)	2/		
	/.J	Salety Input KFE (rotating field enable)	28 20		
	7.3.	2 Operation without external REE input	∠ō 20		
	7.3.	.2 Operation without external RFE input	29		



8	Sett	ings	30
	8.1	Settings – Motor	31
	8.2	Settings – Feedback (encoder)	32
	8.3	Settings – 2nd feedback	35
	8.4	Settings – External brake	37
	8.5	Settings – Ballast circuit	39
	8.6	Settings – Monitoring motor temperature	40
	8.7	Settings – Power connection / DC bus monitoring	41
	8.7.	1 DC bus monitoring with firmware $\geq$ 478	42
	8.7.	2 DC bus monitoring with firmware < 478	43
	8.8	Settings – Monitoring power stage temperature	45
	8.9	Settings – Servo	46
	8.10	Settings – Servo / PWM clock frequency	48
	8.11	Settings – Servo / Analogue output	48
	8.12	Settings – Servo / Setpoint Command Mode	49
	8.13	Settings – Servo / Analogue inputs	50
	8.14 0.1F	Settings – Speed / Linear ramp function and speed limitation	52
	8.15	Settings – BTB / KDY	54
9	Com	imunication (external) with servo	55
	9.1	Communication (external) with servo – CAN bus	55
	9.2	Communication (external) with servo – RS232	56
	9.2.	1 Change RS232 baud rate	56
	9.2.	2 Structure of the RS232 serial protocol	56
1(	0 Curr	ent control	57
	10.1	Current control - Parameter overview	57
	10.1	1 Additional information on the parameters of the current controller	52
	10.1	Current control Structural diagram	50
	10.2	Current control – Structural diagram	59
	10.2	2.2 Sotting surront controller parameters (Kn Ti TiM)	62
	10.2		02
1:	1 Curr	ent reduction (Derating)	65
	11.1	Power reduction – Overview and explanation	65
	11.1	1 Power reduction – Overview	65
	11.1	2 Current reduction – Explanation	67
	11.1	3 Current reduction – Status display	68
12	2 Spe	ed control	69
	12 1	Speed control - Parameter overview	60
	12.1	1 Additional information of the parameters from the speed controller	70
	12.1	2 Additional information of the speed setupint ramps in speed controller mode	71
	12.1	2 Additional information of the speed setpoint famps in speed controller mode	7 I
	12.1	Canad control. Construct dia man	:71
	12.2	Speed control – Structural diagram	72
	12.2		15
13	3 Toro	jue control	78
	13.1	Torque control – Parameter overview	78
	13.2	Torque control – General	79
	13.3	Torque control – Torque cruise control	79
14	4 Posi	tion control	80



1	4.1	Position control – Parameter overview	80		
14.2 Posi		Position control – Structural diagram	82		
14.2.1		2.1 Position controller – Settings	83		
	14.2	2.2 Position controller – Additional information Settings	84		
	14.2	2.3 Position control – Conversion of the units of measurement for position	85		
	14.2	2.4 Position control – Scaling position	85		
1	4.3	Position control – Calibration run	86		
	14.5	2.2 Position controllor Homing Logic diagrams	00		
	14.5		00		
15	Field	d weakening control	91		
1	5.1	Field weakening control – Synchronous motor in general	91		
1	5.2	Field weakening control – Setting parameters	92		
16	Freq	quency converter operation (ACI V/f)	94		
1	6.1	Frequency converter – Parameter setting of the FU characteristic curve	94		
1	6.2	Frequency converter – Setting motor parameters	95		
17	Logi	ic	96		
1	7.1	Logic – General overview	96		
1	7.2	Logic – Digital inputs	97		
	17.2	2.1 Logic – Digital inputs General	97		
	17.2	2.2 Logic – Digital Inputs overview configuration	98		
1	7.3	Logic – Digital outputs	99		
	17.3	3.1 Logic – Digital outputs in general	99		
	17.3	3.2 Logic – Digital outputs overview configuration	100		
18	Diag	gnostics	102		
1	8.1	Diagnostics – General overview	102		
1	8.2	.2 Diagnostics – Manual Read/Write			
1	8.3	Diagnostics - Track	103		
1	8.4	Diagnostics – Information	103		
1	8.5	Diagnostics – Show register	104		
19	Mon	nitor	105		
1	9.1	Monitor – General overview	105		
20	Auto	o (special functions)	106		
2	0.1	Auto – Motor parameters	106		
2	0.2	Auto – Special functions	107		
	20.2	2.1 Special functions – Overview	107		
	20.2	2.2 Special functions – [Fn1] Tuning - Still	108		
	20.2	2.3 Special functions – [Fn2] Tuning - Rotating	108		
	20.2	2.4 Special functions – [Fn3] Phasing - Still	109		
	20.2	2.5 Special functions – [Fn4] Phasing - Rotating	110		
	20.2	2.6 Special functions – [Fn5] DC-Injection	112		
	20.2	2.7 Special Functions – [Fn6] Analog offset	113		
	20.2	2.8 Special functions – [Fn7] Tacho offset	114		
	20.2	2.9 Special functions – [Fn8] Calc from motor nameplate	115		
	20.2	2.10 Special functions – [Fn9] [Fn10] VdcBus compensation	118		
21	Osci	illoscope	119		
		-			



21.1	21.1 Oscilloscope – General overview			
21.2	Oscil	lloscope – Settings and display	120	
21.2	2.1	Oscilloscope – Signal selection	120	
21.2	2.2	Oscilloscope – Overview Trigger and Capture Setting	121	
21.2	2.3	Oscilloscope – Description of trigger and capture settings	121	
21.2	2.4	Oscilloscope – Measurement Activate	123	
21.2	2.5	Oscilloscope – Status display	123	
21.2	2.6	Oscilloscope – Zoom Options	123	
21.2	2.7	Oscilloscope – Line thickness (pencil)	123	
21.2.8		Oscilloscope – Saving and loading of measurements	124	
21.2.9		Oscillocope – Oscilloscope Window Customise	124	
21.2.10		Oscilloscope – Measured value display	125	
21.2.11 Oscilloscope - Parameters on the Oscilloscope page		Oscilloscope - Parameters on the Oscilloscope page	126	
22 Test mode				
22.1	Test	mode – Test	127	
22.2	Test mode – Step generator			
23 Measured values and parameters				
23.1	Mea	sured values (RO) – Overview	129	
23.2	Para	meters (RW / SP) – Overview	132	



# **1** Basis – Information

### 1.1 History

Version	Change	Date
2016 / V1.1	Fax number changed / page 68 (Iq - adjusted)	02.08.2016
2017 / V1	14.11.2017	
2020 / V1	27.01.2020	
2021 / V1	Adaptation to new Revised NDrive	01.03.2021
2023 / V1	Adaption Error- and Warningslists	28.03.2023
	Correction of spellings and visuals	

#### Attention:

Only use **NDrive 3** for units with firmware FW-350 or higher (serial number 70000 or higher).

#### 1.2 More user manuals for UniTek digital devices

- 1.MANUALDPC 4xx-AC DSxx, BAMO-D3, BAMOBIL-DxHardware description2.MANUALDSxx, BAMO-D3, BAMOBL-DxCommissioning
- 3. MANUAL CAN

### Use all MANUALs for project planning, installation and commissioning!

Online: <u>www.unitek.eu</u>

The MANUAL contains warnings and safety instructions, explanations of standards, mechanical and electrical installation instructions.

The MANUAL must be made accessible to all persons working with the unit.

#### **Abbreviations / Terms**

ServoDigital UNITEK motor controllerDeviceDigital UNITEK motor controller

**BUS** system



# 1.3 General

The PC user software NDrive is used for setting and optimising the digital three-phase motor controller (DS, DPC) and analog battery motor controllers (BAMO-D, BAMOBIL-D, BAMOCAR-D) from UniTek. Basic knowledge of operating a PC and the WINDOWS operating system is required.

The NDrive software and the MANUAL are available via the Internet.

# 1.4 Safety instructions

With the NDrive software, the parameters and Settings of servo and motor preselected. The operating parameters can be preset and adjusted during the operation can be changed. PC and the PC programmes are not functionally reliable. The user must ensure that, in the event of a malfunction, no Danger to man and machine can occur and the drive is shut down.



Stored data records can be changed by third parties. After a data record has been read in, it must be checked before it is reused.

Only trained specialists with knowledge of drive technology, control technology and PC operation may make settings and optimisations on the running drive.

The safety instructions of the amplifier or motor controller used must also be observed. Operation deviating from safety conditions is not permitted.

# 1.5 **Operating system**

NDrive is executable with Windows - 2000, - NT4, - XP, - Vista, - 7, - 8, - 10.

#### Minimum PC equipment

Processor Graphic Hard disk space Minimum working memory Interface 80486 or higher WINDOWS compatible 10 MB 8 MB COM1 to COM8 (RS232, USB adapter)

Windows is a registered trademark of Microsoft Corp.

<u>Linux</u>

The use of NDrive via one of the LINUX operating systems is possible with the help of a Windows emulator (e.g., Wine).



# 1.6 **Software – Installation**

The user software NDrive can be downloaded from the UniTek homepage.

No installation is necessary to run NDrive. Only the (.exe) application file must be executed.

Hint:

Since NDrive is not a commercial software application, the selection of untrusted software must be accepted once in Windows.

Internet:

- Go to the UniTek homepage <u>https://www.unitek-industrie-elektronik.de/</u>.
- Click on the **Download**  $\rightarrow$  **NDrive2-Software.zip** button.
- Download the file (NDrive2-Software.zip) and save it.
- Unzip the file (NDrive2-Software.zip).
- Start the NDrive programme by executing the (.exe) application file.
- It is advisable to set the language at the very first start (Help → Change language...) and to restart NDrive so that the language files are loaded correctly.



# 2 NDrive Design

# 2.1 NDrive Design – Overview

The screen display of NDrive is divided into a fixed screen area and a freely selectable screen area.





The fixed screen area (blue, green and black highlighting) always remains and shows basic important information.

This is divided into the following areas:

Fixed	Description:				
screen area:					
Headboard	Title bar				
(blue)	Menu bar				
Laft field					
Left field	• SPEED Speed display in revolutions per minute (rpm) and 16 hit numerie (Num) Per display				
(green)	0 100 % speed				
	CURRENT				
	Current display in Arms and 16 Bit Numeric (Num)				
	Bar graph display 0 200 % nominal current				
	• In-Out				
	Status display of the digital input and output pins:				
	- Green: Input is present or detected and output is set.				
	- Grey: Input not applied and output not set				
	Status				
General status information (operating states, derating, limitations, etc.)					
	Warnings and errors				
	<ul> <li>Warnings and errors</li> <li>Information fields of the attached warning and error messages</li> </ul>				
	<ul> <li>Test</li> <li>Control panel for manual digital control commands of speed (N), torque (Iq) or position</li> </ul>				
	Speed (N) or torque (Iq): Numerical input (032767)				
	$[+] \rightarrow Positive command from the set value of Speed (N) or Torque (Iq)$				
	$[0] \rightarrow \text{Command value of Zero for speed (N) of Torque (Iq) selection [-] \rightarrow \text{Negative command from the set value of Speed (N) or Torque (Iq)}$				
	Position: Numerical input (±32 bit - 1)				
	Dest $\rightarrow$ Command to drive to the numerical entry of Position				
	P. $\rightarrow$ Preset entry as actual position value and command value				
	Callb $\rightarrow$ Start of a calibration run				
Footer	Left: Communication state of the servo connection to NDrive (serial or CAN)				
(black)	Middle: Firmware number				
	Right: Axis designation (self-definable)				



The freely selectable screen area (red area) is divided into various tabs and is generally used for setting the various parameters as well as various displays of the internal system structures.

This is divided into the following tabs:

Tab	Description:				
screen area:					
Start	UniTek NDrive home page with a link to the homepage and contact information.				
Settings	Main parameter settings page. Compact display with all important parameters for configuring the servo controller. This is divided into the main areas of Motor, Servo and Parameter as well as various sub-areas.				
Speed	Structural diagram of the speed and current control logic in the servo. Divided into the input speed or torque control commands (analog and digital), speed ramping and control, current ramping and control, as well as the output value of the PWMs and voltage output.				
Position	Structural diagram of the position control logic in the servo. Divided into the input position control commands and controller structure, speed ramp settings and the structure image of the calibration run.				
Logic	Setting page of the digital inputs and outputs. Subdivided into the configuration of the special functionalities of the inputs and the state setting for automatically setting the respective outputs.				
Bus	Setting page of the CAN bus communication.				
Oscilloscope	Page with the NDrive software oscilloscope. Useful tool for configuring and analysing the operating characteristics of the servo and tuning the control system.				
Monitor	Overview page with important measured variables.				
Device	Overview page with important servo information. (Mainly used for service support analysis)				
Diagnosis	Diagnostic page for displaying individually selected measured variables, as well as manual readout of signals and setting of parameters via the ID addresses.				
Auto	Settings page for motor-specific parameters and the menu for activating special functions.				
Extra	Overview page with important servo information. (Mainly used for service support analysis)				

#### Note:

Parameters that appear in different tabs are automatically adopted in the other tabs when changes are made.



# 2.2 NDrive Design – Controls

### 2.2.1 Controls – Input and selection

			Input field
Nnom	3000	RPM	Click on the selected parameter input field (left mouse button),
Fnom	150.0	Hz	Enter the numerical value and confirm with the return key.
			The changed input field is written to the servo RAM.
			Disc only whole numbers of numbers with dots after them.
			Positive values without sign, negative values with (-) sign.
			The numerical values of each input field can also be changed with the
			mouse scroll wheel. Here too, the numerical value is immediately
			written to the servo RAM.
File Com	munication	Help	Click on the selected ontion in the many har
Load	registers		and the menu items of the selected drop-down list appear.
Court	registers		Then the desired function of the individual menu items can be
Save	registers		selected.
			Pull-down menu Click the arrow key on the selection field. The selection field enlarges
EC Se	rvo	$\sim$	Scroll up or down. Click on the desired selection. The desired selection
			is accepted and the field is reduced to one display.
		_	Selection keys
	ON OFF		Click on the desired option in the keypad. The green keypad shows the
			selected function.
Join		1	The tick in the function field shows the selected function
		_	Tooltip
M-Pole	6	x4f Aotor-pole 2 to 96	Move the cursor to the parameter field or setting field with the mouse
Kt Ke	0x4f Motor pole		and a pop-up explanation field (tooltip) opens.
ne .	motor-pole		This usually contains the corresponding ID address and a short
			description.



# 3 Details Menu Bar / Help

# 3.1 Details Menu Bar / Help – File

Contents of the menu bar when selecting **File** with the associated hotkeys.

File	Communication Help	
	Load registers	Alt-L
	Save registers	Alt-S
	Import register file (*.utd)	
	Print registers	Alt-P
	Print selection of registers	
	Execute script	
	Execute command file	
	End	Alt-E

Menu items from File:	Hotkey:	Description:
Load registers	Alt + L	Load UniTek Register File (.urf)
		$\rightarrow$ Load parameter file from PC into servo Ram
Save registers	Alt + S	Save UniTek Register File (.urf)
		$\rightarrow$ Distinction if NDrive is online or offline
		Online: Save parameter file from servo Ram to PC
		Offline: Save parameter file from NDrive to PC
Import register file (*.utd)		Import UniTek Drive File (.utd)
		$\rightarrow$ Load drive file from PC into the servo
		<b>Note:</b> Function currently deactivated!
Print registers	Alt + P	Printing contents of all registers (parameters and variables)
Print selection of registers		Print the contents of the selected tabs
		$\rightarrow$ The definition of which registers are selected is made in the file " \settings\reglist.txt".
Execute script		Performing a UniTek Script File (.usf)
		Note: For production only!
Execute command file		Executing a Command File (.cmd)
		Note: Function currently deactivated!
End	Alt + X	Close NDrive
		$\rightarrow$ Disconnect the servo and close the window

# 3.2 Details Menu Bar / Help – Communication

Content of the menu bar when selecting **Communication** with the associated hotkeys.

Con	nmunication	Help	
	Offline		Alt-O
	COM1		Alt-1
	COM2		Alt-2
	COM3		Alt-3
	COM4		Alt-4
~	COM5		Alt-5
	COM6		Alt-6
	COM7		Alt-7
	COM8		Alt-8
	Baudrate		>
	View File		Alt-V
	Serial Boot		
	ParametersC	AN	
	ConnectCAN	1	

Menu items from	Hotkey:	Description:
Communication:		
Offline	Alt + O	Go offline
		$\rightarrow$ Terminate communication (serial or CAN) with the servo.
COM18	Alt + 18	Connect NDrive via the serial COM port (1 8)
		$\rightarrow$ After selecting the COM port NDrive tries to connect to the servo.
Baudrate		Setting the serial baud rate
		$\rightarrow$ The servo default baud rate is 115200
View File	Alt + V	Show contents of a UniTek Register File (.urf) (offline) $\rightarrow$ Load parameter file from PC into NDrive.
		$\rightarrow$ NDrive disconnects an existing connection to the servo.
Serial Boot		Executing the Serial Boot Function
		<b>Note:</b> Function currently deactivated!
ParametersCAN		Open parameter setting for CAN bus configuration
		$\rightarrow$ The CommunicationCAN window opens.
ConnectCAN		Connecting the NDrive via the CAN bus
		$\rightarrow$ The condition is the correct CAN bus configuration in the
		CommunicationCAN window.



# 3.3 **Details menu bar / Help – Help**

Contents of the menu bar when selecting **Help** with the associated hotkeys.

Help		
1	Manual	F1
(	Open Folder	
(	Online manual	
,	About	
1	nfo	
(	Change Language	

Menu items from	Hotkey:	Description:
Manual	F1	NDrive Manual Open (Local)
		$\rightarrow$ Open the NDrive manual in the directory "\manuals".
Open Folder		Opens the local NDrive directory "\manuals".
		Note: Contains many other useful servo manuals
		such as a initialization manual for PMS motors with resolver
		$\rightarrow$ "BAMOCAR_Initialization_process.pdf".
Online manual		NDrive Manual Open (Online)
		$\rightarrow$ Link to the Online NDrive Manual on the UniTek Homepage.
About		View NDrive Software Version Information
		$\rightarrow$ Opens the About NDrive Utility Software window which
		displays version information about the NDrive in use.
Info		View NDrive Software Debug Information
		$\rightarrow$ Opens the Menu Info window which displays useful debug
		information from NDrive.
		$\rightarrow$ Useful for analysing connection problems between NDrive
		and servo.
Change Language		Set NDrive language
		$\rightarrow$ Opens the Language window to set the NDrive language.
		<b>Note:</b> NDrive must be restarted after changing the language.



# 4 Communication with NDrive

### 4.1 Communication with NDrive – Hardware

For successful communication with NDrive via either Serial RS232 or CAN, appropriate hardware must be used for the respective communication method.

#### Serial RS232 (COMx)

NDrive communicates from the PC with the servo via RS232 (default baud rate 115200).

If the PC has a USB interface, use a USB to serial RS232 adapter.

Only connect the connecting cable when the Plug and pull interface.

The interface is galvanically connected to the device ground (GND).



#### CAN bus

NDrive uses for the communication from the PC to the servo the CAN bus library from PEAK-System Technik GmbH.

Use a PCAN-USB adapter for the PC with USB interface.

An external power supply for the CAN bus is not necessary. The servo has an internal power supply.



The connecting cable from the PCAN-USB adapter to the servo must have the appropriate terminating resistors for a stable connection.



#### Note:

For general CAN communication with the servo independent of NDrive, other CAN bus providers (e.g. Vector CAN) can also be used.



### 4.2 **Communication with NDrive – Establish connection**

No additional drivers need to be installed for NDrive to communicate with the servo. However, the corresponding drivers of the connected adapters (serial or CAN) must be installed.

#### 4.2.1 Establish connection – Serial RS232

Before starting communication, make sure that the COM channel for the serial connection is known.

In the menu bar, open the option **Communication** and select the **COMx** interface (COM1 to COM8) and click on it. The hooked interface is selected and the connection to the servo is established.

The connection status is displayed in the footer. The connection was successful if **Drive is online (COMx, ...)** can be seen in the status bar.

File	Com	nmunication	Help	
SPEE RPM		Offline	Alt-O	
		COM1	Alt-1	
		COM2	Alt-2	
CUR		COM3	Alt-3	
Arm		COM4	Alt-4	
	$\checkmark$	COM5	Alt-5	
		COM6	Alt-6	
In-C		COM7	Alt-7	
		COM8	Alt-8	

Drive is online (COM5, 115200).

All parameter fields update their fields with the values from the servo RAM memory.

#### End communication:

Open the option **Communication** in the menu bar and click on **Offline**. The disconnected connection is displayed in the footer. The footer flashes: "**Drive is offline.**".

#### 4.2.2 Faulty communication – Serial RS232

- 1. Scroll through data in the warning or error display
  - → COM connection not OK or wrong COM port selected.
- 2. Status symbols flash or an additional window appears with an error message
  - → Download the new NDrive from the UniTek homepage (<u>link</u>).
  - → Contact UniTek Customer Service.
- 3. All names are displayed incorrectly.
  - → Select the language via **Help** → **Change Language...** and restart NDrive.



#### 4.2.3 Establish connection – CAN Bus

Ensure before starting communication, that the CAN port channel of the PCAN-USB adapter is known.

At the beginning, the CAN configuration must be carried out once.

In the menu bar, open the option **Communication** and select **ParametersCAN** and the **CommunicationCAN** window opens. This is where the CAN communication is configured.

For a first conn	ection, the defau	ult settings are
Can Port:	PCAN_USB1	(Depending on user CAN port channel!)
CAN Baud:	500000	(500 kBaud)
Servo RxID:	0x201	
Servo TxID:	0x181	

To establish a connection, open the following in the menu bar the **Communication** option and click on the **ConnectCAN** selection.

The connection status is displayed in the footer. The connection was successful if **Drive is online (PCAN\_USBBUS1, 500000)** can be seen in the status bar.

Drive is online (PCAN\_USBBUS1, 500000).

All parameter fields update their fields with the values from the servo RAM memory.

#### End communication:

Open the option **Communication in** the menu bar and click on **Offline.** The disconnected connection is displayed in the footer. The footer flashes: "**Drive is offline.**".

#### 4.2.4 Faulty communication – CAN bus

- 1. No connection is established.
  - → Check hardware and wiring.
  - → Check whether the correct drivers are installed for the PCAN-USB adapter and that it was really recognised (→ see Windows Device Manager).
  - → Check the settings in the CommunicationCAN window.

A good way to check the general CAN communication with the servo is to send a single CAN message via a general CAN program (e.g. PCAN-View) and check if the servo responds.

Example:

Send	ID: 201h DLC: 3 Msg.: 3D 1B 00	ightarrow Request for firmware number
Receive	ID: 181h DLC: 4 Msg.: 1B DE 01	$\rightarrow$ FW number 478

2. All names are displayed incorrectly.

→ Select the language via **Help** → **Change Language...** and restart NDrive.

Con	nmunication	Help	
	Offline		Alt-O
	Serial Boot		
	ParametersC	AN	
~	ConnectCAN	1	

CommunicationCAN		×
CAN Port	PCAN_USBBUS1	~
CAN NBT	500000	
Servo RxID	0x201	
Servo TxID	0x181	



# 4.3 Firmware update

In the folder of the PC user software NDrive: ...\NDrive2-Software\manuals", use the manual "<u>Firmware update-2020-C2Prog\_EN.pdf</u>".

#### PC user software NDrive:

UniTek Home	page: <u>https://www.unitek-indu</u>	<u>strie-elektronik.de/</u>
Link	Download	
Download	NDrive2-Software.zip	Press "NDrive2-Software.zip" and save
		(e.g. downloads)
Extract	NDrive2-Software.zip	Press RM + (Extract all / Unzip here)
Folder	"NDrive2-Software\manuals"	

By pressing the return key, the changed parameter is directly updated to the servo RAM.

# 5.1.1 Saving in the servo (Eprom)

#### **Eprom Write (save parameters permanently):** Click on the **"Eprom - STORE 0 or 1"** button on the Settings page.

The parameter data is written to the selected level 0 or 1 from the Eprom. Eprom level 0 contains the current parameter set. Each time the 24 V auxiliary voltage is switched on, all parameters from Eprom level 0 are loaded into the RAM memory of the servo.

### Attention:

5

When the 24 V auxiliary voltage is switched off, the RAM data is lost.

### 5.1.2 Loading from the Eprom

### Eprom read (parameter load):

On the Setting page, click on the **"Eprom - RECALL 0, 1 or 2"** button.

The parameter data is taken from the Eprom of the selected level 0, 1 or 2

and loaded into the servo RAM and into the RAM memory of the PC (if connected).

Each time the 24 V auxiliary voltage is switched on, all parameters from Eprom level 0 are loaded into the RAM memory of the servo.



Saving and Loading of servo parameters

5.1 Saving and Loading in the servo (Eprom)





G







### 5.2 Save parameter data to and load from PC

#### 5.2.1 Saving parameter data (.urf) on the PC

Saving the .urf (unitek register file) parameter file to the PC data carrier (hard disk, etc.) with the contents from the device RAM from the servo can be done in 2 different ways.

#### Via the menu bar:

 Click on File in the menu bar.
 File
 Communication
 Help

 Click on the option Save register....
 Load registers...
 Alt-L

 The Save Register File window opens.
 Save registers...
 Alt-S

#### With the diskette symbol (save button):

On the Settings page, click on the **diskette symbol** (Save). The Save Register File window opens. Define the file name and save.



#### 5.2.2 Loading parameter data (.urf) from the PC

Loading the "unitek register file" (.urf) parameter file from a PC data carrier (hard disk, etc.) into the device RAM of the servo can be done in 2 different ways.

#### Via the menu bar:

Click on **File in** the menu bar. Click on the option **Load Register...**. The Load Register File window opens. Select the Parameter (.urf) file and open.

#### With the folder icon (load button):

On the Settings page, click on the **folder icon (Load)**. The Load Register File window opens. Select the Parameter (.urf) file and open.

After loading, the parameters are now in the device RAM memory of the servo. At the same time, all parameter fields in NDrive are overwritten with the loaded values.

#### 5.2.3 Offline operation of parameter data (.urf) on the PC

Load, modify and save Parameter (.urf) files in offline mode: In the menu bar click on **Communication** and then **View File...**. After selecting the Parameter (.urf) file in the Load Register File window, all parameters are loaded into NDrive.

The loaded parameters can now be viewed and changed.

Click on File and Save registers... in the menu bar and save to the same or as a new parameter (.urf) file.



# 6 Basic status information

# 6.1 Status information – Speed and current

Speed in rpm (revolutions per minute) and as a numerical value from the measured value from the ID address 0xA8.

Current in Arms (effective motor current in amps) and as a numerical value from the measured value from the ID address 0x5F.



# 6.2 **Status information – Inputs and outputs**

If the input voltage is positive >10 V and the output voltage is set, the LED indicators will light up.

Symbol:	Function:	ID address:	In-Out
		0xD8	C LMT1
LMT1	Digital input limit 1	Bit 0	LMT2
LMT2	Digital input limit 2	Bit 1	
IN2	Digital input Din 2	Bit 2	
IN1	Digital input Din 1	Bit 3	
RUN (FRG)	Digital input of the software rotary field enable RUN	Bit 4	
RFE	Digital input of the hardware rotary field enable RFE	Bit 5	
	rsvd	Bit 6	ě
	rsvd	Bit 7	
OUT1	Digital output Dout 1	Bit 8	00011
OUT2	Digital output Dout 2	Bit 9	0012
RDY (BTB)	Hardware relay output BTB-Rdy	Bit 10	RDY
GO	State of internal enable GO	Bit 11	GO
OUT3	Digital output Dout 3	Bit 12	OUT3
OUT4	Digital output Dout 4	Bit 13	OUT4
	rsvd	Bit 14	
BRK1	State of excited Brake	Bit 15	BRK1



# 6.3 Status information – Status display

The operating states are shown in the status display / status field.

Symbol:	Function:	ID address:	
		0x40	Status
Ena	Drive enabled	Bit 0	Status
	(Combination hardware RFE and software RUN)		🔘 Ena
NcR0	Speed limited to zero (last setpoint still active)	Bit 1	NcR0
Lim+	Limit switch plus active	Bit 2	C Lim+
Lim-	Limit switch minus active	Bit 3	C Lim-
ОК	Drive in order	Bit 4	Ок
	(no uncontrolled reset)		
lcns	Current limit reduced to continuous current	Bit 5	O T-Nlim
T-Nlim	Speed-limited while in torque control	Bit 6	O P-N
P-N	Position control active	Bit 7	
N-I	Speed control active	Bit 8	
<n0< td=""><td>Actual speed less than 0.1 % (standstill)</td><td>Bit 9</td><td></td></n0<>	Actual speed less than 0.1 % (standstill)	Bit 9	
Rsw	Reference switch tripped	Bit 10	RSW
Cal0	Calibration run in progress	Bit 11	Calo
Cal	Calibration run completed (position calibrated)	Bit 12	Cal
Tol	Position within tolerance window	Bit 13	Tol
Rdy	Ready for operation (BTB/RDY contact closed)	Bit 14	🔘 Rdy
Brk0	Brake not excited with motor active	Bit 15	Brk0
			Ctatus
SignMag	Setpoint inverted	Bit 16	Status
Nclip	Speed limitation activated (N-Lim < 90 %)	Bit 17	SignMag
Nclip+	Speed limitation positive via switch	Bit 18	🔘 Nclip
Nclip-	Speed limitation negative via switch	Bit 19	Nclip+
Ird-Dig	Current limitation via switch	Bit 20	Nclip-
luse-rchd	Current reduction limit reached	Bit 21	Ird-Dig
Ird-N	Current reduction via speed	Bit 22	Uuse-rchd
Ird-TI	Current reduction via output stage temperature enabled	Bit 23	O Ird-N
Ird-TIR	Current reduction to continuous current via output stage	Bit 24	
	temperature is active		
Ird-10Hz	Current reduction at a rotation frequency	Bit 25	
	smaller than 10 Hz		
Ird-TM	Current reduction via motor temperature	Bit 26	
Ird-Ana	Current reduction via analogue input (if $\leq$ 90 %)	Bit 27	o ird-Ana
lwcns	Current peak warning	Bit 28	Iwcns
RFEpulse	Pulsed RFE input monitoring active	Bit 29	RFEpulse
Fiwe Acv	Fieldweakening active	Bit 30	Fiwe Acv
HndWhl	Handwheel input selected	Bit 31	HndWhl



# 6.4 Status information – Error(s)

Error		ID-Adresse:	Servo
in NDrive:		0x8F∟	Display:
NOREPLY- No RS232 COM reply	RS232 interface not plugged in or disturbed		
0: Eprom Read Error	Reading from Eprom defective	Bit 0	0
1: HW Fault detected	Critical hardware error detected	Bit 1	1
2: RFE input not present	Safety circuit not present	Bit 2	2
	(With RUN input active)		
3: CAN TimeOut Error	CAN TimeOut Time exceeded	Bit 3	3
4: Feedback Signal Error	Bad or missing feedback signal	Bit 4	4
5: Mains Voltage Min. Limit	Power voltage missing (digital)	Bit 5	5
	or below DC-Bus min limit (analogue)		
6: Motor-Temp. Max. Limit	Motor temperature too high	Bit 6	6
7: IGBT-Temp. Max. Limit	Output stage temperature too high	Bit 7	7
8: Mains Voltage Max. Limit	Power voltage > 1.8 x UN (digital)	Bit 8	8
	or above DC-Bus max limit (analogue)		
9: Critical AC Current	Overcurrent or strong oscillating current	Bit 9	9
	detected		
A: Race Away detected	Spinning (without setpoint, wrong direction)	Bit 10	А
B: ECode TimeOut Error	Bad or missing ECode protocol	Bit 11	В
C: Watchdog Reset	CPU Reset because of Watchdog detected	Bit 12	С
D: I Offset problem	AC Current Offset detection fault	Bit 13	D
E: Internal HW voltage problem	Error beacuse of internal Voltage problem	Bit 14	E
F: Bleed resistor overload	Only certain motor controllers	Bit 15	F

In the **Error** state, the information of the errors is transmitted to NDrive via the ID address 0x8F and displayed in the "Error(s)" field.

#### Error(s)

- 4: Feedback Signal Error
- 5: Mains Voltage Min. Limit
- 6: Motor Temp. Max. Limit

Clear errors

#### Attention:

- When the auxiliary voltage is applied with the enable closed (RUN X1:7 active), the red LED shows an error. There is no error indication in the 7-segment display.
- Error 1 (POWEWRFAULT) is a sum error message of the hardware monitoring. Additional checking of the status of the signal I Fault (ID: 0xE9) is necessary.

In case of an error:

- the red FAULT diode lights up and the error number is displayed
- the BTB contact is opened
- the software BTB message switches from 1 to 0
- the status message Rdy goes dark
- and when the enable is switched off, the error message remains.

The error message is deleted (enable must not be set):

- when Cancel errors is activated by a digital input
- when a Cancel Errors command via CAN or Serial is send
- with a positive edge from the enable input RUN (FRG)

Light indicator on servo





# 6.5 Status information – Warning(s)

Warnung		ID-Adresse:	Servo
in NDrive:		0x8F <sub>H</sub>	Anzeige:
0: Parameter conflict detected	Parameters are from different device type	Bit 16	0
1: Special CPU Fault	RUN input with jitter or EMI problems	Bit 17	1
2: RFE input not present	Safety circuit not present	Bit 18	2
	(without RUN input active)		
3: Auxiliary Voltage Min. Limit <sup>1</sup>	Auxiliary Voltage is too low	Bit 19	3
4: Feedback Signal problem <sup>2</sup>	Bad or missing feedback signal	Bit 20	4
	(Feedback supervision deactivated)		
5: Warn. 5		Bit 21	5
6: Motor-Temperature (>87%)	T-motor > (I-red-TM oder 93 % von M-	Bit 22	6
	Temp)		
7: IGBT Temperature (>87%)	T-igbt > 87 % vom Limit	Bit 23	7
8: Vout Saturation Max. Limit	Limit of existing voltage output reached	Bit 24	8
9: Warn. 9		Bit 25	9
A: SpeedActual resolution Limit	Resolution range of the speed	Bit 26	А
	measurement exceeded		
B: Check ECode ID: 0x94	Error with an ECode information at ID	Bit 27	В
	Register 0x94 detected		
C: Tripzone Glitch detected	Tripzone triggered unintentional	Bit 28	С
D: ADC Sequencer problem	Problem of the ADC Sequencer channels	Bit 29	D
E: ADC Measurement problem	Problem of internal ADC voltages	Bit 30	E
F: Bleeder resistor load (>87%) <sup>1</sup>	Ballast circuit > 87 % overloaded	Bit 31	F
<sup>1</sup> Only certain motor controllers <sup>2</sup> Feedback supersion is deactivated. Warning indi	cates that a Problem is present		

In the **Warning** state, the information of the warnings is transmitted to NDrive via the ID address 0x8F and displayed in the "Warning(s)" field.

Warning(s)

6: Motor Temperature (>87%)

#### Attention:

In case of a warning:

• The red error LED flashes and the green 7-segment display alternately shows the status and the warning number.

#### Example: Warning 6

_		Light indicator:	
Ь.	Fault	<ul> <li>FAULT LED red - flashing</li> <li>The display alternates between status and warning number 6</li> </ul>	6: Motor-Temperature (>87%)



# 6.6 Status information – Operating status display on the servo

<b>Display:</b> (7 segment LEDs)	Dot/ dash:	Condition:	Status in NDrive:
	flashes	Processor active	
	dark	Auxiliary voltage missing or device internal hardware error	
	flashes	Start status after reset (auxiliary voltage 24 V off-on) The first release ends the flashing state	ОК = 0
	lights up	Drive enabled	OK = 1, ENA = 1
	dark	Drive locked (not enabled)	OK = 1, ENA = 0
	lights up	Speed equal to zero (standstill message)	NO = 1
	lights up	Drive turns right, N current is positive	NO = 0
	lights up	Drive turns left, N current is negative	NO = 0
	flashes lights up	Motor current reduced to continuous current lwcns Motor current at maximum current limit lmax	lwcns = 1 lwcns = 0
	dark	Normal operation. Motor current within current limits	lwcns = 0
	lights up for 0,1 s	Left bar: A new command (value) has been received from the BUS or RS232	
		Right bar: Digital input changed	

#### Example: Motor clockwise

- Dot flashes
- Processor activeDrive enabled
- Bottom line = D Right line = M
  - = Motor turns right



### Ballast circuit

switches:

Direction bar (bottom right or left) is switched off while the ballast circuit is switched on.

# 7 Enable

# 7.1 Enable – Hardware Input RUN (FRG) (Enable)

#### Switching on

Voltage at the enable input (X1:7, X1:G RUN (FRG)) is between 10..30 V=. When the enable input is switched on, the power stage is enabled without delay. The software control of the power stage is delayed by 2 ms. Send operation commands such as setpoints, homing, etc. 5 ms after enable. The Enable state is displayed in the status field at **Ena**.

#### Switching off

Voltage at the enable input (X1:7, X1:G RUN (FRG)) is less than 4 V=. When the enable is switched off, the drive is electronically disabled.

#### Switching off with emergency stop function (Coast stop Off)

Coast stop ON OFF

The drive decelerates to standstill before it is disabled.

When the enable function is switched off, the internal speed setpoint value of **N cmd Ramp** is reduced to zero according to the setting of **R-Lim**.

The power section is disabled by means of the internal command **GO** 50 ms after the axis has come to a standstill or after the ramp time of R-Lim + 50 ms has elapsed. The power stage is disabled after 1.5 s at the latest.

#### Switching off without emergency stop function (Coast stop ON)

When the enable is switched off, the power stage is immediately blocked. The drive coasts to a stop without torque.

Set **R-Lim** (if Coast stop is OFF) so that the drive is decelerated to a standstill. 50 ms after the switch-off ramp time R-Lim has elapsed, the power unit is disabled. After this the drive is free of torque.





# 7.2 Enable – Lock and enable via interfaces (CAN bus, RS232)

This is a special procedure to obtain a release if the release inputs are already present. I.e. the hardware input RUN (FRG) and the safety input RFE are already switched on.

#### Lock

With the command **ENABLE OFF** (MODE-BIT  $0x51Bit_2 = 1$ ) the internal speed setpoint is **N cmd (ramp)** controlled to zero with the ramp **R-Lim** set in the Speed parameter field.

#### Enable

With the command **NOT ENABLE OFF** (MODE-BIT  $0x51Bit_2 = 0$ ) the servo is enabled without delay.

#### Software enable from NDrive

The hardware input RUN (FRG) and the safety input RFE are already switched on.

#### "Dis" button

grey = software release = ON red = software release = OFF

Test			
Speed (N) $$	O Dis		
0	+	0	-
Position (P)			
0	Dest	Ρ.	Calib

#### Sequence for enabling with hardwired RFE and RUN input:

- 1. First lock the servo with the command ENABLE OFF (MODE BIT 0x51Bit 2 = 1).
- 2. Then unlock the servo with the command **NOT ENABLE OFF** (MODE BIT 0x51Bit <sub>2</sub> = 0). The servo is enabled without delay.
  - $\rightarrow$  Only in this order can an enabled be achieved.
  - $\rightarrow$  At the same time, all stored errors are deleted.



# 7.3 Safety input RFE (rotating field enable)

#### Attention:

With the enable input RUN (FRG) switched off - or the rotary field enable (RFE), the drive is disabled and free of torque. The drive could move, if there is no additional mechanical brake or block provided.

The motor conductors are **not** free of voltage. Only the rotating field is disabled. Prior to any work or maintenance on the motor or servo drive, the servo drive must be completely disconnected from the mains power supply.



#### 7.3.1 Operation with external RFE input

- Two-channel enabling lock via a safety switching device
- Switch on enable input RUN (FRG) plus rotary field enable input RFE
- Safety device Contacts closed
- Enable RUN (FRG) 0.5 s after RFE

#### Safety shutdown

- Safety device contacts opened
- No RUN (FRG) signal blocks the PWM pulses in the processor in the first blocking channel
- No RFE signal blocks the PWM pulses in a second blocking channel after the processor

#### Restart

- Release the safety switching device
- Safety device Contacts closed

The motor can only be controled after a enable input RUN (FRG) is set after the rotating field input (RFE).



DS, BAMOBIL

# Enable



#### 7.3.2 Operation without external RFE input

The RFE input must be bridged with the logic voltage. I.e. 24 V output is used as input for RFE.

If the logic voltage is equal to the auxiliary voltage the RFE input is bridged with +24V.

Enable RUN (FRG) 0.5 s after RFE signal.

#### Attention:

For round plugs or Tyco plugs (BAMOCAR, BAMOBIL) use the plug configuration from the unit MANUAL.





# 8 Settings

Main parameter overview and input on the **Settings** page.

UNITER	Settings	Speed	Position	Logic	Bus	Oscilloscope	Monitor	Device	Diag	nostics	Auto E	Extra				
Motor Type N nom F nom V nom Cos Phi	EC Servo 3000 150.0 0 0.00	RPM Hz V	Servo Type S-Nr. Axis Mains Mains	DS 123 sel	405 456789 Rrad 230	64206 DC	Par Cur Kp Ti TiM xKp2	ameter rent 2 6 1 2 0	0 00 00	μs %	Speed Kp Ti Td TiM	20 10 0 60	ms ms %	F Position - Kp Ti Td TiM	5 150 0 80	ms ms %
l max eff l nom eff M-Pole Kt Ke Brake delay	10.0 5.3 6 0.000 90.00 250	A rms A rms Nm/A V/krpm ms	DC-Bu DC-Bu Regen Regen Regen	s max s min -P -R	144 6 1111 25 80	% % EXT W Ohm	Kf Ram I ma I ma	0 xp 2 xpk 1 xpk 1	000 00 0.6	us % A pk	Kacc Filter N R-Acc N R-Dec R-Lim	0 4 300 300 1000	% ms ms ms	Tol-wind Off. Ref. ND-Scale ND-Offset	500 0.000 1 0	
Coast stop M-Temp Feedback	<b>ON</b> OFF 7000	Num	BTB Po PWM 1	ower freg nand —	8 kHz	iohna V	l cor T-pe I lim I-rec	ak 5 Idig 1 J-N 1	.0 00 00	Arms s % % Num	M R-Acc M R-Dec M R-Rcp N-100%	10 50 1000 3000	ms ms ms RPM %	Reference Speed 1 Speed 2	0 100	Num
Type F FB-Pole FB-Offset FB-Incr (Mot)	2 -58.4 2048	Deg Inc/Rev	Mode Cutoff Analo	(dig.) gout	Dig. Co 0 N actu	al V	I-red I-red I-red	I-TE 2 I-TM 5	3000 600	Num Num	N-Lim+ N-Lim-	100 -100	96 96	Reso edge Ref-Ramp	0 DEC EL	Num
2. Feedback Type - Inc-ext Factor-ext Inc-Out Factor	64206 0 64206 12 bit	V Inc/Rev Num Inc/Rev	Analo Forma Offset Cutoff Scale Filter Mode	a Ain 1 +Cm 0 100 1.00 0.0 -10	1 d ~ 0 +10 <sup>1</sup> ~	Ain 2 Off ~ 0 0 1.000 0.0 ms -10+10 <sup>1</sup> ~	T dc V dc V mi F mi V co F co F-sh	2 0 n 4 n 1 rner 1 ii	00 .3 .0 .0 00.0 8.0 near	ms 96 96 Hz 96 Hz						
									RA	M ↔ PC	😫 👱	Epro			Eprom - S	

Input fields for the motor data, the device data (servo), the parameter data and the Icon Buttons for the save and load functions.

The settings for the motor and servo are only entered on the Settings page. The parameter inputs can be entered on different pages.

The changed parameter data is immediately adopted on all pages.

See detailed description of the input fields.

#### Attention:

Before the first commissioning and in case of changes of the motor type the data in the setting fields with the type plate or data sheet of the motor.

Observe engine-specific connection instructions!

In online mode, the setting values may only be changed by trained specialist personnel!





# 8.1 Settings – Motor

Parameter overview for nominal motor data based on information from the motor nameplate and motor data sheet.

Motor		
Туре	EC Servo	$\sim$
Nnom	3000	RPM
Fnom	150.0	Hz
Vnom	0	v
Cos Phi	0.00	
I max eff	10.0	A rms
I nom eff	5.3	A rms
M-Pole	6	
Kt	0.000	Nm/A
Ke	90.00	V/krpm
Brake delay	250	ms
Coast stop	ON OFF	1
M-Temp	7000	Num

Symbol:	Function:	Range:	Unit:	ID address:
Туре	Selection of motor type (EC servo, FU, FU servo, DC)			0x5A <sub>Bit 1312</sub>
N nom	Motor speed (for FU autotuning)	6065000	rpm	0x59
F nom	Frequency rated motor speed (for FU mode)	201200	Hz	0x05
V nom	Voltage at rated motor speed (for FU mode)	01000	V	0x06
Cos Phi	Motor power factor (for FU mode)	0327,00	%	0x0E
I max eff	Motor maximum current	01000,0	Arms	0x4D
I nom eff	Motor continuous current	01000,0	Arms	0x4E
M-Pole	Motor pole number (2 x pole pairs)	296	Num	0x4F
Kt	Motor Kt constant	050,000	Nm/A	0x87 <sub>L</sub>
Ке	Motor Ke constant (Back EMF)	0500,00	V/krpm	0x87 <sub>н</sub>
Brake	- Attraction delay time of the electro-mechanical	01000	ms	0xF1
delay	motor brake			
	<ul> <li>Deceleration delay when no brake is connected</li> </ul>			
Coast	Free run (ON) or emergency stop braking (OFF)	On / Off		0x5A <sub>Bit 3</sub>
stop	(when switching off the enable RUN)			
M-Temp	Motor overtemperature switch-off point (error code 6)	032767	Num	0xA3
	(At 93 % there is a warning message 6 with current			
	derating Ird-TM activation).			

Overview of the motor type selection

	Motor Type	e:
EC Servo V	EC Servo	Synchronous servo motor with encoder system (sensor)
EC Serve	ACI V/f	Asynchronous motor frequency converter without sensor
ACL M/F		(U/F characteristic without slip compensation)
ACI V/T	ACI Servo	Asynchronous motor AC servo-vector control with speed
ACI Servo		encoder system
DC		(e.g., bearing encoder A, B channel)
	DC	DC motor without or with DC tacho encoder



# 8.2 Settings – Feedback (encoder)

Parameter overview for the setting field of the feedback encoder nominal data on the basis of the encoder data sheet.

Shortz.:	Function:	Range:	Unit:	ID address:
Туре	Feedback selection			0xA4 <sub>Bit 40</sub>
	(Red_Enc_TTL, Resolver,)			
FB-Pole	Encoder pole number	212	Num	0xA7
FB-Offset	Phase angle correction	±360	Degree	0x44
FB-Inc (Mot)	Resolution encoder	10248192	Inc/Rev	0xA6
Voltage	DC tachometer voltage		mV/rpm	
Inc-Out	Resolution 2. encoder		Imp/Umd	0xCF∟
Factor	Multiplier SIN/COS Inc.	416	Num	0x7E

Overview of suitable feedback encoders for the respective motor types.

Engine type:	Suitable feedback type:	Туре	Resolver	$\sim$
EC Servo	Rot Enc TTL, Enc TTL (conditional)	FB-Pole	2	
	Resolver	FB-Offset	-58.4	Deg
	Abs_Enc_SC, Enc_SC, Abs_SC	FB-Incr (Mot	:) 2048	Inc/Rev
	Rot			
ACI V/f	SLS, Enc_TTL			
ACI Servo	Enc_TTL	2. Feedbac	k	
	Resolver	Туре		$\sim$
	Abs_Enc_SC, Enc_SC, Abs_SC	Inc-ext	64206	Inc/Rev
DC	Enc_TTL	Factor-ext	0	Num
	Resolver		•	
	Abs_Enc_SC, Enc_SC, Abs_SC	Inc-Out	64206	Inc/Rev
	DC_Tacho	Factor	12 bit	~
	DC_Arm, BL_Arm, DC_Arm_Vir			

#### Attention:

- Depending on their hardware configuration, servo drives are only designed for certain encoders.
- The encoder must be coordinated with the hardware configuration of the motor.
- The selection of the encoder type must match the configuration of the servo for the respective encoder type. I.e. a digital servo is only configured for a certain type of encoder.

Feedback

# Settings



### Resolver encoder:

Resolver	Resolver encoder with 10 kHz and 2 Vpp
FB-Pole	Encoder pole number 2 to 12
FB-Offset	Correction value for the mechanical encoder setting
	Pole wheel angle ±360 degrees
	Automatic recognition of the offset angle = see page AUTO

#### Incremental encoder:

Red_Enc_TTL	Incremental encoder 5 V TTL with rotor position tracks		
FB-Offset	Correction value for the mechanical encoder setting		
	Automatic recognition of the offset angle = see page AUTO		
FB-Inkr (Mot)	Impulse count per revolution		
Attention: The encoder rotor position pole number must match the motor pole number!			

ENC-TTL	Incremental encoder 5 V TTL without rotor position tracks
FB-Inkr (Mot)	Number of pulses per revolutionOnly
	for asynchronous motors or special drives

#### SINUS/COSINUS encoder:

<b>Abs_Enc_SC</b> FB-Offset FB-Inkr (Mot)	1 Vss sin/cos encoder with sin/cos commutation tracks Correction value for the mechanical encoder setting Pulse number per revolution
ENC_SC	1 Vss sin/cos encoder without commutation track
FB-Inkr (Mot)	Pulse number per revolution
ABS_SC	Sine-cosine signal per motor pole pair (analogue Hall sensors)
M-Pole, FB-Pole	Number of motor poles and number of encoder poles equal (M poles = FB poles)

#### Rotor position encoder 5 V, 15 V:

ROT_TACHO FB-Offset	Rotor position sensor with bl tacho (DC tacho) Correction value for the mechanical encoder setting
ROT	Rotor position sensor without bl tacho, only rotor signals (3 digital hall sensors)
FB-Offset	Correction value for the mechanical encoder setting

**BL-ARM**EC/AC motor without tacho**Attention:** The encoder rotor position pole number must match the motor pole number!

# Settings



#### Feedback for DC motors:

DC_TACHO	DC motor with tachometer
FB Offset	120 = Connection M1-M3 (0=M2-M3, -120=M1-M2)
DC-ARM	DC motor with armature voltage sensor (without tacho)
FB Offset	120 = M1-M3 (0=M2-M3, -120=M1-M2)
DC_ARM_VIR	Sensorless DC motor without tachometer, without armature voltage measurement
FB Offset	120 = Connection M1-M3 (0=M2-M3, -120=M1-M2)
Sensorless drives	<u></u>
SLS	Sensorless only for AC motor without feedback encoder in FU operation (ACI V/f) No setting

SLS\_SMO not yet available

SLS\_Usens not yet available

In case of changing the feedback parameters it is necessary to reset the parameter.

- $\rightarrow$  Write the parameter set into the Eprom (Eprom STORE 0)
- $\rightarrow$  and re-read the set of parameters (Eprom RECALL 0)





# 8.3 Settings – 2nd feedback

Parameter overview for setting the X8 connection as the second counter input

Shortz.:	Function:	Range:	Unit:	ID address:
Туре	Selection of 2nd Feedback encoder input			0xA4 <sub>Bit 75</sub>
Inc-ext	Resolution increments 2nd encoder Inc/Rev 0xC		0xCF <sub>L</sub>	
Factor-ext	Encoder factor 2nd encoder	416	Num	0x7E
Inc-Out	Increments output resolution		Inc/Rev	0xCF <sub>H</sub>
Factor	Multiplication factor of the basic pulse number			0xA4 <sub>Bit 1412</sub>
	for SinCos (SC)			

#### Type: Selection for the 2. Feedback encoder input (2. Feedback)

	Input switched off
Enc - Position	Position input
Enc - Info	Info display only input
Enc - Hand.	Handwheel input
SSI	SSI encoder input



Example: Setting X8 as input for incremental encoder signals

#### Type = Enc - Position:

Incremental encoder TTL 5 V A,B,N + push-pull Bridge between X8:1 and X8:6 (X8 switched as input)

#### Factor-ext (scaling):

Calculate the transmission 1 motor revolution = 65536 Num (internal counter)

#### Factor-ext for the adjustment of the 2nd encoder (0x7E)

Encoder\_2\_Scale = 65536 / encoder pulses from 2nd encoder per motor revolution \* 4

Input at Factor-ext. (0x7E) = Encoder\_2\_Scale \* 16384

#### Output:

1 motor revolution corresponds to 0.1 encoder revolutions Encoder pulse number 1000 rpm Pulses per motor revolution 0.1 \* 1000 \* 4 = 400

Input at Encoder\_2\_Scale = 65536 / 400 = 163,840

Input Factor-ext. (0x7E) = 163,840 \* 16384 = 2684354
# Settings



Example: Setting X8 as output for incremental encoder signals

#### Type = Enc - Info:

Setting value of the output pulse number for resolver encoder signals at the X8 connection.

The encoder signals (feedback) supplied by the motor are used as TTL encoder signals for the output at the Sub-D connector X8 (example CNC control). Signals: Channel A, Channel /A, Channel B, Channel /B, Channel N, Channel /N

The encoder output is electrically isolated. Power is supplied via the encoder cable from the CNC/PLC control. Power supply 5 V (±0.2 V) The output signal corresponds to RS485

**Option:** Internal supply from servo (LBR1 + LBR2)

#### **Resolution:**

The resolution is programmable for the variants -RS and -SC. With -IN, the output corresponds to the encoder pulse count. Factor - Multiplication factor of the basic pulse number at SinCos (SC).

Pulses per revolution:	<b>Resolution:</b>	ID address:
		0xA4 <sub>Bit 1412</sub>
256	10 bit	3 dec
1024	12 Bit	2 dec
4096	14 bit	1 dec

Inc-Out	64206	Inc/Rev
Factor	12 bit	~
	14 bit	
	12 bit	
	10 bit	



## 8.4 Settings – External brake

#### Adjustment and control of an external brake:

Many motors have a built-in brake that must first be released by a control before the motor can be rotated. The inverter can control this external brake accordingly.

The brake built into the motor has the maximum braking force in the de-energised state. According to the electrical control, the brake has a type-related on-delay and off-delay defined via the **Brake delay** parameter.

The digital output can switch a brake up to 24 V and 1 A directly. For brakes with higher currents or higher voltages, a relay must be connected in between.

The brake output is activated on the **Logic** page in the parameter field - **Output**. In the pull-down menu for **Dout 1**, **Dout 2** or **Dout 3**, configure the **O-Break** command by clicking on it in the display field.

In the pull-down menu, select the operand [=] (equal) or [!=] (not equal) by clicking on it.

Select the switching function of the output by selecting **0** or **1** in the variable field (normal 0).

On the Settings page in the **Motor** parameter field, enter the drop-out delay of the motor brake (from the brake data sheet) in the **Brake delay** parameter (0..500 ms).

Brake active is displayed in the status field with "BRK1".

#### Attention:

Connect a free-wheeling diode or a varistor directly to the brake connection on the motor.

#### Example of setting a brake output on the Logic page:

Digital outputs	Selection
Dout1	Brake de-energised when enable is switched off. Set the
	release delay with Brake delay.
Dout2	Off
Dout3	Off
Dout4	Off

OUTPUT				
Dout1	O Brake	✓ !=	~ 1	~



#### Description of the brake function (control of the external brake):

When deactivating the enable RUN (FRG) or the CAN command **ENABLE OFF = 1**, the internal speed setpoint **N cmd Ramp** is controlled to zero with the programmed ramp **R-Lim**. After a fixed delay time of 50 ms, the parameter **Brake** is switched from 1 to 0. The braking force increases. After the programmed time **Brake delay**, the internal parameter **GO** is switched to 0 and the servo is locked (torque-free standstill).

#### Description of the brake release function (releasing the external brake):

When enabling RUN (FRG) or the CAN command **ENABLE OFF = 0** is activated, the setpoint is kept at 0 and the status **GO** is immediately switched to 1 when the brake is active.

After 50 % of the **Brake delay** time, the brake is switched off and after another 50 % the setpoint is increased with the ramp **N R-Acc**.



#### Attention:

- The sum of the times of **R-Lim** plus **Brake delay** must be less than 1 s.
- At 1.1 s after switching off the enable, the output stage is disabled by hardware.
- The electrical braking is cancelled and the drive coasts to a stop. After the too long time of **R-Lim** plus **Brake delay** has elapsed, the mechanical brake engages and stops the drive.



## 8.5 Settings – Ballast circuit

- For servo units with a digital DC link setting (0x5A<sub>Bit 7</sub> = 0), the ballast circuit operates directly controlled by the hardware.
- For servo units with an analogue DC link setting (0x5A<sub>Bit 7</sub> = 1), the ballast circuit is controlled by the TMS control card.

Control for the ballast circuit depends on the configuration of the DC link monitoring.

- $\rightarrow$  Activation of the ballast circuit at 93 % depending on DC-BUS max.
- $\rightarrow$  Deactivation of the ballast circuit control at 87 % depending on DC BUS max.
- With internal ballast resistor, the setting parameters are automatically set from the unit detection.
- For external ballast resistors, the values for the resistance (Ballast-R) and the resistance power (Ballast-P) are entered as parameters.

Regen	INT = Internal ballast resistor	Regen	INT EXT	1
	EXT = external ballast resistor	Pagao P	25	w
Regen-P	Enter the resistor power in W	Regen-r	20	Ohm
Regen-R	Enter the resistor value in Ohm	Kegen-K	00	

With an internal ballast resistor, the regen power is calculated from the data of the device type.

With external ballast resistor, the regen power is calculated from the entered values of **Regen-P** and **Regen-R**.

The regen power is displayed on the Monitor page as **Regen. energy**  $(0x45_L)$ .

In the oscilloscope, the DC BUS voltage (Vdc-Bus), the ballast switching pulse (I Regen and the regen power (Regen. energy) can be displayed.

At 87 % of the regen power, a warning is given (ballast circuit >87 % overloaded ( $0x8F_{Bit 31}$ )) and at 100 % the unit is switched off with an error message (ballast circuit overloaded ( $0x8F_{Bit 15}$ )).

The function of the ballast circuit is displayed on the servo.

With the 7-segment display, the setpoint direction bar (bottom left or right) is switched off as long as the ballast circuit is active.

### 8.6 **Settings – Monitoring motor temperature**

Parameter overview of the motor temperature monitoring.

Symbol:	Function:	Range:	Unit:	ID address:
I-red-TM	Triggering point current reduction based on the	032767	Num	0xA2
	motor temperature			
	$\rightarrow$ Warning 6			
M-Temp	Switch-off point based on motor temperature	032767	Num	0xA3
	Error 6			
	At motor temperature > 93 % of M-Temp			
	→ Warning 6 and current reduction			
T-motor	Current motor temperature	032000	Num	0x49

#### Note:

Due to the large number of different temperature sensors, the motor temperature (T-motor) is output as a purely numerical ADC value. The corresponding curves and thus the actual physical temperature must be determined via corresponding tables.

Deactivation of the monitoring takes place with the setting limit of 32767.

#### Current reduction (derating) based on the motor temperature:

If the motor temperature (T-motor) rises above the set value of I-red-TM,

- the maximum current limit is increased linearly from the application point of I-red-TM to the switch-off point of M-Temp reduced to continuous current
- the message Ird-TM (0x40Bit 26) is set in the status field
- warning 6 is set.

I-red-TM 5600 Num

#### Fault switch-off based on the motor temperature:

If the motor temperature (T-motor) rises above the set value of M-Temp,

- The inverter switches off the fault
- error 6 is output.

If the motor temperature (T-motor) rises above 87 % of the set value of M-Temp,

- the maximum current limit is reduced to continuous current
- the message Ird-TM (0x40Bit <sub>26</sub>) is set in the status field
- warning 6 is set.

N-Tellin /000	M-Temp	7000	Num
---------------	--------	------	-----



## 8.7 Settings – Power connection / DC bus monitoring

#### Note / Important:

The manual configuration of the DC link monitoring only works with servo units that have an analogue DC bus measurement.

This applies to all battery DC servo units (Bamobil, Bamocar) and special AC servo units (DPC).

	Mains Type	AC	DC	
	Mains Voltage	230		V
Parameter overview for the selection of the power connection and the setting of the monitoring of the DC	DC-Bus max	120		%
bus with analogue DC link measurement.	DC-Bus min	10		%

Symbol:	Function:	Range:	Unit:	ID address:
Mains Type	Power voltage selection	AC / DC		0x5A <sub>Bit 19</sub>
Mains Voltage	Size of the mains voltage	01000	V	0x64
DC-BUS max	Maximum voltage limit for the DC bus	0200	%	0xA5 <sub>H</sub>
	(software)			
DC-BUS min	Minimum voltage limit for the DC bus	0200	%	0xA5∟
	(software)			

#### Mains Type:

The selection of the power voltage between alternating voltage (AC) or direct voltage (DC) is hardware dependent and should only be carried out with precise knowledge of the servo type.



#### 8.7.1 DC bus monitoring with firmware $\geq$ 478

#### Mains Voltage:

The reference value used for the min/max DC bus monitoring depends on the actual internal DC bus voltage. Depending on the selection at **Mains Type**.

With a Mains Type of:

- [DC] → For Mains Voltage, specify the nominal DC voltage connected.
   (e.g.: Mains Voltage = 400 V → DC bus = 400 V)
- [AC] → For Mains Voltage, specify the connected nominal AC phase-to-phase voltage. The voltage value in the DC bus DC link is then greater by the factor root 2. (e.g.: Mains Voltage = 400 V → DC bus = 565 V)

#### **DC-Bus max:**

- Setting limit for the max. software voltage limit in percentage relation to the input at **Mains Voltage** and depending on the selection of **Mains Type**.
- If this limit is exceeded, an error shutdown occurs, the controller is blocked and error 8 is set.
- The hardware overvoltage monitoring depends on the servo type and works independently of the software setting.
- Setting value for the control of the ballast circuit (servo type dependent).

#### DC-Bus min:

- Setting limit for the min. software voltage limit in percentage relation to the input at **Mains Voltage** and depending on the selection of **Mains Type**.
- If this limit is undershot, an error shutdown occurs, the controller is blocked and error 5 is set.
- The hardware undervoltage monitoring depends on the servo type and works independently of the software setting.

Example 1: Mains Type = DC and Mains Voltage = 400 VDC-Bus max = 110 % = 440 VDC-Bus min = 10 % = 40 V

Example 2: Mains Type = AC and Mains Voltage = 400 VDC-Bus max = 110 % = 622 VDC-Bus min = 10 % = 62 V

#### Note / Important:

Resolution problems of the internal min. and max. calculations of the limits in the event of excessive deviations when input at Mains Voltage in relation to the actual nominal servo voltage.

I.e., for a servo with a nominal voltage of 700 V and an input of Mains Voltage = 10 V, no reliable calculation of the limits is guaranteed.



#### 8.7.2 DC bus monitoring with firmware < 478

#### Mains Voltage:

This setting value only refers to the voltage value for alternating voltage (AC) as power voltage. If DC is selected as the Mains Type, the entry at Mains Voltage has no effect.

#### **DC-Bus max:**

- Setting limit for the upper software voltage limit for inverters with analogue DC bus measurement.
- Entry of **100 % = 32767 Num** 
  - → Calculate 32767 Num / 2 = **16383 Num** and compare the value with that of the device voltage table.
- Setting value for the control of the ballast circuit (servo type dependent).
- Warning occurs at 1.5 times the nominal voltage.
- If this limit is exceeded, an error shutdown occurs, the controller is blocked and error 8 is set.
- The hardware overvoltage monitoring depends on the servo type and works independently of the software setting.

#### **DC-Bus min:**

- Setting limit for the minimum software voltage limit for inverters with analogue DC link measurement.
- Entry of 100 % = 32767 Num
   → Calculate 32767 Num / 2 = 16383 Num and compare the value with that of the device voltage table.
- If this limit is undershot, an error shutdown occurs, the controller is blocked and error 5 is set.
- The hardware undervoltage monitoring depends on the servo type and works independently of the software setting.

#### Note / Important:

- Refer to the hardware device description to determine the setting values of the limits (min, max).
- The setting values of the limits do **not refer to the voltage value in "Mains Voltage"** but to the servospecific nominal supply voltage.



#### Example: Bamocar 400-400 and Bamocar 700-400



#### Standardisation of the DC bus voltage:

Bamocar 400-400:	1V ≙ 55.12044	(Example: 400 V $\triangleq$ 22048 Num (0xEB))
Bamocar 700-400:	1V ≙ 31.58483	(Example: 700 V $\triangleq$ 22109 Num (0xEB))

#### Setting the DC-Bus max (0xA5<sub>H</sub>) and DC-Bus min (0xA5<sub>L</sub>) limits:

(The setting values of the limits do not refer to the voltage value in "Mains Voltage" but to the inverterspecific rated supply voltage).

#### Entry of **100 % = 32767 Num**

→ Calculate 32767 Num / 2 = **16363 Num**. Compare this value with the voltage curve.

Bamocar 400-400:	1 % = 163 Num $\approx$ 2,985 V
Bamocar 700-400:	1 % = 163 Num $\approx$ 5,208 V

Settings for BAMOCAR-PG-D3- 400/400			
DC-Bus max (0xA5 <sub>H</sub> )	for limit voltage	Num 0xEB	
148 %	440 V	24252	
134 %	400 V	22048	
DC-Bus min (0xA5∟)	for undervoltage		
107 %	320 V	17638	
90 %	270 V	14882	

Settings for BAMOCAR-PG-D3- 700/400				
DC-Bus max (0xA5 <sub>H</sub> )	for limit voltage	Num 0xEB		
144 %	750 V	23688		
134 %	700 V	22109		
DC-Bus min (0xA5∟)	for undervoltage			
115 %	600 V	18950		
96 %	500 V	15792		



### 8.8 Settings – Monitoring power stage temperature

Parameter overview for setting the current reduction based on the output stage temperature

Symbol:	Function:	Range:	Unit:	ID address:
l-red-TD	Current limit reduction starting point	032767	Num	0x58
l-red-TE	Current limit reduction end point	032767	Num	0x4C
T-igbt	Measured temperature value of the output stage	032767	Num	0x4A

#### Condition:

- Only for units with analogue recording of the power stage temperature
   I-red-TD 21000 Num
   the software monitoring can be programmed.
   I-red-TE 23000 Num
- Refer to the hardware device description for setting values.



#### l-red-TD:

- Setting value for the start point of the reduction of the current limit depending on the power stage temperature.
- The current limit is lowered linearly to the set end point of I-red-TE to the set continuous current limit as the power stage temperature rises.

#### I-red-TE:

- Setting value for the end point of the power stage temperature at which the current limit is limited to the set continuous current.
- At 85 % of the maximum power stage temperature, warning 7 (DEVICETEMP) is set.
- The maximum power stage temperature is 25200 Num (approx. 83 °C).
- If the power stage temperature (T-igbt) rises above the value of 25200, an error shutdown occurs from the inverter and error 7 (DEVICETEMP) is set.

The hardware power stage temperature monitoring works independently of the software setting.

- The following applies for the activation functionality of the derating via the power stage temperature
   I-red-TD < I-red-TE</li>
  - I-red-TD > 0

 $\rightarrow$  The activation of the functionality is displayed as Ird-TI (0x40<sub>Bit 23</sub>) in the status field.

→ If this current derating functionality is triggered, it is displayed as Ird-TIR (0x40Bit 24) in the status field.

#### Note:

If this derating functionality is activated based on the power stage temperature, the current limitation is deactivated based on the function of **T-peak** (0xF0).



## 8.9 Settings – Servo

Parameter overview on the Settings page in the main **Servo** area.

Servo			Comma	nd
Туре	DS 405		Mode	
S-Nr.	123456789	64206	Cutoff (d	ig.)
Axis Mains sel	Rrad AC	DC	Analogo	ut
Mains	230	v		
DC-Bus ma	ax 144	%		
DC-Bus mi	n 6	96	Analog	Ain 1
Regen	INT	EXT	Format	+Cmd
Regen-P	25	W	Offset	0
Regen-R	80	Ohm	Cutoff	100
			Scale	1.000
BTB Powe	mit	ohne	Filter	0.0
PWM freq	8 kHz	~	Mode	-10+1

Comman	nd				_
Mode	Dig	. Co	mmands	~	
Cutoff (dig.) 0					
Analog out Nactual V					~
Analog	Ain 1			Ain 2	_
Format	+Cmd		$\sim$	Off	$\sim$
Offset	0			0	
Cutoff	100			0	
Scale	1.000			1.000	
Filter	0.0			0.0	ms
Mode	-10+	10)	$\sim$	-10+10	$\sim$

Symbol:	Function:	Range:	Unit:	ID address:
Туре	Unit type (protected)	0255	Num	0x67 <sub>Bit70</sub>
S-Nr.	Serial unit no. (protected)	32 Bit - 1	Num	0x62
Axis	Axis designation (freely writable)	4 characters	ASCII	0xF8
Mains Type	Selection of the power voltage	AC / DC		0x5A <sub>Bit 19</sub>
Mains Voltage	Magnitude of the mains supply voltage	01000	V	0x64
DC-Bus max	Max. voltage limit of the DC Bus (software)	0200	%	0xA5 <sub>н</sub>
DC-Bus min	Min. voltage limit of the DC Bus (software)	0200	%	0xA5∟
Regen	Selection of regen resistor	INT / EXT		0x5A <sub>Bit 1</sub>
Regen-P	Power value of the external regen resistor	2510000	W	0x65∟
Regen-R	Resistance value of the external regen resistor	5100	Ohm	0x65 <sub>н</sub>
BTB Power	BTB message with or without bus circuit undervoltage monitoring	mit / ohne with / without		0x5A <sub>Bit 6</sub>
PWM freq	PWM pulse frequency	Selection field		0x5A <sub>Bit 2220</sub>
Mode	Type of the command value presetting for	Selection field		0x36 <sub>Bit 1312</sub>
(Command)	the speed and torque commands			
Cut-off (dig.)	Zero zone with digital command value presetting	032767	Num	0x1E
Analog out	Output analog voltage in relation to the assigned variable	Selection field		0xDC
Format	Selection of the function of the respective	Selection field		0x36 <sub>Bit 10</sub>
Offset	Offset compensation of the respective analog inputs	±32767	Num	0x2FL 0xD7L
Cutoff	Zero zone of the respective analog command value presettings	032767	Num	0x50 0x53
Scale	Scale factor of the respective analog inputs	±7.999	Num	0x2F <sub>H</sub> 0xD7 <sub>H</sub>
Filter	Filter of the respective analog inputs	0127.5	Num	0x60
Mode	Input level selection of the respective analog	Selection field		0x36 <sub>Bit 54</sub>
(Analog)	inputs			0x36 <sub>Bit 98</sub>



Additional overview of the servo nominal data

Symbol:	Function:
Туре	Controller type is displayed (changes only possible at the factory)
S-Nr.	Serial number is displayed (changes only possible at the factory)
Axis	Axis designation with 4 ASCII characters (This is entered by the user)
Mains Type	Power connection AC~/DC= is displayed.
	(Default setting is entered at the factory)
Mains Voltage	AC and three-phase voltage AC (30~ to 480 V~)
	Battery voltage or DC mains (12 V= to 560 V=)
DC-Bus max	Switching point DC link overvoltage
	Error OVERVOLTAGE (overvoltage >1.8xUN) 0x8F <sub>Bit 8</sub>
DC-Bus min	Switching point DC link undervoltage
	Error POWERVOLTAGE (power voltage missing) 0x8F <sub>Bit 5</sub>
Regen	Selection list ballast resistor (internal - external)
Regen-P	Enter power value for external ballast resistor Enter in watts. If the ballast resistor is
	overloaded, a warning message is displayed.
	Warning BALLAST (ballast circuit <87 %) 0x8F <sub>Bit 31</sub>
Regen-R	Enter resistance value for external ballast resistor Enter in Ohm.
	It is also important to observe the minimum value.
BTB Power	BTB message with or without DC link undervoltage:
	Selection <b>ohne (without)</b> (BTB without undervoltage monitoring) with the enable
	switched off and the power voltage switched off, the RUN/BTB message remains active.
	Selection <b>mit (with)</b> (BTB with undervoltage monitoring).
	When the enable is switched off and the power voltage is switched off, RUN/BTB is
	deactivated.



8 kHz

24 kHz

20 kHz

16 kHz

12 kHz

8 kHz i16

6 kHz i 12 4 kHz i 8

## 8.10 Settings – Servo / PWM clock frequency

Selection of the switching frequency of the output stage is made via the Parameter **PWM freq** ( $0x5A_{Bit 22..20}$ )

Selection (General): Clock frequency equal to calculation speed Values: 8, 12, 16 kHz

Current limit reduction depending on clock frequency:

28 kHz	100 %
12 kHz	85 %
16 kHz	70 %

Selection (Special): Clock frequency (kHz) with higher computing speed (Ix). Values: 2 kHz-I4, 4 kHz-I8, 8 kHz-I16

#### Process Changing the clock frequency:

- Enable RUN (FRG) must be deactivated
- Set frequency
- Save parameter set in Eprom level 0
- Read parameter set from Eprom level 0
- The changed frequency is adopted and the current limits are reduced

**Recommendation of the clock frequency depending on the maximum motor speed and number of poles:** For good FOC control, it is recommended to have at least 16 measuring points for each electrical angle. For a motor with 20 poles (10 pole pairs), this results in a maximum speed:

(16 kHz)	16000 Hz / 16 = 1000 Hz n_max = (60 * 1000 Hz) / 10 = 6000 rpm
(12 kHz)	12000 Hz / 16 = 750 Hz (= fnom_max) n_max = (60 * 750 Hz) / 10 = 4500 rpm
(8 kHz)	8000 Hz / 16 = 500 Hz (= fnom_max) n_max = (60 * 500 Hz) / 10 = 3000 rpm

(→ maximum rotating field frequency)
 (→ maximum recommended speed)

PWM freq

Command

Cutoff (dig.)

Analog out

Mode

## 8.11 Settings – Servo / Analogue output

Setting for the definition of the output of the analogue output voltage is done by selecting **Analog out** (0xDC) variable.

Output of the analogue output voltage:

- The output voltage ±10 V corresponds to ±100 % from the selected signal.
- Digital binary signals provide 0 or +10 V as output





## 8.12 Settings – Servo / Setpoint Command Mode

Overview of the setpoint command mode in the selection Parameter Mode at Command.

Symbol:	Function:	ID address:
		0x36 <sub>Bit1312</sub>
Dig. Commands	General setpoint command via digital communication input (CAN-BUS, RS232)	0 dec
Analogue Speed	Speed setpoint command via analogue voltage input	2 dec
	(AIN1 and AIN2)	
Analogue	Torque (Iq) setpoint command via analogue voltage input	3 dec
Torque	(AIN1 and AIN2)	
Digi+Ana Speed	Speed setpoint via digital communication input and analogue voltage	1 dec
	input. The sum of both inputs gives the setpoint	

#### Dig. Commands:

Digital position, speed or current (torque) setpoint input Setpoint specification via one of the digital communication interfaces (CAN; RS232). Switching between the different operating modes (position, speed,

current) directly after receiving the latest Setpoint command.

#### Analogue Speed:

Analogue speed setpoint

Input at terminal strip  $X1 \rightarrow$  Inputs Ain1 and Ain2

Maximum input voltage ±11 V corresponds to ±32767 Num

This value corresponds to 100 % of the set 16-bit resolution of the maximum physical speed defined at **N-100%** (0xC8).

#### Analogue Torque:

Analogue current setpoint (Iq) Input at terminal strip  $X1 \rightarrow$  inputs Ain1 and Ain2 Maximum input voltage ±11 V corresponds to ±32767 Num This value corresponds to 100 % of the servo peak current I max pk (0xC4).

#### **Digi+Ana Speed:**

Speed setpoint both via the digital communication interface (CAN; RS232) and via the Analogue Speed preset. The final setpoint specification is the sum of both specifications with an internal limitation of  $\pm 32767$ .

This value corresponds to 100 % of the set 16-bit resolution of the maximum physical speed defined at **N-100%** (0xC8).

#### Tips:

#### Reversal of direction of rotation for unipolar setpoint with direction signal:

On the Logic page, assign a digital input with **N cmd Reverse**. Activation either via a real logic level at the set input or via changing the activation condition (AL / AH) via the digital communication interfaces (CAN; RS232).

#### **Overwrite setpoint Speed to 0 rpm:**

Same as the direction of rotation reversal but assign a digital input with Speed Ramp 0.





## 8.13 Settings – Servo / Analogue inputs

Parameter overview for setting the analogue inputs Ain1 and Ain2

Symbol:	Function:	Range:	Unit:	ID address:
				Ain1 -
				Ain2 -
Format	Selection of the function of the respective	Selection field		0x36 <sub>Bit 10</sub>
	analogue inputs			0x36 <sub>Bit 32</sub>
Offset	Offset compensation of the respective	±32767	Num	0x2F∟
	analogue inputs			0xD7L
Cutoff	Zero zone of the respective analogue	032767	Num	0x50
	setpoints			0x53
Scale	Scaling factor of the respective analogue	±7.999	Num	0x2F <sub>H</sub>
	inputs			0xD7 <sub>H</sub>
Filter	Filter of the respective analogue inputs	0127.5	Num	0x60
Mode	Input level selection of the respective	Selection field		0x36 <sub>Bit 54</sub>
(Analog)	analogue inputs			0x36 <sub>Bit 98</sub>

#### Format:

The analogue inputs **Ain1** and **Ain2** are assigned to a function in the **Format** field.

Format: Ain1		ID address:
Off	Disabled	$0x36_{Bit 10} = 0$
+Cmd	Setpoint command normal	0x36 <sub>Bit 10</sub> = 1
-Cmd	Setpoint command inverted	0x36 <sub>Bit 10</sub> = 2
sq(Cmd)	Square reference setpoint command	0x36 <sub>Bit 10</sub> = 3
N limit	Speed limitation 0 100 % via Ain1	0x36 <sub>Bit 15</sub>
	(with digital setpoint input (position, speed)). This corresponds to 100 % of	
	the max. physical speed defined in <b>N-100%</b> (0xC8).	

Format: Ain2		ID address:
Off	Disabled	0x36 <sub>Bit 32</sub> = 0
+Cmd	Setpoint command normal (Ain2 is added to Ain1)	0x36 <sub>Bit 32</sub> = 1
-Cmd	Setpoint command invertet (Ain2 is subtracted from Ain1)	0x36 <sub>Bit 32</sub> = 2
*Cmd	Setpoint command normal (Ain2 is multiplied by Ain1)	0x36 <sub>Bit 32</sub> = 3
l limit	Current limitation 0100 % via Ain2	0x36 <sub>Bit 14</sub>
	(for all digital, analogue setpoints).	
	This corresponds to 100 % of the unit peak current <b>I max pk</b> (0xC4).	

Ain 1	Ain 2
+Cmd 🗸	Off 🗸 🗸
Off	0
+Cmd	100
-Cmd sa(Cmd)	1.000
Nlimit	0.0 ms
-10+10V $ \smallsetminus $	-10+10V $\sim$
	Ain 1 +Cmd Off +Cmd -Cmd sq(Cmd) N limit -10+10V V

- Analog -			
Analog	Ain 1		Ain 2
Format	+Cmd	$\sim$	Off 🗸 🗸
Offset	0		Off
Cutoff	100		+Cmd
Scale	1.000		-Cmd *Cmd
Filter	0.0		Himit
Mode	-10+10V	$\sim$	-10+10V $\sim$

# Settings



#### Offset:

Compensation of setpoint zero error with analogue input.

With 0 V voltage applied, change the offset value positively or negatively until the setpoint value input at **Ain scaled** displays the value zero.

#### Cutoff:

Adjustable zero zone where the unprocessed measured value of Ain1 and Ain2 is set to 0. Sets a setpoint value equal to 0, since there is usually always a small residual voltage of around 0 V at the inputs of Ain1 and Ain2.

#### Special cases:

Zero zone with analogue speed setpoint:

The setpoint is internally switched to 0 within this zone. The drive stands still, no drift (no position parameter entered).

If the external torque is greater than the servo current limit, the drive can be rotated from the zero position.

Zero zone for analogue speed setpoint with position hold value:

Within the zero zone, the drive is held at its zero position by means of internal position control. If the external torque is greater than the servo current limit (I max pk), the drive can be rotated out of the zero position. If the torque is smaller, the drive returns to its zero position.

Attention: The parameters must be entered in the Position parameter field.

With an analogue setpoint from a PLC/CNC position control, the value for the Zero zone be very small or 0.

#### Scale:

Scaling factor of the respective analogue input signals. This allows the entire width of the input voltages (±11 V) to be adjusted over the entire range of the final setpoint (±32767). This also allows the gradient of the setpoint to be varied. (Input voltages greater than 11 V are capped).

#### Mode:

Input range of the analogue setpoints with								
-10+10V	bipolar setpoint							
0+10V	unipolar setpoint							
420mA	current setpoint (external resistor 500 Ohm)							
+1+9V	Setpoint with potentiometer monitoring							



The setpoint specification of Ain1 and Ain2 after scaling is output in the variables  $Ain_{1,2}$  scaled as setpoint. This is displayed on the page Speed at **Ain<sub>1,2</sub> scaled**.

 $Ain_{1,2}$  scaled =  $(Ain_{1,2}in + Offset_{1,2})$  x Scale<sub>1,2</sub>



## 8.14 Settings – Speed / Linear ramp function and speed limitation

Parameter overview for setting the different ramp times for the speed, torque and emergency stop ramps.

Symbol:	Function:	Range:	Unit:	ID address:
N R-Acc	Speed - Acceleration ramp	030000	ms	0x35∟
N R-Dec	Speed - Brake ramp	030000	ms	0xED <sub>L</sub>
M R-Acc	Moment - Acceleration ramp <sup>1</sup>	04000	ms	0x35 <sub>н</sub>
M R-Dec	Moment - dismantling ramp <sup>1</sup>	04000	ms	0xED <sub>H</sub>
M R-Rcp	Moment - recuperation ramp <sup>1,2</sup>	04000	ms	0xC7 <sub>H</sub>
R-Lim	Emergency stop, limit switch ramp	01000	ms	0xC7L
N-100%	Physical reference value for the internal	10050000	rpm	0xC8
	resolution of the speed to 16 bits (±32767)			
N-Lim	Speed limitation for positive and negative	0100	%	0x34
	direction of rotation <sup>3</sup>			
N-Lim+	Speed limitation for positive direction of rotation	0100	%	0x3F
	(if logic input N clip(neg&pos) is activated)			
N-Lim-	Speed limitation for negative direction of	0100	%	0x3E
	rotation			
	(if logic input N clip(neg&pos) is activated)			
<sup>1</sup> From FW476 on <sup>2</sup> From FW476 on	ly active if it is a current (torque) specification.			

<sup>3</sup> Torque cruise control is activated at current (torque) setting and N-Lim < 100%.

- For speed ramps (N R-Acc, N R-Dec, R-Lim), the following applies as a reference for the time specification of the value for 100 % setpoint defined in parameter N-100% (0xC8).
- For moment ramps (M R-Acc, M R-Dec, M R-Rcp), the following applies as a reference forthe time specification the value for 100 % setpoint of the unit peak current in the parameter I max pk (0xC4).
- All ramps are formed linearly and, with a speed input, generate a constant acceleration.





# Settings

#### S-ramp function

#### Note:

Not yet active!



#### **S-ramps function**

The linear time function is converted into an S-shaped (sinus<sup>2</sup>) function. The constant acceleration and deceleration changes into a steady change. Jerks and current peaks are greatly reduced.



### 8.15 Settings – BTB / RDY

#### **BTB/RDY** message (relay contact)

The BTB contact (solid-state relay) is closed when the unit is ready for operation (residual resistance 30 Ohm); in the event of an error, the BTB contact is open (resistance > 1 M $\Omega$ ).

#### **BTB** ready for operation

Is displayed in the status field with Rdy (0x40Bit 14).

#### Not ready for operation /BTB (error)

Indicated on the front with the red FAULT LED.

#### BTB and power voltage

The signalling state when the power voltage is switched off can be selected on the **Settings** page in the **Servo** parameter field with **BTB-Power** (Undervoltage monitoring).

#### Selection BTB Power - "without (ohne)"

BTB without undervoltage monitoring. With the enable switched off and the power voltage, **the RUN/BTB message remains.** 

#### Selection BTB Power - "with (mit)"

BTB with undervoltage monitoring. With enable switched off and power voltage switched off **RUN/BTB drops out**.

#### Error message and BTB/RDY:

In the event of a system-dangerous error X (see error list), the

- **BTB** message switched off. The servo is locked internally without delay and the output **O\_GO** (0xE3) is set to low.
- On the servo: The FAULT LED lights up red. The 7-segment display shows the error number.
- In NDrive: The error states are displayed in the Error field.

#### The error messages are reset when:

- Switching on the controller enable RUN (FRG).
- Sending the command Parameter **Cancel Error** via a communication interface.
- Trigger a digital input that is programmed with **Cancel Error(s)** on the **Logic** page.







## 9 Communication (external) with servo

## 9.1 Communication (external) with servo – CAN bus

Parameter overview of the NDrive page **Bus** for the CAN bus communication interface.

Symbol:	Function:	Range:	Unit:	ID address:
NBT	CAN transmission rate (see list)	00xFFFE	hex	0x73 <sub>Bit 110</sub>
Rx ID	CAN ID - Receive address	00x7EE	hex	0x68
Tx ID	CAN ID - Transmit address	00x7EE	hex	0x69
T-Out	CAN timeout time	0 60000	ms	0xD0
Axis	Axis designation (freely writable)	4 characters	ASCII	0xF8

Transmission rate NBT:	Setting value in NBT (0x73):	Cable length max.:
1000 kBaud	0x4002	20 m
625 kBaud	0x4014	70 m
500 kBaud	0x4025 (default)	70 m
250 kBaud	0x405C	100 m
125 kBaud	0x4325	100 m
100 kBaud	0x4425	100 m

The station addresses for receiving and transmitting and the Transmission rate are set in the parameter field **CAN bus** entered.

After changes in the CAN programming and storage, the unit must be restarted  $\rightarrow$  Switch auxiliary voltage off and on!

#### **Default settings:**

Receive address	Rx ID = 0x201
Transmit address	Tx ID = 0x181
Transmission rate	NBT = 4025 (→ 500 kBaud)

### Note:

For a detailed explanation of CAN communication please download the CAN manual from the UniTek homepage.

⊂CAN-Bι	15			
NBT	4025	hex	500	kbps
Rx ID	201	hex		
Tx ID	181	hex		
T-Out			0	ms



### 9.2 Communication (external) with servo – RS232

#### 9.2.1 Change RS232 baud rate

The RS232 baud rate is set via the ID address 0x5A <sub>Bit 15</sub>								
0x5A <sub>Bit 15</sub>	0	corresponds to	115200	(default)				
0x5A <sub>Bit 15</sub>	1	corresponds to	9600					

The baud rate stored in the unit is set when the auxiliary voltage 24 V= is switched on, after the firmware version number, is displayed.

bd0	corresponds to	115200
bd1	corresponds to	9600

First the firmware version is displayed (e.g. 4 - 7 - 8) Then the baud rate (e.g. b - d - 0)

#### 9.2.2 Structure of the RS232 serial protocol

Representation of the structure / protocol of a message via the serial RS232 interface.

RS 232 16 bit										
Send	Send from PC to Drive							Answer Drive to PC		
Char1	Char2	Char3	Char4	Char5	Char6	Char7		Byte 1	Byte 2	
RegID	RegID	Data	Data	Data	Data	Sync		Data	Data	
Bits	Bit s	Bits	Bits	Bits	Bits	"X"		Bits	Bits	
0704	0300	1512	1108	0704	0300			0704	0704	
ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII		binary	binary	

RS 232 32 bit														
Send from PC to Drive								Answe	er Drive	to PC				
Char1	Char2	Char3	Char4	Char5	Char6	Char7	Char8	Char9	Char10	Char11	Byte1	Byte2	Byte 3	Byte4
RegID	RegID	Data	Sync.	Data	Data	Data	Data							
Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	Bits	"X"	Bits	Bits	Bits	Bits
0704	0300	3128	2724	2320	1916	1512	1208	0704	0300		0704	0704	0704	0704
ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	ASCII	binary	binary	binary	binary

#### **Example:** Request from Speed Actual (0x30)

Send from PC to Drive					Answer Drive to PC					
Char1	Char2	Char3	Char4	Char5	Char6	Char7		Byte 1	Byte 2	
RegID	RegID	Data	Data	Data	Data	Sync		Data	Data	
Bits	Bits	Bits	Bits	Bits	Bits	"X"		Bits	Bits	
0704	0300	1512	1108	0704	0300			0704	0704	
3	D	0	0	3	0	Х		lo	hi	
RegID r read (0:	RegID readSpeed Actualread (0x3D)Speed actual value (0x30)		ASCII		Value o	f 0x30				

## **10 Current control**

## **10.1 Current control – Parameter overview**

Parameter overview of the settings for the current controller, as well as the general permitted current limits from the servo unit and the limits for activating derating functions.

Note:

Many of these parameters can also be found on the pages **Speed** and **oscilloscope**.

Current -		
current		
Кр	20	
Ti	600	μs
TiM	100	%
хКр2	0	96
Kf	0	
Ramp	2000	us
l max pk	100	96
l max pk	10,6	A pk
l con eff	100	96
l con eff	5,0	A rms
T-peak	5	s
l lim dig	100	96
I-red-N	100	96
I-red-TD	21000	Num
I-red-TE	23000	Num
I-red-TM	5600	Num

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x1C
Ti	Reset time (integral time constant)	37510000	ms	0x1D
TiM	Maximum value from integral memory Ti	0300	%	0x2B
xKP2	Proportional gain in the case Is current	0, 100500	%	0xC9
	greater than current limit			
Kf	Current feed forward	0167	Num	0xCB
Ramp	Ramp setting set current	125132000	μs	0x25
I max pk	Devices Peak current [A]	0100	%	0xC4
l con eff	Devices Continuous current [Arms]	0100	%	0xC5
T-peak2	Permitted overcurrent time above continuous	1 40	S	0xF0
	current limit (degradation 5 times longer)			
I limit (dig) <sup>3</sup>	Current reduction when logic input	0 100	%	0x46
	I limit (dig.) is activated			
I-red-N	Current reduction via the actual speed	0 100	%	0x3C
I-red-TD	Start of current reduction via the output stage	0 32767	Num	0x58
	temperature			
I-red-TE	End of current reduction via the output stage	0 32767	Num	0x4C
	temperature			
l-red-TM	Start current reduction via the	0 32767	Num	0xA2
	Motor temperature			
<sup>1</sup> Dependent PWM c	lock frequency			

<sup>2</sup> Only active if current reduction based on the output stage temperature is not activated  $(0x40_{Bit 23} (Ird-TI) = 0)$ 

<sup>3</sup> Reference is maximum unit peak current (I max pk (0xC4) = 100 %)

н

Industrie Elektronik

m b

G



#### 10.1.1 Additional information on the parameters of the current controller

The current controller is a classic PI controller  $\rightarrow$  Kp \* (1 + 1/(Ti \* s))

Кр	Input for the proportion Note: Input value of 33	onal gain in the current controller 3 (Num) $ riangle$ 1.0 (Physical manipulated variable of voltage)				
	Kp too small: Kp too large: Recommended <sup>1</sup> :	Misalignment, poor dynamics, low-frequency oscillations Strong engine noise, high-frequency vibrations 1040 Num				
Ti	Integration reset time Note: Ti depending on	in the current controller the proportional gain Kp				
	Ti too large: Ti too small: Recommended <sup>1</sup> :	Low frequency vibrations High-frequency vibrations, strong tendency to oscillate 7002500 ms				
TiM	Maximum value from	integral memory Ti				
	TiM too small: Recommended <sup>1</sup> :	Speed target at higher load is not reached 80100 %				
xKp2	<ul> <li>New gain factor (i.e. new Kp) for damping the current-actual overshoot above current inuse (0x48)</li> <li>Note: Activate only if the system requires it</li> </ul>					
	xKp2 too large: Recommended <sup>1</sup> :	Danger of current oscillations 0 (Disabled) or 100120 %				
Kf	precontrol to compens Note: Activate only if t	sate for the response delay in the current controller he system requires it				
	Kf too large: Recommended <sup>1</sup> :	Danger of current oscillations 0 (Disabled) or 1050 %.				
Ramp	Current rise limitation	or ramp rise from the set current				
	Ramp too large: Recommended <sup>1</sup> :	Danger of long-wave speed oscillations (motor becomes unstable) 6002500 μs				
<sup>1</sup> Guide Differe	line values based on ma nces depending on the	any years of experience system are nevertheless possible				

The current control parameters can be determined by the motor data such as winding inductance and winding resistance.

#### Attention:

- The current controller parameters may only be changed by trained specialist personnel.
- Poorly set gain parameters can damage the unit or the drive. damage.
- Check the effect of all settings with the NDrive oscilloscope.





## 10.2 Current control – Structural diagram

The structural diagram of the current control with input and display window of the controller parameters is shown on the page **Speed** for numerical values under **Current Commands** and **Current Controller**.



Current setpoints:	Function:	ID address:
I fn(N)	Speed controller output (current setpoint from speed controller)	
I fn(M)	Torque setpoint after ramp	
	(Dig. setpoint preset from Iq current (M set(dig.))	
Id set (dig.)	Dig. setpoint input from Id current (normalised like M set(dig.))	0x21
lq cmd	Active current (Iq) Setpoint (internal)	0x26
lq cmd ramp	Active current (Iq) Setpoint (internal) after ramp and limitation	0x22
ld cmd	Reactive current (Id) Setpoint (internal)	0x23
Current controller		
values:		
lq actual	Current active current (Iq)	0x27
Id actual	Current reactive current (Id)	0x28
I actual	Actual current value	0x20
I act (filt)	Actual current value after display filter	0x5F
lq error	Control error active current (Iq)	0x38
Id error	Control error Reactive current (Id)	0x39
Voltage values:		
Vemf	Current Vemf voltage share (feed forward Back EMF)	0x29 <sub>н</sub>
Vq	Current Vq voltage share	0x29 <sub>L</sub>
Vd	Current Vd voltage share	0x2AL
Vout	Current output voltage	0x8AL
Vdc bus	Measured value of the DC link voltage	OxEB
PWM 1	PWM output level phase 1	0xAC
PWM 2	PWM output level phase 2	0xAD
PWM 3	PWM output level phase 3	0xAE
V-red	Field weakening control – voltage reference value in % of V out	0x8B
V-kp	Field weakening control – proport. amplific. in the voltage controller	0x8C
V-Ti	Field weakening control – integral time (integral time constant)	0x8D



Ramp setting field on the Speed page.

Symbol:	Function:	ID address:
Ramp	Ramp setting set current [µs]	0x25
I max pk	Devices Peak current [A]	0xC4
I con eff	Devices Continuous current [Arms]	0xC5
T-peak	Permitted overcurrent time above continuous current limit [s].	0xF0
I lim dig	Current reduction in % if logic input I limit (dig.) is activated	0x46
lxt	Load	0x45 <sub>H</sub>
I lim inuse	Current limit (internal)	0x48



The current setpoint (I cmd) is edited in the setting field (Ramp).

The current rise (Ramp), the peak current (I max pk), the continuous current (I con eff) and the permitted overcurrent time (T-peak) are set.

The summarised current reductions due to speed, current and temperature are displayed at I lim inuse. When the current is reduced, the I reduced LED lights up.

The result of the current setpoint processing is shown in the Current setpoint after ramp (I cmd ramp) display field.

#### Current controller setting field on the Speed page.

Symbol:	Function:	ID address:
Кр	Proportional Gain [Num]	0x1C
Ti	Integral time constant [µs]	0x1D
TiM	Maximum value of the integral memory Ti [%]	0x2B
Ке	Motor Ke Constant (Back EMF)	0x87 <sub>н</sub>

#### Field control setting field on the Speed page.

Symbol:	Function:	ID address:
Id nom	Nominal magnetising current in % of nominal motor	0xB2
	current [%].	
Id min	Minimum magentising current in % of rated motor	0xB5
	current [%].	
V-red	Field weakness control - Voltage Reference Value in	0x8B
	% of Vout [%]	
V-kp	Gain of the field weakening control [Num]	0x8C
V-Ti	Integral time of the field weakening control [Num]	0x8D



The actual current values (I-actual1, I-actual2, I-actual3) are evaluated as Iq-actual and Id-actual. The displayed actual current value I act (filt) is obtained from the actual current value (I actual) with a filter. In the current controller, the Iq and Id errors are processed with the amplification parameters (Kp, Ti, TiM). The reference value for the Id control is formed via the vector control feedback.



#### PWM display field on the Speed page

Symbol:	Function:	ID address:
Vemf	Current Vemf voltage share	0x29 <sub>H</sub>
	(feed forward Back EMF)	
Vq	Current Vq voltage share	0x29L
Vd	Current Vd voltage share	0x2AL
Vout	Current output voltage	0x8AL
Vdc bus	Measured value of the DC link	OxEB
	voltage	
PWM1	Pulse width modulation phase 1	0xAC
PWM2	Pulse width modulation phase 2	0xAD
PWM3	Pulse width modulation phase 3	0xAE



The PWM pulses for the output stage circuit are formed from the current controller output signals Vemf, Vq and Vd.

#### 10.2.1 Conversion of the units of measurement for electricity

The numerical values for the nominal current must be observed for digital communication via RS232 or CAN Bus.

The track field displays the numerical values.

$$i = RegID[0xNN] * \frac{1}{5} * \frac{RegID[0xC6]}{RegID[0xD9]} A_{rms}$$

Note:

- 0xD9 and 0xC6 are fixed defined device-dependent values.
- The physical values (if any) are displayed in A in the Ndrive oscilloscope.



#### 10.2.2 Setting current controller parameters (Kp ,Ti, TiM)

UNITE	K Settings	Speed	Position	Logic	Bus	Oscillos	cope Monitor	Device	Diagnost	ics Aut	o Extra	а					
Current Kp Ti XKp2 Kf Ramp I max pk I con eff T-peak FB-Offset I reduce I lim dig I-red-N I-red-TD I-red-TM	30 µ15 800 µ15 100 % 0 15 2000 US 100 % 5 5 5 -58.4 Deg 100 % 100 % 21000 Num 23000 Num 23000 Num	Speed Kp Ti Td TiM Kacc Filter N R-Acc N R-Det R-Lim M R-Acc M R-Det M R-Cp M R-Rcp N-1009 N-Lim N-Lim-	30 10 0 60 0 4 1 1 1000 10 1000 3600 10 100 -100	ms ms % % % % ms ms ms ms RPM %	<b>b</b>										~~~~	~~~	
	116					(t)	and the second		-1	24				and the second	22		
Step Ge	nerator		Trigger		Valu	e PM	Delta Value	Channel		Pos	U/Div			Options Inin	S	tatus	
Iorqu		tea.	Chan 1	~	2 359 P	PM		N cma (rar	np) 🗸	0	10000			Over		Pure EEC	ton
2 Step	20000	awal	Kise > Lev	~	3 1 38 /			la cond con	~	0	600	1		Zero	V		
Time 1	300	evel:	v		4 1 53 4	A		la chual		0	600	V /		Units	1		
Step 2	0	if I	Capture	10.00	5 10 59			i actual	~	0	600	V		Label	• D	X+Y	Y
Time 2	4000	10	2000		6 2000			March (d)	rmp 🗸	0	4000			AbsDelta	V )	€€	1
Step 3	D		Normal	~	7 100	-		wiset (dig.	, v	0	500			InvColour	_		
Time 3	1000	imescale	50ms	~	100			incr_delta	×	0	4000					File .uo	
Stop	►Start P	retrig	25%	~	Time	58.5ms	)elta -	Vout / Vxx	x v	1	4000		<b>U</b>		Ľ		

The setting of the current controller is strongly dependent on the characteristics of the overall system and especially on the characteristics of the used and mostly unknown motor.

Inverters are generally not plug and play systems. A special closer look at the behaviour during current control is crucial for safe and quiet operation.

#### Prerequisite:

- Handling the NDrive oscilloscope (signals "I cmd ramp" and "I actual" as measuring channel).
- The motor should either be freewheeling or at a constant load.
- Stable RS232 communication for setting a digital setpoint and recording with the NDrive oscilloscope.
- The current controller parameters may only be changed by qualified personnel.

#### Note:

The following setting from the current controller focuses on the general first jump from setpoint to actual value. At high speeds and near the voltage limit, corrections may have to be made.



#### Setting Kp value:

- Remove from integral part (TiM = 0 %)
- Fast speed ramps (N R-Acc = 10..100 ms)
- Set trigger in NDrive oscilloscope to channel 1 (N cmd (ramp)), Rise > Lev 100
- Start oscilloscope recording, send speed setpoint (e.g. 10000), stop motor, analyse oscilloscope recording.

#### Kp value too small

- Difference between current setpoint (I cmd (ramp)) and Current actual value (lactual) too high
- 2. Maximum torque is not reached at high speeds



#### Kp value too large

- 1. Current actual value oscillates above the current setpoint value
- 2. Rough running and high-frequency engine noise



#### Kp value good

- 1. Current actual value does not oscillate
- 2. Difference between current setpoint and current actual value is small

(Optimal: control error < 5 %)





#### Setting Ti and TiM value:

- Maintain determined KP value
- Adding the integral part (TiM  $\neq$  0 %, Ti  $\neq$  0  $\mu$ s)
- Fast speed ramps (N R-Acc = 10..100 ms)
- Set trigger in NDrive oscilloscope to channel 1 (N cmd (ramp)), Rise > Lev 100
- Start oscilloscope recording, send speed setpoint (e.g. 10000), stop motor, analyse oscilloscope recording.

#### TiM too small

- 1. The setpoint speed (green) is not reached at higher load despite sufficiently high setpoint current (red)
- 2. The control variable of the output voltage is missing
- 3. Recommendation: 80..100 %



#### Ti too big

- 1. Control error is hardly compensated or compensated too slowly
- 2. Long-wave swing possible

#### Ti too small

- 1. Large and fast overshoot at the first target jump
- 2. Short-wave oscillation possible

#### Note:

Since Ti depends on Kp, a subsequent adjustment of Kp affects the behaviour of the integral component.

#### Kp and Ti well adjusted

- 1. Fast control from the fast setpoint jump without large overshoot as well as fast correction in case of setpoint change
- 2. No short or long wave oscillation

#### Note:

- The system can become unstable during rapid load changes or in the range of the voltage limit
- Motor type and EMC influences have a strong effect on the control behaviour



## **11 Current reduction (Derating)**

### **11.1 Power reduction – Overview and explanation**

The current limits of peak and continuous current permitted during operation are determined by the set values of the motor and servo. The rule is that the lower value of the respective peak and continuous currents determines the limits during operation.

	Symbol:	Function:	Range:	Unit:	ID address:
Motor	I max eff	Motor maximum current	01000.0	Arms	0x4D
	I nom eff	Motor continuous current	01000.0	Arms	0x4E
Servo	I max pk	Devices Peak current [A]	0100	%	0xC4
	I con eff	Devices Continuous current [Arms]	0100	%	0xC5

#### **11.1.1** Power reduction – Overview

Parameter overview of the various adjustable derating options.

When reducing the current (derating) from the permitted peak current to the permitted continuous current, it is possible to choose between static (fixed value) or dynamic (function) current reduction electricity reduction can be distinguished.

T-peak	5	S
l lim dig	100	96
I-red-N	100	96
I-red-TD	21000	Num
I-red-TE	23000	Num
I-red-TM	5600	Num

Derating:	Symbol:	Function:	Range:	Unit:	ID address:
Time <sup>3</sup>	T-peak	Overcurrent time function	140	S	0xF0
Digital input <sup>1</sup>	I lim dig	Current reduction in % when Logic	0100	%	0x46
		input I limit (dig.) is activated			
Speed	I-red-N	Overcurrent speed function	032767	Num	0x3C
Actual value <sup>1</sup>					
Power stage	I-red-TD	Start of current reduction via the	032767	Num	0x58
temperature		output stage temperature			
(start) <sup>2</sup>					
Power stage	I-red-TE	End of current reduction via the	032767	Num	0x4C
temperature		output stage temperature			
(end) <sup>2</sup>					
Engine	I-red-TM	Reduction due to motor temperature	032767	Num	0xA2
temperature <sup>2</sup>					
Engine	M-Temp	Reduction from 93 % of M-Temp	032767	Num	0xA3
temperature <sup>2</sup>					
n < 10 Hz <sup>2</sup>		Reduction to continuous current if			
		motor speed is less than 10 Hz			
Analogue		Ain 2 is set to I limit. Ain 2 determines	032767	Num	0xD6 <sub>н</sub>
input <sup>1</sup>		allowed peak current			
<sup>1</sup> Static reduction					
<sup>3</sup> Static reduction wit	th dynamic calcu	lation			





Note: Names may vary slightly.

Elektronik

b

н

Industrie

m

G



#### **11.1.2** Current reduction – Explanation

In general, if the target current reaches the currently permitted current limit, this is indicated with the message in the status field  $0x40_{Bit 21}$  (**luse-rchd**).

#### T-peak:

If the current used is greater than the permitted continuous current, a calculation starts which carries out a time-based calculation depending on the delta of the excess. The calculation is therefore dynamic. If the dynamic time calculation corresponds to the set value of **T-peak** (0xF0), the current limit is reduced to continuous current. If the time calculation is at 87.5 % of T-peak,  $0x40_{Bit 28}$  (lwcns) is set in the status field. If the current is less than the permitted continuous current, the time memory is depleted again. The reset time is equal to 2 times T-peak.

**Note:** This current reduction based on time is only activated if current reduction based on power stage temperature is deactivated (I-red-TD = 0 or I-red-TD  $\ge$  T-red-TE).

 $\circ$  The activation of the function of T-peak is indicated via the status field 0x40<sub>Bit 23</sub> (Ird-TI) = 0.

#### I lim dig:

On the Logic page, a digital input can be programmed to I lim (dig).

If this input is activated or a CAN command is received for this input, the current limit is reduced to the value of the parameter I lim dig (0x46).

• Derating Active: Status field 0x40<sub>Bit 20</sub> (Ird-Dig)

#### I-red-N:

From the speed entered in parameter I-red-N (0x3C), the current limit is reduced linearly.

At nominal speed, the current limit corresponds to the continuous current.

• Derating Active: Status field 0x40<sub>Bit 22</sub> (Ird-N)

#### I-red-TD & I-red-TE:

If the output stage temperature exceeds the value of I-red-TD (0x58), the current limit is reduced linearly, the message in status field  $0x40_{Bit 24}$  is displayed and warning 7 (DEVICETEMP) is set.

If the value of I-red-TE (0x4C) is reached, the current limit is reduced to the permitted continuous current.

- $\circ~$  Activation condition: (I-red-TD < I-red-TE) and (I-red-TD > 0)
- $\circ~$  Function Active: Status field 0x40  $_{Bit\,23}$  (Ird-Ti)
- Derating Active: Status field 0x40<sub>Bit 24</sub> (Ird-TiR)

If the power stage temperature exceeds 25200 Num (83°C), an emergency shutdown occurs and error 7 (DEVICETEMP) is set.

#### I-red-TM:

If the motor temperature exceeds the value of **I-red-TM (**0xA2), the current limit is reduced linearly, the message in status field 0x40<sub>Bit 26</sub> (Ird-TM) and warning 6 (MOTORTEMP) is set.

If the temperature continues to rise, the current limit is reduced linearly until the value of **M-Temp** (0xA3) is reached. Then an emergency shutdown occurs and error 6 (MOTORTEMP) is set.

#### Attention:

The warning messages in the status must be taken into account. Reduced current limits can indicate functional faults in the machine or system.





#### **11.1.3** Current reduction – Status display

Signal:	Derating	Description of the signals:	ID address:
	function:		0x40
Icns		Current limit is reduced to continuous current	Bit 5
Ird-dig	Digital input	Current limit is reduced due to I lim dig	Bit 20
luse-rchd		Current setpoint is at the permitted current limit	Bit 21
Ird-N	Speed	Current limit is reduced because of I-red-N	Bit 22
	Actual value		
Ird-Ti	Power stage	Function of current reduction due to power stage	Bit 23
	temperature	temperature is activated ( $\rightarrow$ T-peak deactivated)	
Ird-TiR	Power stage	Current reduction due to power stage temperature is	Bit 24
	temperature	active	
Ird-10Hz	Speed	Current reduction with a rotating field frequency lower	Bit 25
	Actual value	than 10 Hz $\rightarrow$ Blocking protection <sup>1</sup>	
Ird-TM	Motor	Current limit is reduced because of I-red-TM or M-Temp	Bit 26
	temperature	(93 %)	
Ird-Ana	Analogue input	Current limit is reduced due to Ain2 (I limit) smaller than	Bit 27
		the actual current limit	
Iwcns	Time	The dynamic time limit is loaded to 87.5 % of T-peak	Bit 28

Overview of the signals in the status field (0x40) for the current reduction functions.

Measured values (monitor)		ID address:
T-motor	Current engine temperature	0x49
T-igbt	Current power stage temperature	0x4A
T-air	Current air temperature in the servo	0x4B
I lim inuse	Current limit (internal)	0x48

<sup>1</sup>Blocking protection:

With a rotating field frequency of less than 10 Hz, the current limit must be reduced to the permitted continuous servo current. This is important to protect the servo.

At your own risk, this blocking protection can be deactivated by automatically switching to a PWM clock frequency of 4 kHz below a rotating field frequency of 10 Hz:

- ID address 0x5A<sub>Bit 31</sub> = 0 Blocking protection activated (current limit is reduced)
- ID address 0x5A<sub>Bit 31</sub> = 1 Blocking protection deactivated (clock frequency switched to 4 kHz)

## **12 Speed control**

## 12.1 Speed control – Parameter overview

Parameter overview of the settings for the speed controller and the general permitted speed limits.

Note:

\_

\_

Many of these parameters can also be found on the pages **Speed** and **Oscilloscope**.



. . .

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x2C
Ті	Integration time (integral time constant)	010000	ms	0x2D
Td	Derivative time	0100	ms	0x2E
TiM	Maximum value from integral memory Ti	0100	%	0x3B
Касс	Proportional Gain - Delta Acceleration	0100	%	0x5B
Filter	Filter speed actual value	010	Num	0x5E
N R-Acc	Speed - Acceleration ramp	030000	ms	0x35∟
N R-Dec	Speed - Brake ramp	030000	ms	0xEDL
R-Lim	Emergency stop, limit switch ramp	01000	ms	0xC7L
		-		
M R-Acc	Moment - Acceleration ramp	04000	ms	0x35 <sub>н</sub>
M R-Dec	Moment - mining ramp	04000	ms	0xED <sub>H</sub>
M R-Rcp	Moment - Recuperation Ramp (0xCDBit 4)	04000	ms	0xC7 <sub>н</sub>
N-100%	Physical reference value for the internal	10050000	rpm	0xC8
	resolution of the speed to 16 bits (±32767)			
N-Lim	Speed limitation for positive and negative	0100	%	0x34
	direction of rotation			
N-Lim+	Limitation for positive direction of rotation (if	0100	%	0x3F
	logic input N clip(neg&pos) is activated)			
N-Lim-	Limitation for negative direction of rotation (if	0100	%	0x3E
	logic input N clip(neg&pos) is activated)			



## Speed control



#### 12.1.1 Additional information of the parameters from the speed controller

Kp too small:	correction error, poor dynamics, low-frequency oscillations
Kp too large:	Strong engine noise, high-frequency vibrations
Recommended <sup>1</sup> :	550 Num

**Ti** Integration time in the speed controller Note: Ti depending on the proportional gain Kp

Ti too large:	Low-frequency vibrations, large speed overshoots, very weak
Ti too small:	High-frequency vibrations, strong tendency to oscillate
Recommended <sup>1</sup> :	6400 ms

**TiM** Maximum value from integral memory Ti

TiM too small:	Speed target at higher load is not reached
Recommended <sup>1</sup> :	2060 %

**Td** Differential time constant in the rotary speed controller Note: Activate only if the system requires it.

Td too large:	high-frequency vibrations, strong tendency to vibrate
Recommended <sup>1</sup> :	0 (Disabled) or 620 ms

**Kacc** Dynamic acceleration value directly to the current controller Note: Activate only if the system requires it.

Kacc too large:Danger of current oscillationsRecommended1:0 (Disabled) or 10..50 %

**Filter** Filter for the actual speed value ( $0 \triangleq$  without filter, 10 is the maximum filter effect)

Filter too small:	motor noise, high-frequency vibrations, strong tendency to vibrate
Filter too large:	low-frequency oscillations

<sup>1</sup>Guideline values based on many years of experience. Differences depending on the system are nevertheless possible.



#### **12.1.2** Additional information of the speed setpoint ramps in speed controller mode

The speed setpoint in N cmd (int) (0x5D) is adjusted according to the ramp settings and sets the final speed setpoint in N cmd (ramp) (0x32) to the speed controller.

N R-Acc	Acceleration ramp for speed and position setpoint Parameter value always corresponds to the time from 0 rpm to the reference of N-100%.
N R-Dec	Brake ramp for speed and position setpoint Parameter value always corresponds to the time from 0 rpm to the reference of N-100%. (set to < 10 ms for position control)
R-Lim	Minimum braking ramp for limit switch and emergency stop With speed control only active if free run-out is deactivated (can be selected for calibration run)
M R-Acc	
M R-Dec	
M R-Rcp	These settings of the current ramps are not active during speed control.
	They are only active during gate control.
	For speed control, only the current ramp calculation using the parameter
	Ramp (0x25) active.

#### **12.1.3** Additional information of the speed setpoint limitation in speed controller mode

N-100%	Physical reference value for the internal resolution of the speed to 16 bits (±32767). Always set this value to Maximum engine speed. If the speed is to be limited to a smaller value, please use the parameter N-Lim (0x34).
N-Lim	Speed limitation in % for positive and negative direction of rotation depending on the reference value in N-100% (0xC8) .
	With a current setting (torque control) and N-Lim < 100 %, the torque cruise control (speed limitation) is activated.
N-Lim+	Speed limitation in % for positive direction of rotation depending on reference value in N-100% (0xC8)
	$\rightarrow$ Active only if a logic input is set to N clip(neg&pos) and activated.
	Special function: Current limit for automatic recuperation with torque control
N-Lim-	Speed limitation in % for negative direction of rotation depending on reference value in N-100% (0xC8)
	$\rightarrow$ Active only if a logic input is set to N clip(neg&pos) and activated.
	Special function: Current limit for automatic recuperation with torque control


# 12.2 Speed control – Structural diagram

The structural diagram of the speed control with input and display window of the controller parameters is shown on the page **Speed** for numerical values under **Analog**, **Speed** and **Speed** Controller.



Speed and active current (Iq) setpoints:		Function:	ID address:
Ain a IN1 / IN2		Analogue input 1 and 2	$0xD5_{L} / 0xD6_{L}$
Offset	IN1 / IN2	Offset compensation of the respective analogue inputs	$0x2F_L/0xD7_L$
Zero zone	IN1 / IN2	Zero zone with analogue setpoint setting	0x50 / 0x53
Scale	IN1 / IN2	Scaling factor of the respective analogue inputs	0x2F <sub>H</sub> / 0xD7 <sub>H</sub>
Ain scaled	IN1 / IN2	Analogue setpoint setting of inputs Ain1 and Ain2	0xD5 <sub>H</sub> / 0xD6 <sub>H</sub>
N set (dig.)		Digital setpoint setting of the speed	0x31
M set (dig.)		Digital setpoint setting from active current (Iq)	0x90
Cutoff (dig.)		Zero zone with digital setpoint setting	0x1E
Speed contr	oller values:		
N cmd (int)		Speed setpoint used (internal)	0x5D
N cmd (ramp	<b>)</b> )	Speed setpoint after ramp	0x32
N actual		Speed actual value signal for the control	0x30
N act (filt)		Actual speed signal for the display	0xA8
N error		Control error speed actual value	0x33
M cmd ramp	mp Active current (Iq) setpoint after ramp (scaled)		0x3AL



Analogue setting field on the Speed page.

Symbol:	Function:	Input1 (Ain1)	Input2 (Ain2)
Ain in	Analogue input 1 and 2	0xD5∟	0xD6L
Offset	Offset compensation of the respective	0x2F <sub>L</sub>	0x2F∟
Cutoff	Zero zone with analogue setpoint setting	0x50	0x53
Scale	Scaling factor of the respective analogue inputs	0x2F <sub>н</sub>	0xD7 <sub>H</sub>
Ain scaled	Analogue setpoint setting of inputs Ain1 and Ain2 (Ain scaled = (Ain in + Offset) x Scale)	0xD5 <sub>H</sub>	0xD6 <sub>H</sub>

	Ana Inout1	log
Ain in	4	-64
Offset	0	0
Cutoff	100	0
Scale	1.000	1.000
Ain scaled	0	-36

With **Ain in<sub>1,2</sub>** the measured analogue input values of Input1 and Input2 are displayed.

These signals are processed with the parameters Offset<sub>1,2</sub>, Cutoff<sub>1,2</sub> and Scale<sub>1,2</sub>. The result is displayed in Ain scaled<sub>1,2</sub>.

The selector switches are used to choose between analogue and digital setpoint. If both switches are closed, the digital and analogue setpoints are added together. The sum value for N cmd (int) is internally limited to ±32767.

The digital setpoints can be specified as digital Speed (N set (dig.)), digital Torque (M set (dig.)) or by the position controller directly via N fn(intern).

Signals:	Function green:		
Ena	Approval hardware / software		
GO	Internal release (output stage)		
Lim-	Limit switch minus		
Lim+	Limit switch plus		
NcRO	Setpoint zero		
Brk	Brake		



R-Dec

N-Lim+

### Ramp setting field on the RPM page.

030000	ms	0x35∟	N
030000	ms	0xED <sub>L</sub>	R-
01000	ms	0xC7∟	N
	030000 030000 01000	030000 ms 030000 ms 01000 ms	030000         ms         0x35⊥           030000         ms         0xED⊥           01000         ms         0xC7⊥

### Setpoint limits setting field on the Speed page.

Symbol:	Function:	Range:	Unit:	ID address:
N-Lim	Speed limitation for positive and	0100	%	0x34
	negative direction of rotation			
N-Lim+	Limitation for positive direction of	0100	%	0x3F
	rotation (if logic input			
	N clip(neg&pos) is activated)			
N-Lim-	Limitation for negative direction of	0100	%	0x3E
	rotation (if logic input			
	N clip(neg&pos) is activated)			



300

300

1000

35



### Control panel 1:

The speed setpoint is only switched on (green) with enable (Ena) and internal enable (GO) and displayed in the speed setpoint display field (N cmd (int)).

### Control panel 2:

If the enable (Ena), the limit switches (Lim-, Lim+), not speed = 0 and not brake (Brk) are switched (green), the speed setpoint (N cmd (int)) is processed in the ramp field.

### Ramp field:

The acceleration ramp (N R-Acc), the deceleration ramp (N R-Dec), the limit switch emergency stop ramp (R-Lim) and the speed limitation (N-Lim, N-Lim+, N-Lim-) are set. The result is shown in the speed setpoint after ramp (N cmd (ramp)) display field.

This processed signal (N cmd (ramp)) is finally the input for the speed controller.

### Speed controller parameters

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x2C
Ti	Integration time (integral time constant)	010000	ms	0x2D
Td	Derivative time (differentiation part)	0100	ms	0x2E
TiM	Maximum value from integral memory Ti	0100	%	0x3B

The filtered actual speed value (N act (filt)) is displayed after the filter in the field actual speed value (N actual) is displayed.

The actual speed value is subtracted from the speed setpoint at the mixing point. The result is shown in the speed error (N error) display field.

The speed error is processed in the speed controller (PID amplifier).

The proportional gain (Kp), the integral component (Ti), the differential component (Td) and the memory limitation for the speed controller are set.

The output from the speed controller is the unprocessed current setpoint (I fn(N)).





### 12.2.1 Speed controller parameter setting (Kp ,Ti, TiM)



The setting of the speed controller is mainly dependent on:

- the properties of the overall system (load, friction and inertia torques of the drive)
- depends on the power of the inverter and motor used (motor and inverter must be correctly rated for the overall system)
- the required control behaviour of the speed (smooth, aggressive, transient behaviour)

### **Prerequisite:**

- Handling the NDrive oscilloscope (signals "N cmd (ramp)" and "N actual" as measuring channel).
- The motor should either be freewheeling or at a constant load.
- Have a stable RS232 communication to set a digital setpoint and record with the NDrive oscilloscope.

### Note:

The following setting of the speed controller concentrates on generally static overall systems. For dynamic systems, adjustments may have to be made subsequently.



### Setting Kp value:

- Remove from integral part (TiM = 0 %).
- Set desired speed ramp (N R-Acc = 10..10000 ms).
- Set trigger in NDrive oscilloscope to channel 1 (N cmd (ramp)), Rise > Lev 100.
- Start oscilloscope recording, specify speed setpoint (e.g. 1000) (test or step generator), deactivate inverter (RUN (FRG) = Off), analyse oscilloscope recording.

### Kp value too small

- 1. Difference between speed setpoint (N cmd (ramp)) and Actual speed value (N actual) too high.
- 2. The speed setpoint is not reached and the acceleration is too low.
- 3. The drive reacts softly to setpoint changes and can be turned without much force when at standstill.



### Kp value too large

- 1. Actual speed value oscillates strongly above the speed setpoint value.
- 2. Rough running, high tendency to vibrate (even when stationary) and engine noise.



### Kp value good

- 1. Speed actual value does not oscillate.
- 2. Difference between speed setpoint and actual speed is small (optimum: control error < 5 %).

The remaining speed error is compensated with the integral setting.



### Setting Ti and TiM value:

- Maintain determined KP value.
- Adding the integral part (TiM  $\neq$  0 %, Ti  $\neq$  0  $\mu$ s).
- Set desired speed ramp (N R-Acc = 10..10000 ms).
- Set trigger in NDrive oscilloscope to channel 1 (N cmd (ramp)), Rise > Lev 100.
- Start oscilloscope recording, specify speed setpoint (e.g. 1000) (test or step generator), deactivate inverter (RUN (FRG) = Off), analyse oscilloscope recording.

### Ti too big

- 1. Rule error is hardly compensated or compensated too slowly.
- 2. Long-wave swing possible.



### Ti too small

- 1. Large and fast overshoot at the first target jump.
- 2. Short-wave oscillation possible.

#### Note:

3. Since Ti depends on Kp, a subsequent adjustment of Kp affects the behaviour of the integral component.





- 1. Fast control from the fast setpoint jump without large overshoot as well as fast correction in case of setpoint change.
- 2. No short or long wave oscillation.

Note:

- The system can become unstable in the event of rapid load changes or in the range of the voltage limit.
- Set the **TiM** parameter to minimum to reduce the overshoot. Select TiM value as small as possible.





# **13 Torque control**

# 13.1 Torque control – Parameter overview

Parameter overview for setting the general current specifications, the various ramp times for the speed and torque ramps and the various limitations.

Symbol:	Function:	Range:	Unit:	ID address:		
M set (dig.)	Digital setpoint for the active current (Iq)	±32767	Num	0x90		
	→ Dig. torque setpoint					
	(Normalisation: $32767 \triangleq I \max pk (at 100 \%)$ )					
Id set (dig.)	Digital setpoint for the reactive current (Id)	±32767	Num	0x21		
	(Normalisation: $32767 \triangleq I \max pk (at 100 \%))$					
N R-Acc	Speed - Acceleration ramp	030000	ms	0x35∟		
N R-Dec	Speed - Brake ramp	030000	ms	0xEDL		
M R-Acc	Moment - Acceleration ramp <sup>1</sup>	04000	ms	0x35 <sub>н</sub>		
M R-Dec	Moment - dismantling ramp <sup>1</sup>	04000	ms	0xED <sub>H</sub>		
M R-Rcp	Moment - recuperation ramp <sup>1,2</sup>	04000	ms	0xC7 <sub>н</sub>		
N-100%	Physical reference value for the internal	10050000	rpm	0xC8		
	resolution of the speed to 16 bits (±32767)					
N-Lim	Positive and negative speed limitation	0100	%	0x34		
	N-Lim = 100 % $\rightarrow$ Pure torque operation <sup>4</sup>					
	N-Lim < 100 % $\rightarrow$ Torque cruise control active					
N-Lim+	Current limit for recuperating braking current	0100	%	0x3F		
	(see automatic recuperation function)					
N-Lim-	Current limit for recuperating braking current	0100	%	0x3E		
	(see automatic recuperation function)					
M out	Iq current $\rightarrow$ torque actual value	±32767	Num	0xA0		
	(Normalisation: $32767 \triangleq I \max pk$ (at 100 %))					
<sup>1</sup> From FW476						
<sup>3</sup> Torque cruise co	ntrol is activated with current (torque) setting and N-Lim < 100%.					
<sup>4</sup> Speed is limited	only based on the load and the DC link voltage					



## 13.2 Torque control – General

- A torque control is actually a current setpoint specification. The motor torque is formed from the motor constant of kt = Nm / 1 Arms, which is generally unknown.
- The current setpoint can either be analogue via the analogue torque mode or as a digital setpoint via M set (dig.) (0x90). Both specify the active current (Iq).
- The reference for the current setpoint range always refers to 100 % of the possible servo current ((±10 V or ±32767) ≙ I max pk (100 %)).
- The current setpoint specification is switched directly to the current controller via the torque ramps (M R-Acc, M R-Dec, M R-Rcp)

### Note:

In the case of digital setpoint input, the last input received decides whether it is a speed control (N set (dig.)) or a torque control (M set(dig.)). It is therefore possible to switch directly between the different operating modes (e.g.: Hill Hold).

A detailed description of the various torque control settings as well as the various special functions such as automatic recuperative braking, can be found in the additional manuals (NDrive folder \ manuals) "Bamocar\_FAQ.pdf" and "Information on special Car applications.pdf".

### 13.3 Torque control – Torque cruise control

Torque cruise control is an operating mode in which a current setpoint is set as a default, but the higherlevel speed controller is still actively working and reduces the current setpoint in order not to exceed the speed limit. Torque cruise control is thus comparable to a limiter in a vehicle.

### N-Lim = 100 % (torque cruise control deactivated):

- Pure torque (current) operation without intervention of the speed controller.
  - $\rightarrow$  No limit active
  - $\rightarrow$  No limiting based on the speed ramps active
- Speed is limited only based on the applied load and the DC link voltage.
  - $\rightarrow$  Risk that the actual speed is greater than the 16-bit resolution of N-100% (0xC8).
- No need to set the parameters of the speed controller.

### N-Lim < 100 % (torque cruise control activated):

- Torque (current) operation with intervention of the speed controller based on the maximum permitted speed.
- The speed ramp setting (N R-Acc, N R-Dec) is always active and ensures torque operation with defined acceleration.
  - $\rightarrow$  Precise consideration of the large number of different ramp options required.
- Setting the parameters of the speed controller necessary

### **Recommendation:**

- Activation of torque cruise control (N-Lim = 99 %) always with torque control. Reason: Prevents loss of control in the event of sudden load changes and prevents the motor from running away.
- Set the speed controller soft (Kp = 5, Ti = 400), then the current control remains smoother.
- Fast speed ramps (N R-Acc = N R-Dec = 10 ms) so that intervention remains minimal.



# **14 Position control**

### 14.1 Position control – Parameter overview

Parameter overview of the settings for the position controller.

Note:

Many of these parameters and others can also be found on the **Position** and **Oscilloscope** pages.



Position controller Parameter:

Symbol:	Function: Range: Unit: ID add					
Кр	Proportional gain	0200	Num	0x6A		
	Determines the steepness of the deceleration					
	ramp					
Ti	Integration time (depending on Kp)	010000	ms	0x6B		
Td	Derivative time (differential share)	01000	ms	0x6C		
TiM	Maximum value from integral memory Ti0100%0x71					
The amplified position error forms the speed setpoint						
Position control is deactivated when Kp = 0						
The dynam	ic control gains Ti are only effective in the target range	2				

### Calibration run Parameter:

Symbol:	Function:	Range:	Unit:	ID address:
Speed 1	Speed to limit switch	032000	Num	0x76∟
	The limit switch is overrun depending on the speed			
Speed 2	Reverse speed back to zero pulse	02000	Num	0x77 <sub>L</sub>
	(loop speed)			
Reso Edge	Expected switching edge	065536	Num	0x75
Ref Ramp	Selection of the ramp during homing between N R-	DEC / LIM		0x5A <sub>Bit 5</sub>
Acc and R-Lim				
The calibration run is used to determine the zero point of the incremental measuring system				



### Position parameters:

Symbol:	Function:	Range:	Unit:	ID address:	
Tol-wind	Position tolerance window	02000	Num	0x79	
Off. Ref.	Mechanical zero offset		Num	0x72	
ND-Scale	NDrive position display factor	32 Bit - 1	Num	0x7C	
ND-Offset	NDrive Position display offset	Num	0x7D		
Pos dest	Preset target position	±32 Bit - 1	Num	0x6E	
Pos cmd	Target position used (internal)	±32 Bit - 1	Num	0x91	
Pos current	Actual position value	±32 Bit - 1	Num	0x6D	
Pos error	error Position control error value ±32 Bit - 1 Num 0x70				
$32 \text{ Bit} - 1 \rightarrow 2^{32} - 1$ $\pm 32 \text{ Bit} - 1 \rightarrow \pm 2^{32}$	32 Bit - $1 \rightarrow 2^{32}$ - $1 = 4.294.967.295$ +32 Bit - $1 \rightarrow \pm 2^{32-1}$ - $1 = \pm 2.147.483.647$				

### Note:

- One motor revolution corresponds to the numerical value of 65536.
- The position setpoints or parameter values sent by the controller via RS232 or CAN are executed immediately.



## 14.2 Position control – Structural diagram

The structural diagram of the position control with input and display window of the controller parameters is shown on the **Position** page for numerical values under Position **Controller**.



The actual position value (Pos actual) is subtracted from the target position value (Pos dest) at the mixing point. If the result is smaller than the set tolerance value (Tol-wind), the status signal reports this at the tolerance window. When released, the position target value (Pos dest) is switched on as the position setpoint (Pos cmd). The actual position value (Pos current) is subtracted from the position setpoint (Pos cmd) at the mixing point.

The result is shown in the speed error (N error) display field. If the messages of the releases (Ena, GO), the limit switches (Lim-, Lim+), and the position controller amplification are not zero (PosKp > 0) are switched (green), the position error (Pos error) is indicated in the position controller. (Pos  $\rightarrow$  Speed).

The proportional amplification (Kp), the integral component (Ti), the differentiating component (Td) and the memory limitation for the integral component (TiM) are set for both amplifiers.

The output of the position controller is the speed setpoint as the internal function (N fn(internal)).





### 14.2.1 Position controller – Settings

The amplified position error forms the speed setpoint

	Proportional control gain			nal control gain	
- Position		Кр	Proportional gain position control loop.		
Кр	5			Determines the steepness of the deceleration ramp.	
Ti	150	ms	Attention:		
Td	0	ms	The position control is switched off when no Kp value is entered		
TiM	80	%			
			Dynamic control gain		
			(only effec	tive in the target area)	
			Ті	Integral time	
			Тd	Differential time	
			TIM Limit integral part		
			P R-dec Position target ramp time:		
				Delay time from maximum speed in ms.	

Depiction of travel		9	Setting - travel		
		ſ	N R-Acc	Determines the acceleration ramp up to the speed	
				limit for constant travel.	
<i>a</i> <u>-</u>		ſ	N-Lim	Determines the speed at constant speed.	
		ŀ	Кр	Determines the target ramp depending on the	
				position control error.	
		F	P R-dec	Displays the delay time from 100 % speed to the	
				position (zero speed).	
T			<ul> <li>Small Kp</li> </ul>	gain leads to a long target ramp.	
			High Kp	gain creates a short (steep) target ramp.	
	$  \setminus  $		<ul> <li>If the Kp</li> </ul>	gain is too high, the drive overruns the target	
		1	position	and oscillates in position.	
1			The optimal target ramp is as long as possible and as short		
			as neces	sary.	



### Addition - Positioning

Tol-wind	Position tolerance window (numerical value)		
	If <b>Pos-actual &lt; Tol-wind</b> , the output <b>O Toler</b> is set		
	to 1 and displayed in the status <b>Tol</b> .		
Note: • One mot of 65555 • The posi CAN are	tor revolution corresponds to the numerical value 5. tion setpoints or parameters received via RS232 or executed immediately.		



### 14.2.2 Position controller – Additional information Settings

### Acceleration:

N R-Acc	Acceleration time tb to maximum speed in ms
	Acceleration a=V/tb

#### Constant drive:

N-Lim	Speed limit below the maximum speed
	Maximum speed is 100 % (32767 Num)

### Delay:

N R-Dec Set <10	) ms for	position	control
-----------------	----------	----------	---------

**Kp** The slope of the deceleration results from the proportional amplification

#### Delay time:

T-Ramp (tv) from maximum speed (32767 Num) to zero is displayed in ms on the Position page

Example of delay:

v = maximum speed in m/s, tv = deceleration time (T Ramp) in s v = 3 m/s, tv = 0.261 s

Deceleration a in m/s<sup>2</sup>:

 $a = \frac{v}{tv}$   $\rightarrow$   $a = \frac{3}{0,261} \frac{m}{s^2} = 11,5 \frac{m}{s^2}$ 

Gain Kp from given speed and deceleration:

$$Kp = \sqrt{\frac{a*2603}{v}} \rightarrow Kp = \sqrt{\frac{11,5*2603}{3}} \% = 99,9 \%$$

Ramp target distance:

$$s = \frac{v^2}{s*a}$$
  $\rightarrow$   $s = \frac{3^2}{2*11,5} m = 0,391 m$ 



#### 14.2.3 Position control – Conversion of the units of measurement for position

Range Pos-actual value:	Resolver:	Incremental encoder:
Pulses/rpm	65536 per rpm	65536 per rpm
Maximum value ±2147483647		
(31Bit-1)		
Resolution (smallest value)	16 (65536/4096 (12 Bit))	65536/Inc x 4
Example:		Incremental encoder: 2048 Imp/rpm
Spindle drive with slope:	Travel path:	Travel path:
5 mm/rpm	1000 mm = 200 rpm	1000 mm = 200 rpm
	→ 200 rpm = 13107200	→ 200Upm = 1638400
	Resolution: 65536/4096 = 16	Resolution: 65536/8192 = 8

#### 14.2.4 Position control – Scaling position

#### Display factor scale position values for NDrive display

The parameter ND-Scale (0x7C, Pos display factor) sets the display of the values for Pos dest, Pos cmd and Pos current on the Position page. With value zero, the display corresponds to the numerical value (1 motor revolution is equal to 65536 Num).

#### Adjust the display to the feed value

Calculate the conversion factor from the feed path to one motor revolution. For the display, this value must be multiplied by the constant 65536.000 ( $\triangleq$  1.000 mm / rev).

#### Example 1: distance in mm

Display value in mm at Pos dest, Pos cmd and Pos aktuell Spindle slope = 5 mm Gear ratio i = 20

Conversion factor for one revolution 1/5 \* 20 = 4Pos display factor 65536.000 \* 4 = 262144.000 ND-Scale is equal to 262144.000

#### Example 2: angle in degrees

Display value in degrees for Pos dest, Pos cmd and Pos actual Gear ratio 1 degree equals 10 motor revolutions

Conversion factor for one revolution = 10 Pos display factor 65536.000 \* 10 = 655360.000 ND-Scale is equal to 655360.000





### 14.3 Position control – Calibration run

### 14.3.1 Position control – Calibration run structural image

The structural image of the Calibration run for position control with input and display window of the controller parameters is shown on the **Position** for numerical values page under **Calibration run**.

The calibration run is used to determine the zero point of the incremental measurement system.



Symbol:	Function:	Range:	Unit:	ID address:
Speed 1	Speed to limit switch	032000	Num	0x76∟
	The limit switch is overrun depending on the speed.			
Speed 2	Reverse speed back to zero pulse	02000	Num	0x77 <sub>L</sub>
	(loop speed)			
Reso Edge	Expected switching edge	065536	Num	0x75
N R-Dec	Speed – Brake ramp	030000	ms	0xED <sub>L</sub>
R-Lim	Emergency stop, limit switch ramp	01000	ms	0xC7L

The reference switches are selected in the Digital Inputs parameter field. After switching on the machine and enabling RUN (FRG), the calibration run (**Start Ref Drive**) is triggered by a digital input (Din1, Din2) or by the interface (CAN-BUS, RS232 via ID address  $0x78 \neq 0$ ).

### Attention:

Move commands such as Start Ref Drive, N cmd (int) and others are only recognised 5 ms after release. First close or send the release and then send the move commands.



### **Calibration run**

The drive travels to the limit switch at speed Speed 1, passes over it at loop speed Speed 2 and returns. With a reference switch, the drive travels in positive direction with a loop, in negative direction with a double loop. The unit position zero point is set after the limit switch edge at the incremental encoder zero signal.

With the resolver, the absolute value of the position (within half a motor revolution) is stored at the limit switch edge (Zero-Capture).

The mechanical zero point can be shifted in plus or minus direction with the parameter Off. Ref. in plus or minus direction.

Overview of the reference switches for defining a digital input.

Input selection:	Function:
Ref. & Limit Plus	Limit switch positive Direction of rotation is reference switch
Ref. & Limit Minus	Limit switch negative direction of rotation is reference switch
Ref. Plus	Switch flank in positive direction of rotation, independent of limit switches, is
	reference switch

Locic-Input-Output				
INPUT				
Limit1	Ref. & Limit Plus	$\sim$	AL AH	
Limit2	Ref. & Limit Minus	$\sim$	AL AH	
Din1	Ref. Plus	~	AL AH	
Din2	Off	~	AL AH	

The selection window (parameter field Servo) is used to switch the delay when changing from Speed 1 to Speed 2 from R-Lim to N R-Dec.



### 14.3.2 Position controller – Homing Logic diagrams











Zeitdiagramm Referenzfahrt auf Referenzschalter in positiver Richtung









# **15 Field weakening control**

### 15.1 Field weakening control – Synchronous motor in general

Field weakening operation in synchronous motors with surface magnets is only possible in a small range. (max factor 1, 2) possible and therefore not economically viable.

In synchronous motors with embedded magnets (shank pole machines), speed ranges of up to a factor of 4 are achieved. In this case, the motor and the servo can be dimensioned smaller if the design is optimal.

### Attention:

In case of field weakening failure (mains disconnection, fault disconnection, etc.) at maximum speeds, high induced regenerative voltages can be generated by the motor. For servo units powered using the AC mains, the limit voltage is 400 V or 800 V.

For battery-operated units, the Back EMF voltage must always be lower than the battery voltage.

Without external protective circuits, the servo units or batteries can be destroyed in the event of motor overvoltages.



## 15.2 Field weakening control – Setting parameters

Parameter overview for the field weakening control on the **Speed** page.

Note:

Many of these parameters can also be found on the **Oscilloscope** page.



Symbol:	Function:	Range:	Unit:	ID address:
Id nom	Nominal Id magnetising current in % of the nominal	0100	%	0xB2
	motor current (I nom eff)			
	Recommendation: 0 % for PMSM			
Id min	Minimum magnetising current in % of the nominal	-1000	%	0xB5
	motor current (I nom eff)			
	Recommendation: -5030 %			
V-red	Voltage reference value in % of Vout	0100	%	0x8B
	(V-red $\neq$ 0, 100 % $\rightarrow$ activation field weakening control)			
	Recommendation: 6080 %			
V-kp	Proportional amplification of the field weakening control	065535	Num	0x8C
	Recommendation: 5004000			
V-Ti	Integral time of the field weakening control	065535	Num	0x8D
	Recommendation: 3005000			
	Attention: Vibration tendency			

## Without field weakening:

The speed (n\_actual) does not reach the speed specification (n\_cmd) at maximum possible output voltage (Vout).

As is usual with PMSM, the Id current (Id\_actual) is constantly regulated to 0 A.

The lq-current (lq\_actual) first provides a corresponding moment for the acceleration and then drops to the maximum possible value.

### With field weakening:

The speed (n\_actual) reaches the speed specification (n\_cmd) below the maximum possible output voltage (Vout).

The ld current (Id\_actual) is regulated for the field weakening to the value of Id\_ref specified by the field weakening controller.

In the case of motors with surface magnets, a high Id current for a small increase in speed.

Here, too, the lq-current (lq\_actual) first provides a corresponding torque for the acceleration and then drops to the required or still available value.

### Attention:

Field weakening is not a recommendet approach of solving a poorly designed system.

Although the speed can be increased, the torque drops to a very low value due to the physical properties of a PMS motor. This means that the motor has significantly less power in field weakening mode despite high power consumption.

The additional reactive current (Id\_actual) ensures on the one hand that the motor heats up very strongly and on the other hand, although the active current (Iq  $\triangleq$  moment) is very low, the consumption from the supply is very high due to the additional current component.

This means that in a system with a HV battery (e.g., vehicle), this is at the expense of the battery capacity (and thus the range).



G

m b





# 16 Frequency converter operation (ACI V/f)

## 16.1 Frequency converter – Parameter setting of the FU characteristic curve

Parameter overview of the frequency inverter characteristic curve of **FU Start**.

Note:

Many of these parameters can also be found on the **Oscilloscope** page.

FU Start -		
Tdc	200	ms
V dc	0.3	96
Vmin	4.0	96
Fmin	1.0	Hz
V corner	100.0	96
Fcorner	88.0	Hz
F-sh	linear	$\sim$

Symbol:	Function:	Range:	Unit:	ID address:
T dc	Premagnetisation time	102000	ms	0x07L
	Delay between switching on and starting the frequency			
V dc	Premagnetisation DC voltage value	020	%	0x08L
V min	Minimum voltage (boost) when the motor is at a	0100	%	0x0A <sub>L</sub>
	standstill			
	$\rightarrow$ U/F characteristic curve is raised			
	Recommended: V min = V dc			
F min	Minimum frequency when the motor is at a standstill	0100,0	Hz	0x0BL
V corner	Maximum output voltage at the cut-off frequency	0100,0	%	0x0CL
F corner	Cut-off frequency for maximum output voltage	11000,0	Hz	0x0DL
F-sh	Shape of the characteristic curve (linear, half-square,			
	square)			



### Note:

In Ndrive, only the parameter field FU Start of the characteristic curve setting for frequency inverter operation is currently in use. The characteristic curve for FU Stop is the same as that of FU Start.



### 16.2 Frequency converter – Setting motor parameters

Frequency control without a feedback encoder can be configured via the setting field for the frequency inverter in the Motor field.

For standard motors for AC mains operation, the nameplate indicates often specifications for 50/60 Hz operation and star-delta connection can be found. These specifications are internationally standardised. For motors for inverter operation, the nominal operating point is at a fixed frequency, usually above 50/60 Hz Mains frequency. Not all manufacturers specify the further values completely.

Motor		
Туре	ACI V/f	$\sim$
Nnom	3000	RPM
Fnom	150.0	Hz
Vnom	400	v
Cos Phi	1.00	
I max eff	10.0	A rms
I nom eff	5.3	A rms
M-Pole	6	
Kt	0.000	Nm/A
Ke	90.00	V/krpm

The nominal speed at the nominal operating point (nominal frequency, nominal load) is sometimes missing or the specification of Cosphi is missing. In some cases, the values are also given in a misleading way, e.g. voltage related to phase to phase (terminal voltage), or phase voltage (terminal to star point), or DC bus voltage Please check the manufacturer's specifications and dimensions carefully (V, VAC, VDC, A, Arms, etc.).

Nominal data:	Symbol:	Example motor 50Hz:	Example motor 60Hz:	Unit:
Mains frequency	F nom	50	60	Hz
Rated voltage	V nom	220-240, 360-420	255-275, 440-486	V
Rated current	l nom eff	2.33-2.25, 1.35-1.30	2.26-2.18, 1.30-1.26	Arms
Rated speed	N nom	2820	3385	rpm
Cosphi	Cos Phi	0.85	0.85	

From the above nominal data, the drive's internal function "[Fn8] Calc from motor nameplate" to determine further values for the motor model ( $\rightarrow$  page **Auto**).

Updating the display in NDrive only takes place with process offline-online (i.e. RS232 communication disconnect and reconnect).

### Activation of frequency inverter operation:

- 1. On the Settings page, select "ACI V/f" as the motor type.
- 2. Select "SLS" as the feedback type.

<ul> <li>Special functions, (disable drive) –</li> </ul>	ŪXŪŪŪŪ
[Fn8] Calc from motor nameplate	$\sim$
Enter motot data, (see right)	
if cos Phi unknown, enter zero	
START	
Idle	

### Note:

In frequency converter operation when controlling an AS motor without an encoder feedback, there is no slip compensation.

# 17 Logic

# 17.1 Logic – General overview

Setting field for the digital inputs (INPUT) and the digital outputs (OUTPUT) in NDrive on the **Logic** page.

- Locic-Input	-Output					
INPUT						
Limit1	Ref. & Limit Plus	$\sim$	AL	AH		
Limit2	Ref. & Limit Minus	~	AL	AH		
Din1	[Start] Ref. Drive	~	AL	AH		
Din2	Off	~	AL	AH		
OUTPUT						
Dout1	Warning-Error map	~	!=	~	Var1	$\sim$
Dout2	Status map	~	=	~	Var2	$\sim$
Dout3	Off	~	Off	~	0	$\sim$
Dout4	Off	~	Off	~	0	$\sim$
Var1	32			0x000	00020	
Var2	1			0x000	00001	
Var3	0			0x000	00000	
Var4	0			0x000	00000	

#### **INPUT:** Programmable digital input, preferred as limit switch and reference switch Limit1 Limit2 Programmable digital input, preferred as limit switch and reference switch Din1 Programmable digital input Din2 Programmable digital input

OUTPUT:	
Dout1	Programmable digital output (operant and comparison variable)
Dout2	Programmable digital output (operant and comparison variable)
Dout3	Programmable digital output (operant and comparison variable)
Dout4	Programmable digital output (operant and comparison variable)
	(Dout4 is not available on all devices)
Var1 to Var4	Comparison variable

G

## 17.2 Logic – Digital inputs

### 17.2.1 Logic – Digital inputs General

In general, the logic level can be read out for each digital input.

In addition, it is possible to assign a variety of special functions to each individual digital input.

The special functions are selected via the respective pull-down menu.

These special functions are triggered by the logic level of the digital input depending on the configuration of the activation condition (AL / AH).

The setting of the activation condition of the special functions takes place via the switches AL = Active Low and AH = Active High.



G

m b



With the return key, the functions are written into the RAM memory and executed By saving in Eprom level 0, these settings are also permanently saved and are applied after a restart.

The limit switch inputs Limit1, Limit2 are displayed in the status field with Lim+ and Lim-. However, these can also be configured for other functions.

### Example:

INPUT:	Selection:	Function:	Acv. Logic:
Limit1	Ref. & Limit Plus	Limit switch positive direction is also a reference switch	AL
Limit2	Limit minus	Limit switch minus	AL
Din1	[Start]Ref. Drive	Start calibration run	AH

### Note:

All digital inputs have an internal pull-down resistor and therefore do not need to be wired low if not used.

H



### 17.2.2 Logic – Digital Inputs overview configuration

Overview of the configuration options or the special functions of a digital input (INPUT)

INPUT:	Function:	
Ref. & Limit Plus	Limit switch positive direction is also a reference switch	
Ref. & Limit Minus	Limit switch minus direction is also reference switch	
Ref. Plus	Reference switch plus direction	
Limit Plus	Limit switch positive direction	
Limit minus	Limit switch minus direction	
Limit Plus &. Minus	Limit switch plus direction and minus direction	
Cancel Error(s)	Clear error memory	
[Start]Ref. Drive	Start calibration run	
Speed Ramp 0	Speed setpoint internally switched to 0 (during Speed 0 active)	
[Start] Dest > Var1	Position Variable 1 is started	
[Start] Dest > Var2	Position Variable 2 is started	
N cmd Reverse	Setpoint polarity is switched (speed direction inverted)	
Preset] Pos = Var3	Position actual value is set to variable 3	
[Capture] Var3 = Pos	Sets variable 3 as position (destination) and moves to position	
[Capture] Var4 = Pos	Sets variable 4 as position (destination) and moves to position	
[Switch] Spd = !Ain1/Ain2	Toggle command setpoint Ain1 or setpoint Ain2	
[Switch] Spd = !Var1/Var2	Changeover command setpoint Var1 or setpoint Var2	
I limit (dig.)	Current limitation to the setting of parameter I limit dig	
N clip (neg. & pos.) Speed limitation to the setting of the parameter		
	N-Lim+ and N-Lim-	
[Switch] Cmd = !Dig/Ana	Switch command setpoint digital + analogue setting	
	(Command Mode Digi + Ana Speed)	
Speed Ramp 0 + Pos	Positioning to position within one motor revolution	
	(pos = Reso Edge)	
Handwheel	Incremental setpoint from handwheel encoder (2nd counter input)	
Brake Car <sup>1</sup>	Regenerative braking function #1	
	(Current setting for N-Lim+ and N-Lim-)	
recu_disab	Regenerative braking function is switched off	
rising bank1, falling bank2	PARA_UPDATE	
[Start] Dest = Var1,2,3,4	Position setpoint from sum of variables Var1 to Var2 is started	
[Start] cw = Var1,2,3,4	Cw_combi	
Brake Car #2 <sup>1</sup>	Regenerative braking function #2	
	Consideration of the delta deviation from the analogue input for the	
1500 "Information on special Car application	braking force	

# 17.3 Logic – Digital outputs

### 17.3.1 Logic – Digital outputs in general

In general, the output logic level of each digital output can be configured using a wide range of possibilities.

For the configuration, a known measure variable (first column) is used as a reference. This can then be used via a variety of possibilities of comparison operands (second column) with self-defined variables to output the corresponding desired logic level.

The selection of the measure variable used as a reference, the operants and the selection of the comparison variables is done via the respective pull-down menu.

The value of the comparison variable is entered in the respective input field of Var1, Var2, Var3 and Var4.

The logical result is output at the digital output as low (< 1 V) or high (> 10 V).

With the return key, the functions are written into the RAM memory and executed. By saving to Eprom level 0, these settings are also permanently saved and are applied after a restart.

### Attention:

For switched inductances (relays, brakes, etc.), connect overvoltage protection by means of free-wheeling diodes or varistors. The output driver switches off in case of overvoltage.





### 17.3.2 Logic – Digital outputs overview configuration

 Overview of the configuration options of a digital output.

 OUTPUT:
 Function:

 L cmd
 Current setpoint (result speed controller)

OUTPUT:	Function:	ID address:
l cmd	Current setpoint (result speed controller)	0x26
l actual	Actual current value	0x20
N cmd (ramp)	Speed setpoint	0x32
N actual	Actual speed value	0x30
Pos cmd	Target position used (internal)	0x6E
Pos actual	Actual position value	0x6D
N error	Speed control error	0x33
Pos error	Control error Position actual value	0x70
T-motor	Motor temperature	0x49
All parameters lis	ted in the measured value selection can be assigned to the outputs	

<b>Operant:</b>	Function:	
Off	Always off	
On	Always On	
1Hz	Pulses with f = 1 Hz	
=	same	
!=	unequal	
>	greater than	
<	smaller than	
abs >	Absolute value greater than	
abs <	Absolute value less than	
tol >	Tolerance input TOL-wind	
Tol <	Tolerance input TOL-wind	
>=	greater than or equal to	
<=	Less than or equal to	
hyst >=	Hysteresis at >=	
Hyst <=	Hysteresis at <=	
window	Tolerance window ±25 %	

Variable:	Function:	ID address:
0	Logic signal zero	
1	Logic signal one	
Var1	Numerical value of the	0xD1
Var2	entered variable fields	0xD2
Var3		0xD3
Var4		0xD4
Ain1	Numerical value of the	
Ain2	voltages at the analogue	
	inputs	



OUTPUT						
Dout1	Warning-Error map	$\sim$	!=	~	Var1	~
Dout2	Status map	$\sim$	=	~	Var2	~
Dout3	Off	~	Off	~	0	~
Dout4	Off	~	Off	~	0	~
Var1	32			0x000	00020	
Var2	1			0x000	00001	

### Example 1: Configuring an inverted the "Power voltage missing" error on a digital output

Target:

Output Dout1 should output a high (> 10 V) logic level when the power voltage is switched on or when no error 5 (POWERVOLTAGE, power voltage missing) is present.

- Select the signal (Warning-Error map) for the Dout1 output via the pull-down menu.
- Set operant to (!=).
- (Var1) is selected as the comparison variable.
- In the input field for Var1, enter the decimal value 32 for the query on error 5 of the error information.
   (0x8FBit 5). A query on a combination on several bits is also possible.

### Example 2: Configuring the status information "Ena" on a digital output

Target:

Output Dout2 should output a high (> 10 V) logic level when the inverter is activated or if the PWMs actively output a voltage on the motor lines, the status information **Ena**  $(0x40_{Bit 0})$  is set.

- Select the signal (Status Map) for the Dout2 output via the pull-down menu.
- Operant set to (=) (Inverted to (!=)).
- (Var2) is selected as the comparison variable.
- Enter the decimal value 1 for the query on the status information Ena (0x40<sub>Bit 0</sub>) in the input field for Var2. A check for a combination of several bits is also possible.



# **18 Diagnostics**

# 18.1 Diagnostics – General overview

The **Diagnostics** page in NDrive is an information window for displaying as well as manually reading signals and setting parameters.

		Manual Real	d/Write	Track	Information /
Manual	Read/Write	-		0 (0×0)	Logic freq 60304 Hz
1	rack	Write	ID register 0x31		Info Intr 638 ···
Info	rmation		value 5000	Nactual V 0 (0x0)	fpga 1st error 0x0000 dec
Show a	II registers			Error map 🗸 0 (0x0)	fpga Status 0x0000 dec
Show sele	cted registers	Read	ID register 0x1B	I Fault 🗸 0 (0x0)	Mode 0x0008 dec
Aut	o-Reso		478	-0#	
Auto-	Optimize		value (0x01de)		Close
	icript		1	Off	
En	or-Log		Close	Close	
		-			
RegNr Typ	Hex value	Decimal	Label M-Pole	: Description . Notor pore count	:
0x50 (RW)	0x0064	100	Cutoff	: cutoff window Ainl	^
0x51 (SP)	0x0008	8	Mode	Mode : Mode State	
0x52 (SP)	0x0000f811	63505	Status mask	: Status mask	
0x53 (RW)	0x0000	0	Cutoff	: cutoff window Ain2	
0x54 (RO)	: 0x0001	1	Il actual	: Current actual value Il	
0x55 (RO)	0x0000	0	I2 actual	I2 actual : Current actual value I2	
0x56 (RO)	0x0000	0	I3 actual	: Current actual value I3	
0x57 (RO)	0x01a4	420	I lim inuse rmp	: ??	
0x58 (RW)	0x5208	21000	I-red-TD	: ??	
0x59 (RW)	0x0bb8	3000	N nom	: Rated motor speed	
0x5a (RW)	0x0000080c	2060	Device Options	: Device settings (options)	
0x5b (RW)	0x0000	0	Kacc	: Acceleration amplification	
0x5c (RO)	0x9271	37489	Rotor	: Rotor signals	
0x5d (RO)	0x0000	0	N cmd (int)	: Command speed internal	
0x5e (RW)	0x0004	4	Filter	: Filter speed actual value	
0x5f (RO)	0x0000	0	I act (filt)	: Filtered actual current	

Overview of the individual windows on the Diagnostics page.

Manual Read / Write	Direct readout and input of parameter values on defined ID addresses
Track	Display of selected measured signals (numerical)
Information	Display field for current states of special signals
Show all registers	All registers are listed as a table
Show selected registers	Selected registers are listed as a table
Auto-reso	Not yet installed
Auto-Optimize	Not yet installed
Script	Not yet installed
Error log	Not yet installed

# 18.2 Diagnostics – Manual Read/Write

Direct readout and entry of parameter values (Attention: only for service!).

### Parameter Write:

- Enter the ID address in the **ID register** input field.
- In the **value** input field, enter the value for the selected ID address (numeric or as hex value).
- Enter or click on the Write button. The new value is adopted immediately.

### **Parameter Read:**

- Enter the ID address in the ID register input field.
- Press Enter or click on the Read button. The content of the ID address is displayed in the value field (numeric and as hex value).

### 18.3 Diagnostics - Track

Displays with automatic cyclical readout of a selection of up to 8 different measuring and Parameter values (Attention: only for service!).

The respective variable is selected via the pull-down menu.

The current values are displayed numerically as well as in hex values (0x..).

### Note:

All measured values can also be displayed in the oscilloscope.

### **18.4 Diagnostics – Information**

Display field for current states of special signals.

Shortz.:	Function:
Logic Freq.	Speed of the foreground programme
Info Intr	Speed actual value fault
fpga 1st error	First error code recorded from the Ecode signal
fpga status	Current error code from the Ecode signal
Fashion	Mode bit setting (0x51)



Write	ID register	0x31
	value	5000
Read	ID register	0x1B
	value	478 (0x01de)
	Close	

G

m

b



H



# 18.5 **Diagnostics – Show register**

Displaying a list view of all or only a certain number of variables. (No cyclical updating but only once)

RegNr	Тур	Hex value	Decimal	Label	: Description	
0x51	(SP):	0x0000	0	Mode	: Mode State	^
0x52	(SP):	0x0000f811	63505	Status mask	: Status mask	
0x53	(RW):	0x0064	100	Cutoff	: cutoff window Ain2	
0x54	(RO):	0x0006	6	Il actual	: Current actual value Il	
0x55	(RO):	0x0002	2	I2 actual	: Current actual value I2	
0x56	(RO):	0x000x0	0	I3 actual	: Current actual value I3	
0x57	(RO):	0x01a4	420	I lim inuse rmp	: ??	
0x58	(RW):	0x5208	21000	I-red-TD	: ??	
0x59	(RW):	8dd0x0	3000	N nom	: Rated motor speed	
0x5a	(RW):	0x0000080c	2060	Device Options	: Device settings (options)	
0x5b	(RW):	0x000x0	0	Kacc	: Acceleration amplification	
0x5c	(RO):	0xffd5	65493	Rotor	: Rotor signals	
0x5d	(RO):	0x000x0	0	N cmd (int)	: Command speed internal	
0x5e	(RW):	0x0004	4	Filter	: Filter speed actual value	
0x5f	(RO):	0x000x0	0	I act (filt)	: Filtered actual current	
0x60	(RW):	0x000x0	0	Filter	:	
0x61	(RO):	0x000x0	0	Vdc-Mid	: Battery voltage (Centre)	
						*
			Close	Update Save all registers	Print all registers	

### Options for the display field for registers:

Selection:	Function:
Show all registers	All 255 registers are displayed in a table.
	The register contents cannot be changed.
Show selected registers	Only the registers that are important for the user are shown in a table.
	The selection is made with the configuration of the text file "reglist.txt".
	$\rightarrow$ '\NDrive2-Software\settings\reglist.txt'
	The register contents cannot be changed.

### Selection of options in the footer:

Selection:	Function:
Close	Display field is closed.
Update	The parameter values are read anew from the device (servo).
Save all / selected Registers	All / The displayed registers are written to a file.
Print all / selected registers	All / The displayed registers are printed.

# **19 Monitor**

# 19.1 Monitor – General overview

Overview of the signals displayed on the Monitor page.

EK	Settings	Speed	Position	Logic	Bus	Oscilloscope	Monitor	Device	Diagnostics	Auto	Extr
Moni	tor values -										
N cmd	(ramp)		500	0				1		1	00%
Nactu	lai		503	2						1	00%
lq cma	1		21	1						1	50%
l act (f	īlt)		12	Ē				1		1	50%
ld actu	ual		0							1	50%
lq acti	ual		10	1				Ť		1	50%
lxt			0							1	50%
Power	r		0	-				1		1	5096
Vdc-Bu	us (dir)		0							1	50%
Regen	. energy		0					1		1	50%
T-moto	or.		0							1	50%
T-igbt			0					1		1	50%
T-air			0	1						6	0 C
l lim ir	nuse		630						1	1	50%
Vout			828							1	50%
			416					- i		1	50%

Symbol:	Function:	Range:	Unit:	ID address:
N cmd (ramp)	Speed setpoint after ramp and limit	032767	Num	0x32
N actual	Speed actual value	032767	Num	0x30
lq cmd	Active current (Iq) Setpoint (internal)	±2000	Num	0x26
I act (filt)	Actual current value after display filter	±2000	Num	0x5F
Id actual	Current reactive current (Id)	±2000	Num	0x28
lq actual	Current active current (Iq)	±2000	Num	0x27
lxt	Capacity utilisation Ixt	04000	Num	0x45∟
Power	Motor power (do not use!)	04000	Num	0xF6
Vdc-Bus (dir)	DC link voltage	032767	Num	OxEB
Regen. energy	Ballast power	04000	Num	0x45 <sub>н</sub>
T-motor	Current engine temperature	032767	Num	0x49
T-igbt	Current power stage temperature	032767	Num	0x4A
T-air	Current air temperature in the servo	032767	Num	0x4B
l lim inuse	Current limit	02000	Num	0x48
Vout	Current output voltage	04000	Num	0x8A
M out	Actual active current (Iq) standardised	±32767	Num	0xA0



# 20 Auto (special functions)

The **Auto** page in NDrive contains an overview of engine-specific parameters and the menu for activating special functions.

### 20.1 Auto – Motor parameters

Overview of the **Motor-Parameter** and the **Motor-Nameplate** parameters on the **Auto** page.

Motor-Parameter								
L sigma-q	0.120	0.120	mH					
L sigma-d	0.120	0.120	mH					
R stator	180	180	mOhm					
TC stator		0.666	ms					
L magnet.	0.23	0.23	mH					
R rotor	100	100	mOhm					
TC rotor		2	ms					
FB-Offset	150.0	150.0	Deg					

Motor-Name	eplate	EC Servo
Nnom	3000	RPM
Fnom	150.0	Hz
Vnom	230	v
Cos Phi	1.00	
I max eff	10.0	A rms
I nom eff	5.3	A rms
M-Pole	6	
ld nom	0	0 %
ld min	0	0 %
Kt	0.650	Nm/A
Ke	90.00	V/krpm

Symbol:	Function:	Range:	Unit:	ID address:
L sigma-q	q component of the stator leakage inductance	0 65,535	mH	0xB1
	(for ACIM, Lsd = Lsq)			
L sigma-d	d component of the stator leakage inductance	0 65,535	mH	OxBB
R stator	Stator resistor <sup>1</sup>	065535	mOhm	0xBC
TC stator	Stator time constant (Ls/Rs) <sup>2</sup>	032767	ms	0xB6
L magnet.	Main inductance	0655,35	mH	0xB3
R rotor	Rotor Resistor <sup>1</sup>	065535	mOhm	0xB4
TC rotor	Rotor time constant (Lm/Rr) <sup>2</sup>	02000	ms	0xBD
FB-Offset	Encoder offset angle	±360	Deg	0x44
<sup>1</sup> Enter without a c	omma			

<sup>2</sup> Calculation takes place internally

Symbol:	Function:	Range:	Unit:	ID address:
N nom	Engine speed (for FU autotuning)	6065000	rpm	0x59
F nom	Frequency rated motor speed (for FU mode)	201200	Hz	0x05
V nom	Voltage at rated motor speed (for FU mode)	01000	V	0x06
Cos Phi	Motor power factor (for FU mode)	0327,00	%	0x0E
I max eff	Motor maximum current	01000,0	Arms	0x4D
I nom eff	Motor continuous current	01000,0	Arms	0x4E
M-Pole	Motor pole number (2 x pole pairs)	296	Num	0x4F
ld nom	Nominal Id magnetising current in % of nominal motor current (I nom eff)	0100	%	0xB2
ld min	Minimum magnetising current in % of rated motor current (I nom eff)	-1000	%	0xB5
Kt	Motor Kt constant	050,000	Nm/A	0x87L
Ке	Motor Ke Constant (Back EMF)	0500,00	V/krpm	0x87 <sub>н</sub>



## 20.2 Auto – Special functions

### 20.2.1 Special functions – Overview

Overview of the individual special functions in the window **Special functions** on the **Auto** page.

special functions, (disable drive) 6x0000		
[Fn4] Phasing - Rotating 🗸 🗸		
Idle		
[Fn1] Tuning - Still		
[Fn2] Tuning - Rotating		
[Fn3] Phasing - Still		
[Fn4] Phasing - Rotating		
[Fn5] DC-Injection		
[Fn6] Analog offset		
[Fn7] Tacho offset		
[Fn8] Calc from motor nameplate		
[Fn9] VdcBus zero compenstaion		
[Fn10] VdcBus voltage compenstaion		
[Fn11]		
[Fn12]		
[Fn13]		
[Fn14]		
[Fn15]		

Special function:	Meaning:	ID address:
		0x85
Idle	Hibernation	0 dec
[Fn1] Tuning - Still	not used	1 dec
[Fn2] Tuning - Rotating	not used	2 dec
[Fn3] Phasing - Still	not used	3 dec
[Fn4] Phasing - rotating	Automatic detection of rotor offset angle for	4 dec
	synchronous motors (FB offset)	
[Fn5] DC Current	Fixed current angle of phases U, V, W with rated motor	5 dec
	current	
[Fn6] Analogue offset	Automatic adjustment of the analogue inputs	6 dec
[Fn7] Speedometer offset	Automatic adjustment of the segment offset for bl-tacho	7 dec
[Fn8] Calculation from motor	Calculating the motor data according to nameplate data	8 dec
nameplate		
[Fn9] Adjustment	1.Step measured value correction DC link voltage	9 dec
VdcBus Zero	$\rightarrow$ Adjustment for measuring point at 0 V	
[Fn10] Adjustment	2. Step measured value correction DC link voltage	10 dec
VdcBus Voltage	$\rightarrow$ Adjustment for measuring point at reference voltage	


#### 20.2.2 Special functions – [Fn1] Tuning - Still

Function not yet released!

Activation:

- 1. Selection [Fn1] Tuning Still
- 2. Message on the ID address 0x85 = 1

Special functions, (disable drive) 00000		
[Fn1] Tuning - Still	$\sim$	
Determine Motor Parameters		
first call function		
[Fn8] Calc from motor nameplate		
START		
Idle		

#### 20.2.3 Special functions – [Fn2] Tuning - Rotating

Function not yet released!

Activation:

- 1. Selection [Fn2] Tuning Rotating
- 2. Message on the ID address 0x85 = 2

Special functions, (disable drive)			
[Fn2] Tuning - Rotating 🗸 🗸			
START			
Idle			



# 20.2.4 Special functions – [Fn3] Phasing - Still

Function not yet released!

Activation:

- 1. Selection [Fn3] Phasing Still
- 2. Message on the ID address 0x85 = 3

Special functions, (disable drive)		
[Fn3] Phasing - Still 🗸 🗸		
START		
ldle		



#### 20.2.5 Special functions – [Fn4] Phasing - Rotating

#### Goals:

- Check correct connection of motor cables (U, V, W).
- Check input of the number of motor poles (M-Pole).
- Determination of the encoder phase angle (FB-Offset).

#### Hardware preparation:

- The motor must be freewheeling or connected on a light load.
- The motor must not present a hazard in the event of uncontrolled acceleration.
- Supply unit with power voltage (mains / HV) (For units with HV DC voltage, it is recommended to apply a low DC voltage (12..48 V)).

#### Preparation parameters:

- Motor pole number **M-Pole** (0x4F) and encoder pole number **FB-Pole** (0xA7) must be set correctly.
- Set the reduction of the permitted current **I max pk** to **10%**.
- Set the rotational speed for the phasing process via **Speed 2** to 3 % of the nominal speed (e.g.: 100).

#### Start and procedure description:

- 1. Selection [Fn3] Phasing Rotating
- 2. Activating the function  $\rightarrow$  Press START (or message on the ID address 0x85 = 4)
- 3. After pressing START, 10 s remain to activate the enable RUN (FRG) input (In NDrive: Wait for RUN = 1).
- 4. The current ramp sets the set current, and the motor moves with a jerk between 2 of its electrical poles.
- 5. The motor then rotates clockwise for exactly 360° from pole to pole depending on the motor pole number (may jump jerkily from pole to pole).
- After a short time, the current ramp degrades again.
  Finally, disable the enable RUN (FRG) input (In NDrive: Wait for RUN = 0).

#### Findings:

- The slow **clockwise rotation** confirms the correct arrangement of the U,V,W connections.
- The **360° rotation** confirms the correct specification of the motor pole number M-Pole (0x4F).
- The phase angle determined is displayed in the right-hand field (grey) (here: -59.8 Deg). After a successful phasing process, the new value must be entered in the left field (yellow) and saved permanently on the page Setting Eprom level 0.

FB-Offset	20	-59.8	Deg
1 D-Oliset	20	-33.0	

Note:

- The FB-Offset only needs to be determined once and not after every restart.
- The accuracy of this method is physically limited to ±2 %. However, sufficient for general operation.

Special functions, (disable drive)		
[Fn4] Phasing - Rotating $\sim$		
Determine Feedback Offset Angle for		
synchronous motor (PMSM)		
(+Speed> CW motor rotation)		
START		
Idle		

Phasing-Parameter		
Speed 2	100	Num



#### Error situation:

- The motor does not turn
  - $\circ$  U,V,W connection is not correct  $\rightarrow$  *change unknown*
  - Current limit possibly too small or the connected load is too large
  - $\circ~$  The value of Speed 2 is too small or too large
- The motor rotates anticlockwise (counterclockwise)
  ∪,V,W connection is not correct → Replace connection U and W
- The motor rotates more or less than 360°.
  - Incorrect specification of the number of motor poles M-Pole (0x4F)  $\rightarrow$  correction

#### **Overview of the process:**

Function:	Message at NDrive:	7-segment display:
Select function [Fn4] Phasing - rotating and click START		
Switch on enable within 10 seconds	Waiting for RUN = 1 (enable RUN input)	40
Release closed	Current ramp	41
Current built up (rotary movement begins)	Nominal value reached	42
Pole angle and motor pole number detection performed	Output rotating field	43
End correct	End End, wait for RUN = 0 (disable RUN input)	49

#### Abort on error:

Function:	Message at NDrive:	7-segment display:
Enable switched off during measuring	Error	47
process		
Time out, measuring time exceeded		48



#### 20.2.6 Special functions – [Fn5] DC-Injection

By specifying an angle of current flow (angle), the rotor (motor shaft) is moved to this angle and held (no rotating field).

#### Start and procedure description:

- 1. Selection of [Fn5] DC-Injection
- 2. Reduce current limit nominal current l nom eff to 30%.
- 3. Set the desired electrical angle under FB Offset (0x44).
- 4. Supply unit with power voltage (mains / HV)
- Activate function → Press START (or message on the ID address 0x85 = 5)
- 7. Enable the RUN input

Special functions, (disable drive) (0000
[Fn5] DC-Injection $\checkmark$
Current injection of phases U-V-W
with Nominal Current split to 3-ph
according to offset angle (0= V-W)
START
Idle

#### **Result:**

- The motor shaft rotates and sets itself to the specified angle with the maximum possible current.
- As long as the enable is set, a new angle for FB-Offset (0x44) can be specified in the left field (yellow).
- Switching off the RUN input disables the function.

#### Attention:

Before further motor operation, the correct value for FB offset must be re-entered and saved (Eprom level 0).

If the value for FB-Offset is incorrect, the drive may rotate or move uncontrollably!





#### 20.2.7 Special Functions – [Fn6] Analog offset

Function not yet released!

#### Activation:

- 1. Selection [Fn6] Analog offset
- 2. Message on the ID address 0x85 = 6

Now, the scattering of the analogue inputs can be adjusted using the settings of the analogue parameters (Offset, Cutoff and Scale).

Special functions, (disable drive)		
[Fn6] Analog offset	~	
START		
Idle		



#### 20.2.8 Special functions – [Fn7] Tacho offset

Adjustment of segment offset error in brushless tacho systems.

#### Start and procedure description:

- 1. Selection of [Fn7] Tacho offset
- 2. Activate function  $\rightarrow$  Press START
- (or message on the ID address 0x85 = 7)3. Enable the RUN (FRG) input
- 4. After a successful tacho offset, one must set the Internal value determined on the Setting page. Save permanently in Eprom level 0.

Special functions, (disable drive)		
[Fn7] Tacho offset 🗸 🗸		
START		
Idle		

#### **Overview of the process:**

Function	Message at NDrive:	7-segment display:
Click on the Start Tacho offset function		70
Enable the RUN (FRG) input		
End correct		79

#### Abort on error:

Function:	Message at NDrive:	7-segment display:
Enable switched on during measuring process		76
Movement detected on the rotor		77
No speedometer connected		78



#### 20.2.9 Special functions – [Fn8] Calc from motor nameplate

Calculation of motor data for asynchronous motors.

#### Start and procedure description:

- 1. Enter the motor data in the **Motor-Parameter** window in the left-hand parameter fields (yellow).
- Selection of [Fn8] Calc from motor nameplate
  Activate function → Press START
- (or message on the ID address 0x85 = 8)

After the calculation has been completed, the calculated values are displayed in the right-hand column (grey).

For permanent storage, the data must be permanently save on the Setting page in Eprom Level 0.

Special functions, (disable drive)		
[Fn8] Calc from motor nameplate $\sim$		
Enter motot data, (see right)		
if cos Phi unknown, enter zero		
START		
Idle		

Overview of the <b>Motor-Parameter</b> field on the <b>Auto</b> page.
---

Symbol:	Function:	Range:	Unit:	ID address:
L sigma-q	a-q q component of the stator leakage inductance		mH	0xB1
	(for ACIM, Lsd = Lsq)			
L sigma-d	d component of the stator leakage inductance	065,535	mH	0xBB
R stator	Stator resistor <sup>1</sup>	065535	mOhm	0xBC
TC Stator	Stator time constant (Ls/Rs) <sup>2</sup>	032767	ms	0xB6
L magnet.	Main inductance	0655,35	mH	0xB3
R rotor	Rotor Resistor <sup>1</sup>	065535	mOhm	0xB4
TC Rotor	Rotor time constant (Lm/Rr) <sup>2</sup>	02000	ms	0xBD
FB-Offset	Encoder offset angle	±360	Deg	0x44
<sup>1</sup> Enter without a comma				
<sup>2</sup> Calculation takes	place internally			



#### General

There are various descriptions of the motor model in the literature, all of which are identical in principle. Some of the abbreviations used may be different. Differences exist only in the proximity to physically measurable quantities (T-model), or further abstraction for simplified calculation models (inverse gamma model).

Some manufacturers provide additional values such as number of poles, open-circuit current at a defined open-circuit voltage (= magnetising current), ohmic resistance of the stator windings, stator impedance at a defined frequency, as well as values on the rotor-related variables.

This information from the manufacturer is usually helpful and correct. The real, physical values can be measured. For values related to the stator, by direct measurement. For values related to the rotor, indirectly, by measuring the reaction on the stator.

The representation in the motor models partly no longer refers to the real physical values, but to converted values.



Bild 1: T-Modell, stationary,[2]



Bild 2: inverses Gamma Modell, stationary,[2]

- Rs Stator resistance
- ir Current in rotor
- Lm Main inductance
- Lrσ Rotor leakage inductance
- im Magnetising current
- Rr Rotor resistance
- Lso Stator leakage inductance
- iμ Current through Lm
- σ total scattering factor



#### Basic procedure

For new or unknown motors, the following assignment can first be checked in the operating mode FU, page Settings "Type": positive speed setpoint = clockwise field U, V, W = clockwise rotation = positive speed actual value. Set values on page "Settings", FU left field according to V/f-characteristic. Operation at nominal point without load results in approx. magnetising current.

#### **Optimisation process**

Couple a loading machine with approx. 20 to 50 % of the nominal torque. Set a constant torque in the NDrive via the test control panel (bottom left). The result is a stationary speed.

When the machine is rotating, the value of Lm or Rr can be changed (T-rotor = Lm/Rr). The effect is immediate in the control. The aim is to optimise the T-rotor for a higher resulting speed at the same load. The result in operation is a lower current consumption with the same load torque. The value of T-Rotor in ms is only updated by NDrive during the offline-online process.

In a second stage, Id nom (NDrive side speed) can be varied, no field weakening active (V-red = 0). Easy to observe at standstill (current = magnetising current). When the machine is rotating, the value again becomes effective immediately. The goal is again a higher resulting speed at the same load. The result in operation is a higher final speed when the voltage limit is reached (maximum modulation). Compare the values determined on a test basis with any values provided by the manufacturer. Save and reset the servo (Off-On). Check values and function again.



#### 20.2.10 Special functions – [Fn9] [Fn10] VdcBus compensation

Calibration of the analogue VdcBus DC link measurement (device-dependent) as of firmware 466.

Calibration is carried out in 2 steps, one of which determines the zero point ([Fn9] VdcBus zero compensation) and the other the corresponding reference point ([Fn10] VdcBus voltage compensation). In principle, all units are already calibrated at the factory.

When replacing a component, the adjustment must be carried out again.

#### Step 1: [Fn9] VdcBus zero compensation

#### Start and process description:

- 1. For the automatic adjustment, the Command Mode must be set to Dig. Commands.
- 2. Selection of [Fn9] VdcBus zero compensation
- 3. At the VdcBus U+ and U- connections apply no voltage (for Bamobil devices please short-circuit U+ and U-)
- 4. Activate function  $\rightarrow$  Press START (or message on the ID address 0x85 = 9)
- 5. After approx. 4 s the message "End" informs the successful VdcBus zero compensation.

Special functions, (disable drive)	
[Fn9] VdcBus zero compenstaion $\qquad \qquad \qquad$	
Turn off power-voltage source(s),	
and ensure device is discharged	
START	
Idle	

#### Step 2: [Fn10] VdcBus voltage compensation

#### Start and process description:

- 1. For the automatic adjustment, the Command Mode must be set to Dig. Commands.
- 2. Selection of [Fn10] VdcBus voltage compensation
- 3. At the VdcBus U+ and U- connections apply a constant DC voltage with min. 2/3 of the units nominal voltage.
- 4. Measure the DC link voltage with a voltmeter.
- 5. In the parameter field **Calibr.** (0x1A) enter the measured voltage value as the reference voltage.
- 6. Activate function  $\rightarrow$  Press START (or message on the ID address 0x85 = 10)
- 7. After approx. 4 s the message "End" informs the successful VdcBus reference point adjustment.

The internal calculated calibration points must finally be saved permanently on the Setting page in Eprom level 0 and 1.

-Analog-		
Kalibr.	0,0	v
Vdc-Bus	1	

#### Note:

If the calibration points deviate too much from the standard, default values are taken.

Special functions, (disable drive) COCCO [Fn10] VdcBus voltage compensitate

START

Turn on power-voltage source,

and ensure device is charged

Idle



# 21 Oscilloscope

# 21.1 Oscilloscope – General overview

Overview of the **Oscilloscope** page in NDrive with compact parameter overview for inverter specific parameters, Step Generator and the menu for the oscilloscope settings.





# 21.2 Oscilloscope – Settings and display

#### 21.2.1 Oscilloscope – Signal selection

Overview of the selection of up to 8 channels (signals) and description of the individual fields on the **Oscilloscope** page.

	Value	Delta Value	Channel	Pos	U/Div		-
1	916 RPM	÷	N cmd (ramp)	/ 0	10000	$\checkmark$	C
2	914 RPM	-	Nactual	0	10000	$\checkmark$	C
3	0.27 A	-	lq cmd ramp	0	600	1	C
4	0.32 A	-	lactual	0	600	$\checkmark$	C
5	10.59 A	-	l lim inuse 💦	0	600		C
6	0		M set (dig.)	0	4000		С
7	252	•	incr_delta	0	500		C
8	1640	-	Vout / Vxxx	0	4000		C
	Time 184ms	Delta-				8 20	* 10

Field:	Function:	
Value	Values at the first cursor line (numeric or physical (if available)).	
Time	Time from the trigger line to the first cursor line.	
Delta Value	Difference values from the first to the second cursor.	
Delta (Time)	Difference time from the first to the second cursor.	
Channel	Selection of the signal to be measured and thus assignment of the channel number.	
	With -Off- the channel is switched off.	
Pos	Shifting the zero line for this channel in positive or negative direction.	
	The input of 100 corresponds to a vertical shift of the signal by one grid.	
	The ratio depends on the measured value.	
U/Div	Numerical units for setting the vertical grid line.	
	I.e. with U/Div = 10000 at N cmd (ramp) the numerical value of 10000 equals a horizontal line. The reference is always based on the numerical and not the physical value.	
Control box	The display of the channel is switched on and off.	
	The channel that is switched off remains in the background and is also saved.	
Channel	By clicking the colour key C, the colour of the measuring signal in the oscilloscope	
colours	window can be changed via the colour selection window.	
The trigger line is the line on which the trigger was defined. The first cursor line is the line that is set by pressing the left mouse button.		

The second cursor line is the line at which the mouse pointer is located.

#### 21.2.2 Oscilloscope – Overview Trigger and Capture Setting

Overview of trigger and capture settings.

Trigger:	Function:		Trigger
On	Selecting the signal for the trigger function	On	Chan 1
Edge	Selection of the trigger function in relation to the selection in the	Edge	Rise > Lev
	field <b>On</b>	Level	100
Level	Setting the trigger level (numeric) depending on the trigger		Capture
	function and the selected signal.	Buf	2000

Capture:	Function:	
Buf	Resolution or number of measuring points divided among all	
	channels used	
Run	Trigger switching function selection	
Timescale	Time unit per horizontal grid line	
Pre trig	Horizontal shift of the trigger line	
	Measured value display possible before the trigger line	



The number of measuring points in the NDrive software oscilloscope depends on the settings of the time base (timescale), just like in a real oscilloscope. Thus, the distances between the measuring points are also dependent on these settings. **It is therefore not a data logger**.

I.e. zooming in afterwards on a long timescale setting cannot show a more detailed view of the measurement points in a smaller time range. You have to be clear on which time base you are measuring.

#### 21.2.3 Oscilloscope – Description of trigger and capture settings

#### On:

The selection of the signal for the trigger function is selected via the pull-down menu. Either a specific channel (1..8) or a signal listed in the pull-down menu can be taken, even if it is not defined in one of the channels.

Edga.	
Ease:	

Luge.	
Symbol:	Trigger Description: (Always in relation to the value in Level)
Rise > Lev	The signal crosses from a smaller to a larger of the set level value $\rightarrow$ <b>Positive edge</b> .
Rise < Lev	The signal crosses from a larger to a smaller of the set level value $\rightarrow$ <b>Negative edge</b> .
Rise or Fall	The signal crosses a <b>positive or negative edge of</b> the set level value.
=Lev	The signal is equal to the set level value.
!= Lev	The signal is <b>not equal to</b> the set level value.
> Lev	The signal is greater than the set level value.
< Lev	The signal is <b>less than</b> the set level value.

#### Level:

This numerical value is the reference for selecting the trigger function in **Edge**.

Note:

Changes are only accepted if the activation function of a measurement (Run/Stop) is set to Stop.



#### Buf:

The number of measuring points of 250, 500, 1000 or 2000 for all 8 channels simultaneously defines the detail of the measurement.

With a **Buf** setting of 2000 and only 2 channels activated, each channel receives 1000 measuring points Recommendation: 2000

#### Run:

Symbol:	Function:	
Auto	to Continuous measurement without the need to detect a trigger function.	
Single	e If a trigger function is detected, a measurement is carried out.	
	Afterwards, the activation function (Run / Stop) is automatically set to Stop.	
Normal	A measurement is carried out for each trigger function detected.	

#### Timescale:

The time unit (timescale) per horizontal subdivision defines not only the time unit of the display in the oscilloscope window but also the delta intervals at which a measuring point of a channel is measured. In general, a channel has 50 measuring points between each grid of a horizontal subdivision. This means that with a timescale setting of 500 ms, the delta of a measuring point is equal to 10 ms. (Measuring point Delta = Timescale / 50 = 500 ms / 50 = 10 ms).

#### Pre Trig:

The Tre trig shifts the trigger function by the corresponding setting depending on the Timscale setting. It allows events to be viewed before the actual trigger.

#### Note:

- With the trigger function (Edge: != Lev) on the signal I\_actual and Capture (Run: Single) setting, it is easy to trigger a "force trigger" with a single recording.
- If the pre trig is greater than 0 %, the display in the oscilloscope window may overlap. This happens when a new trigger is detected during the transmission time.
  This happens especially when Run = Auto is set. It is then advisable to use a pre trig of 0 % to be used.



#### 21.2.4 Oscilloscope – Measurement Activate

Overview of the activation function of a measurement for the oscilloscope.

Run / Stop:	Symbol:	Function:	
Run	Pup	The <b>Run</b> keypad is used to arm the oscilloscope recording	
	- Kult	Recording is started at the next trigger signal	
Stop	Chan	The <b>Stop</b> button stops and discards the recording	
	Stop	The current display is frozen	

#### 21.2.5 Oscilloscope – Status display

Overview of the status display for the oscilloscope.

Status:	Colour:	Function:	
waiting (0)	Red	Measurement is activated (Run) and waiting for a new trigger event	
waiting (xx)	Green	Measurement was triggered and data is temporarily stored in the servo	
reading	Blue	Measurement is finished and data is sent from the servo to the PC	
drawing		Displaying the data in the oscilloscope window	
idle	White	Measurement is deactivated (Stop)	

#### 21.2.6 Oscilloscope – Zoom Options

Overview of the zoom options of a measurement in the oscilloscope window.

Zoom:	Symbol:	Function:
Zoom [+]	Ð	Measurement in the oscilloscope window is enlarged depending on the
	Q	selected zoom axes direction.
Zoom [-]	0	Measurement in the oscilloscope window is scaled down depending on
	$\boldsymbol{\lambda}$	the selected zoom axes direction.

Zoom axes	Symbol:	Function:
direction:		
[X] and [Y] - Axis	<b>M</b> . M	Measurement is performed on the <b>X and Y axes with</b> this selection.
	X+Y	enlarged ( $\rightarrow$ zoom [+]) or reduced ( $\rightarrow$ zoom [-])
<b>[X] -</b> Axis		Measurement is displayed on the <b>X-axis</b> with this selection.
	X	enlarged ( $\rightarrow$ zoom [+]) or reduced ( $\rightarrow$ zoom [-])
<b>[Y] -</b> Axis		Measurement is displayed on the <b>Y-axis</b> with this selection.
	Y	enlarged ( $\rightarrow$ zoom [+]) or reduced ( $\rightarrow$ zoom [-])

#### Note:

Only the display is enlarged. The number of measuring points depends on the timescale setting and always remains the same regardless of the zoom setting.

#### 21.2.7 Oscilloscope – Line thickness (pencil)

1

The **pencil** symbol allows you to choose between 3 different thicknesses of the measuring lines. This changes the line thickness of all 8 measuring channels.



#### 21.2.8 Oscilloscope – Saving and loading of measurements

File *.uof	Symbol:	Function:
Load .uof file	1	Load measurement from a UniTek oscilloscope file (.uof)
Save .uof file		Save measurement as UniTek oscilloscope file (.uof)
Save .csv file		Save measurement as Excel file (.csv)

Overview of the save and load options of an oscilloscope measurement.

#### Note:

- Measurements in .uof format can be loaded in the NDrive oscilloscope (also in offline mode), changed and saved again.
- Measurements in .csv format cannot be subsequently loaded and viewed in the NDrive oscilloscope (i.e. unusable for later analyses).

#### 21.2.9 Oscillocope – Oscilloscope Window Customise

Overview of the options for setting the oscilloscope window and special display of a measurement.

Option:	Function:	
Join	Connect measuring points (interpolated)	
Over	Display remains and is overwritten	
Zero	Zero line visible	
Units	Display Num or real values (if available)	
Trig	Trigger line visible	
Label	Channel name visible	
AbsDelta	Function not yet activated	
InvColour	Invert all colours	
-		

Symbol:	Settings:
В	Background colour
К	Raster line colour
Z	Cursor line colour
Т	Trigger line colour





#### 21.2.10 Oscilloscope – Measured value display



#### Measured values Display:

- The records of the measured values are displayed in the selected colours.
- Measured values can be displayed or hidden via the tick symbol.
- The tick symbol in the **Units** box switches the displayed values from numerical values to physical values if the conversion is available for the signal.

#### **Trigger line:**

- The **first trigger line (vertical)** is marked by an arrow symbol at the top and bottom of the screen. This is defined by the trigger setting via the **Pre Trig** selection.
- The **second trigger line (horizontal)** is marked by an arrow symbol on the left edge of the picture. This is defined by the trigger setting via the **Level** value.



**Cursor line:** 

- The **first cursor line (solid cross line)** is always located where the **mouse pointer** is. Depending on this position, the value for each measurement variable is displayed at **Value**.
- The **second cursor line (dashed vertical line)** is defined by the user (left mouse button) depending on the current position of the first cursor line.

In the **Delta Value** field, the **difference value** between the first and the second cursor line is displayed for each measured value.

#### Time:

- The **Time** window shows the time from the first trigger line (vertical) to the first cursor line (solid cross line).
- The **Delta (Time)** window shows the time from the second cursor line (dashed vertical line) to the first cursor line (solid cross line).

#### 21.2.11 Oscilloscope - Parameters on the Oscilloscope page

The Oscilloscope page contains a compact selection of important parameters for direct modification while making measurements with the oscilloscope.

In the area depending on the selection of the pull-down menu (here: I reduce), various blocks of parameters can be displayed.

The changes are applied to the current parameter set in the RAM memory and automatically to the other tabs.

Current			Speed		
Кр	20		Кр	20	
Ti	600	μs	Ti	10	ms
TiM	100	%	Td	0	ms
xKp2	0	96	TiM	60	96
Kf	0		Kacc	0	96
Ramp	2000	us	Filter	4	
l max pk	100	96	N R-Acc	300	ms
I con eff	100	%	N R-Dec	300	ms
T-peak	5	s	R-Lim	1000	ms
FB-Offset	-58.4	Deg	M R-Acc	10	ms
			M R-Dec	50	ms
			M R-Rcp	1000	ms
Ireduce		$\sim$	N-100%	3000	RPM
l lim dig	100	96	N-Lim	35	%
I-red-N	100	%	N-Lim+	100	96
I-red-TD	21000	Num	N-Lim-	-100	96
I-red-TE	23000	Num			
I-red-TM	5600	Num			



# 22 Test mode

# 22.1 Test mode – Test

### Attention :

This field is only intended for test operation.

Test				
Speed (N)	$\sim$	O Dis		
15000		+	0	-
Position	(P)			
0		Dest	Ρ.	Calib



The test field allows direct digital setpoint commands to be sent for either Speed (N), Torque (Iq) or Position. This makes it very suitable for general test operation.

To be able to use the functions of the test field, the operating **mode Command Mode** must be set to **Dig. commands must** be set.

#### Test mode setpoint Setting of Speed (N) or Torque (Iq)

- The setting of a Speed (N) or Torque (Iq) setpoint is defined via the corresponding selection in the pulldown menu.
- The numerical setpoint is entered in the left field (range: 0..32767).
- When clicking the (+) or (-) button, the entered setpoint is executed immediately. When the stop button (O) is clicked, the setpoint is set to zero.

#### Test mode of setpoint preset position and reference cycle

- Enter the numerical position setpoint in the left field (range: ±2147483647).
- When the button (Dest. ) is clicked, the drive immediately moves to the entered position setpoint at the speed selected at N max.
- When the button (Calib) is clicked, the drive runs a reference cycle.
- With the key (P.) the entered numerical position is taken over as actual position and as target position.
- Dis Software release (only with active hardware release) The Dis button can be used to lock (red) and unlock (grey) the release.



# 22.2 Test mode – Step generator

Default:	Function:	Range:
Flux (ld)	Reactive current (Id) Default $\pm 32767$ $\rightarrow$ Id set (dig.)	
Torque (Iq)	Active current (Iq) Default $\pm 32767$ $\rightarrow$ M_set (dig.)	
Speed (N)	Speed (N) as default $\pm 32767$ $\rightarrow$ n_cmd	
Position (P)	Position target as default $\rightarrow$ Pos dest	±2147483647
		-
2 Step	Selection 2 or 3 steps	

Step generator for output of up to 3 cyclic repeating setpoints.

Step Ge	enerator
Spee	ed (N) 🗸 🗸
2 Step	✓
Step 1	10000
Time 1	400
Step 2	-10000
Time 2	400
Step 3	0
Time 3	1000
-	

Selection:	Function:	Range:
Step1	Value 1	See default
	(current (Id, Iq), speed or position)	
Time1	Time for value 1	032767
Step2	Value 2	See default
	(current (Id, Iq), speed or position)	
Time2	Time for value 2	032767
Step 3	Value 3	See default
	(current (Id, Iq), speed or position)	
Time 3	Time for value 3	032767
Start	Starts or stops the generator function	
Stop		

#### Note:

The time entries (Time) can vary for values >2000 depending on the PC.

Setpoint step functions are specified with the step generator. The ramps are determined in the parameter settings for current and speed controllers.

When the controller enable (RUN) is active, the drive is started by clicking the **Start** button and stopped with **Stop.** The functions can be selected as flux (Id), torque (Iq) and speed (N) or position values. The value for Stop is 0 for flux (Id), torque (Iq) and speed (N).

#### Pay special attention:

With limited travel, ensure that the travel is within the machine limits for the test settings.

With the test setting flux (Id) and torque (Iq), the drive can rotate at maximum speed.

With field weakening, overspeed can be achieved.





# 23 Measured values and parameters

# 23.1 Measured values (RO) – Overview

Symbol:	Function:	Range:	Unit:	ID address:
Firmware no.	Software firmware number (protected)	09999	Num	0x1B
Туре	Unit designation (protected)	0255	Num	0x67 <sub>Bit70</sub>
S-Nr.	Serial number device (protected)	32 Bit - 1	Num	0x62
Status	Current status information	32 Bit - 1	Bitmask	0x40
Warning-Error	Current error and warning information	32 Bit - 1	Bitmask	0x8F
Error	Current error information	0 32767	Bitmask	0x8FL
Warning	Current warning information	0 32767	Bitmask	0x8F <sub>H</sub>
Ain1 in	Analogue input 1	±32767	Num	0xD5
Ain2 in	Analogue input 2	±32767	Num	0xD6
Ain1 scaled	Analogue input 1 scaled	±32767	Num	0xFB
Ain2 scaled	Analogue input 2 scaled	±32767	Num	0xFC
N cmd (int)	Speed setpoint used (internal)	±32767	Num	0x5D
N cmd (ramp)	Speed setpoint after ramp	±32767	Num	0x32
N actual	Actual speed	±32767	Num	0x30
N act (filt)	Actual speed value filtered for display	±32767	Num	0xA8
N error	Control error speed actual value	±32767	Num	0x33
M cmd ramp	Active current (Iq) Setpoint (scaled) after ramp	±32767	Num	0x3AL
M out	Actual active current (Iq) (scaled)	±32767	Num	0xA0
lq cmd	Active current (Iq) Setpoint (internal)	±2000	Num	0x26
lq cmd ramp	Active current (Iq) Setpoint (internal) after	±2000	Num	0x22
	ramp and limitation			
ld cmd	Reactive current (Id) Setpoint (internal)	±2000	Num	0x23
I lim inuse	Current limit (internal)	±2000	Num	0x48
I lim inuse ramp	Current limit (internal) after ramp	±2000	Num	0x57
I2_adc	ADC Voltage of the actual current sensor 2	2048	Num	0xAA
		(±2000)		
I3_adc	ADC Voltage of the actual current sensor 3	2048	Num	0xA9
		(±2000)		
I1 actual	Actual current phase 1	±2000	Num	0x54
12 actual	Actual current phase 2	±2000	Num	0x55
13 actual	Actual current phase 3	±2000	Num	0x56
l actual	Actual current value	±2000	Num	0x20
l act (filt)	Actual current value after display filter	±2000	Num	0x5F
lq actual	Current active current (Iq)	±2000	Num	0x27
ld actual	Current reactive current (Id)	±2000	Num	0x28
lq error	Control error active current (Iq)	±2000	Num	0x38
ld error	Control error reactive current (Id)	±2000	Num	0x39
32 Bit - 1 → $2^{32}$ - 1 = 4.29 +32 Bit - 1 → $+2^{32-1}$ - 1 = 4.29	94.967.295 +2 147 483 647			



Symbol:	Function:	Range:	Unit:	ID address:
Vemf	Current Vemf voltage share	±4096	Num	0x29 <sub>H</sub>
Vq	Current Vq voltage share	±4096	Num	0x29L
Vd	Current Vd voltage share	±4096	Num	0x2AL
Vout	Current output voltage	±4096	Num	0x8AL
Vdc-Bat	Measured value of the DC link voltage	032767	Num	0x66
Vdc-Bus	Measured value of the DC link voltage filtered	032767	Num	OxEB
Pos dest	Preset target position	±32 Bit - 1	Num	0x6E
Pos cmd	Target position used (internal)	±32 Bit - 1	Num	0x91
Pos actual	Actual position value	±32 Bit - 1	Num	0x6D
Pos error	Control error Position actual value	±32 Bit - 1	Num	0x70
Zero-Capture	Absolute value zero crossing for resolver	065535	Num	0x74
InOut Block	Digital input and output bit mask	032767	Bitmask	0xD8
in limit1	Digital input LMT1	0/1	Bit	0xE4
in limit2	Digital input LMT2	0/1	Bit	0xE5
in Din1	Digital input IN1	0/1	Bit	0xE6
in Din2	Digital input IN2	0/1	Bit	0xE7
in Run (Frg)	Digital input controller enable RUN	0/1	Bit	0xE8
I Fault	Int. error message from the power unit	0/1	Bit	0xE9
l Regen	Ballast circuit state	0/1	Bit	OxEA
I Voltage Err	Overvoltage message (only for servo units with	0/1	Bit	OxEB
	digital Vdc bus measurement)			
I LossOfSignal	Hardware resolver signal error message	0/1	Bit	OxEC
		- 4		
out Dout1	Digital output OUT1	0/1	Bit	0xE0
out Dout2	Digital output OUT2	0/1	Bit	0xE1
out Dout3	Digital output OUT3	0/1	Bit	0xDE
out Dout4	Digital output OUT4	0/1	Bit	0xDF
out Rdy (BTB)	Ready-to-operate message RDY	0/1	Bit	0xE2
0 Go	Internal release GO	0/1	Bit	UXE3
O Brake	Brake active BRK1	0/1	Bit	UXF2
	Reduction to continuous current icns	0/1	BIT	UXF3
O Less NO	Speed less than 0.1 %	0/1	BIT	UXF5
U Toler	Within the position tolerance	0/1	BIT	UXF4
iner delte	Difference rater position ofter compliantime	0 22767	Nuna	0×41
MotorDos moch	Difference rotor position after sampling time	0.32767	Num	0x41
	Rotor position mechanical	0.32767	Num	0x42
Rotor	Rotor position cignals (PST) (0 or 7 – orror)	032707	Num	0x45
ROLUI		10	NUITI	UXSC
$p_{\rm W} = 1  (1/2)$	Pulse width modulation phase 1	750	Num	ΟχΑς
pwiii (1/2)		(+750)	Num	UNAC
$p_{Wm2}(3/4)$	Pulse width modulation phase 2	750	Num	ΟχΑΓ
		(+750)		
pwm3 (5/6)	Pulse width modulation phase 3	750	Num	0xAF
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		(±750)		
32 Bit - $1 \rightarrow 2^{32} - 1 = 4.29$	94.967.295		1	J
$\pm 32 \text{ Bit} - 1 \rightarrow \pm 2^{32-1} - 1 = :$	±2.147.483.647			



# Measured values and parameters

Symbol:	Function:	Range:	Unit:	ID address:
T-motor	Motor temperature	032767	Num	0x49
T-igbt	Power stage temperature	032767	Num	0x4A
T-air	Air temperature (unit interior)	032767	Num	0x4B
Ixt & Regen.	Monitor from Ixt & Regen Circuite		Num	0x45
Energy				
lxt	lxt monitoring	032767	Num	0x45∟
Ballast energy	Ballast energy monitoring	032767	Num	0x45 <sub>н</sub>
Ballast Count	Ballast performance monitoring	032767	Num	0xA1
fpga status	ECODE from the FPGA device	032767	Bitmask	0x63
fpga 1st error	ECODE from the FPGA device from the first	032767	Bitmask	0x94
	detected error			
Logic (Hz)	Main processing frequency	065000	Hz	0xAB
Ctrl	Control Status	32 Bit - 1	Num	0x11
Temp debug	For service only	±32767	Num	0x9A
*PTR1	For service only	±32767	Num	0xB8
*PTR2	For service only	±32767	Num	0xBA
32 Bit - 1 $\rightarrow$ 2 <sup>32</sup> - 1 = 4.29	4.967.295			



# 23.2 Parameters (RW / SP) – Overview

### Parameters – Motor

Symbol:	Function:	Range:	Unit:	ID address:
Type <sup>1</sup>	Selection of motor type (EC servo, FU, FU servo, DC)			0x5A <sub>Bit 1312</sub>
N nom	Engine speed (for FU autotuning)	6065000	rpm	0x59
F nom	Frequency Rated motor speed (for FI mode)	201200	Hz	0x05
U nom	Voltage at rated motor speed (for FI mode)	01000	V	0x06
Cos Phi	Motor power factor (for FI mode)	0327,00	%	0x0E
I max eff	Motor maximum current	01000,0	Arms	0x4D
I nom eff	Motor continuous current	01000,0	Arms	0x4E
M-Pole	Motor pole number (2 x pole pairs)	296	Num	0x4F
Kt	Motor Kt constant	050,000	Nm/A	0x87L
Ке	Motor Ke Constant (Back EMF)	0500,00	V/krpm	0x87 <sub>н</sub>
Brake	- Attraction delay time of the electro-mechanical	01000	ms	0xF1
delay	motor brake			
	- Deceleration delay when no brake is connected			
Coast	Free run (ON) or emergency stop braking (OFF)	On / Off		0x5A <sub>Bit 3</sub>
stop	(when switching off the enable RUN)			
M-Temp	Motor overtemperature switch-off point	032767	Num	0xA3
	(error code 6)			
	(At 93 % there is a warning message 6 with current			
	derating Ird-TM activation).			

# <sup>1</sup> Parameter – Motor: Type

Symbol:	Function:	ID address:
Туре		0x5A <sub>Bit 1312</sub>
EC Servo	Synchronous servo motor with encoder system (sensor)	0 dec
ACI V/f	Asynchronous motor Frequency converter without sensor	1 dec
	(U/F characteristic without slip compensation)	
ACI Servo	Asynchronous motor AC servo-vector control with speed encoder system	2 dec
	(e.g., bearing encoder A, B channel)	
DC	DC motor without or with DC tacho encoder	3 dec



#### Parameter – Feedback encoder

Symbol:	Function:	Range:	Unit:	ID address:
Type <sup>2</sup>	Feedback selection			0xA4 <sub>Bit 40</sub>
	(Red_Enc_TTL, Resolver,)			
FB-Pole	Encoder pole number	212	Num	0xA7
FB-Offset	Phase angle correction	±360	Degree	0x44
FB-Incr (Mot)	Resolution encoder	10248192	Inc/Rev	0xA6
Voltage	DC tachometer voltage		mV/rpm	
Inc-Out	Resolution- 2.donor		Inc/Rev	0xCF <sub>L</sub>
Factor	Multiplier SIN/COS Inc.	416	Num	0x7E

# <sup>2</sup> Parameters – Feedback encoder: Type

Symbol:	Function:	ID address:
Туре		0xA4 <sub>Bit 40</sub>
Rot_Enc_TTL	Incremental encoder TTL 5 V with rotor position tracks	0 dec
Resolver	Resolver	1 dec
Abs_Enc_SC	Incremental encoder Sin/Cos 1Vpp with commutation track	2 dec
Rot_Tacho	Rotor position sensor with brushless tachometer	3 dec
Rot	Rotor position sensor (without tacho)	4 dec
DC_Tacho	DC tachogenerator	5 dec
DC_Arm	Armature voltage (internal)	6 dec
BL_Arm	EC-AC motor without tachometer	7 dec
Enc_TTL	Incremental encoder TTL 5 V (without rotor position)	8 dec
Enc_SC	Incremental encoder Sin/Cos 1Vpp without commutation track	9 dec
Abs_SC	Incremental encoder Sin/Cos 1Vpp per motor pole pair	10 dec
DC_Arm_Vir	Sensorless (DC motor without tacho, without armature voltage	11 dec
	measurement	
SLS	Sensorless (Only for ACI V/f operation)	12 dec
SLS_SMO	Not activated	13 dec
SLS_Usens	Not activated	14 dec
Ana_In1_calc	Not activated	15 dec
Ana_In2_calc	Not activated	16 dec
Panasonic	Not activated	17 dec
DC_Bus	Not activated	18 dec



# Measured values and parameters

#### Parameter – 2. Feedback encoder

Symbol:	Function:	Range:	Unit:	ID address:
Type <sup>3</sup>	Selection 2nd counting input			0xA4 <sub>Bit 75</sub>
Inc-ext	Resolution increments 2nd encoder		Inc/Rev	0xCF <sub>L</sub>
Factor-ext	Encoder factor 2nd encoder	416	Num	0x7E
Inc-Out	Increments output resolution		Inc/Rev	0xCF <sub>H</sub>
Factor	Multiplication factor of the basic pulse number			0xA4 <sub>Bit 1412</sub>
	for SinCos (SC)			

# <sup>3</sup> Parameters – 2. Feedback encoder: Type

Symbol:	Function:	ID address:
Туре		<b>0xA4</b> Bit 7 5
	Input switched off	0 dec
Enc - Position	Position input	1 dec
Enc - Info	Info display only input	2 dec
Enc - Hand.	Handwheel input	3 dec
SSI	SSI encoder input	



#### Parameter – Servo

Symbol:	Function:	Range:	Unit:	ID address:
Туре	Unit type (protected)	0255	Num	0x67 <sub>Bit 70</sub>
S-Nr.	Serial unit no. (protected)	32 Bit - 1	Num	0x62
Axis	Axis designation (freely writable)	4 characters	ASCII	0xF8
Mains sel	Selection of the power voltage	AC / DC		0x5A <sub>Bit 19</sub>
Mains	Magnitude of the mains supply voltage	01000	V	0x64
DC-Bus max	Max. voltage limit of the DC Bus (software)	0200	%	0xA5 <sub>н</sub>
DC-Bus min	Min. voltage limit of the DC Bus (software)	0200	%	0xA5∟
Regen	Selection of regen resistor	INT / EXT		0x5A <sub>Bit 1</sub>
Regen-P	Power value of the external regen resistor	2510000	W	0x65∟
Regen-R	Resistance value of the external regen	5100	Ohm	0x65 <sub>н</sub>
	resistor			
<b>BTB</b> Power	BTB message with or without bus circuit	mit / ohne		0x5A <sub>Bit 6</sub>
	undervoltage monitoring	with / without		
PWM freq <sup>4</sup>	PWM pulse frequency	Selection field		0x5A <sub>Bit 2220</sub>
Mode <sup>5</sup>	Type of the command value presetting for	Selection field		0x36 <sub>Bit 1312</sub>
(Command)	the speed and torque commands			
Cutoff (dig.)	Zero zone with digital command value	032767	Num	0x1E
	presetting			

#### <sup>4</sup> Parameters – Servo: PWM freq

Symbol:	Function:	ID address:
PWM freq		0x4A <sub>Bit 2220</sub>
8kHz		0 dec
24kHz	Not active!	1 dec
20kHz	Not active!	2 dec
16kHz		3 dec
12kHz		4 dec
8kHz I16	internal 16 kHz	5 dec
4kHz I8	internal 8 kHz	6 dec
2kHz I4	internal 4 kHz	7 dec

#### <sup>5</sup> Parameters – Servo Command: Mode

Symbol:	Function:	ID address:
Mode		0x36 <sub>Bit 1312</sub>
Digital Speed	Digital speed setpoint from RS232 or CAN-BUS	0 dec
Analog Speed	Speed setpoint analogue	1 dec
Analog Torque	Torque - setpoint analogue	2 dec
Digi + Ana Speed	Digital plus analogue setpoint	3 dec

# Parameter – Overview Analogue (Ain1 + Ain2)

Symbol:	Function:	Range:	Unit:	ID address:
				Ain1 -
				Ain2 -
Format <sup>6</sup>	Selection of the function of the respective	Selection field		0x36 <sub>Bit 10</sub>
	analogue inputs			0x36 <sub>Bit 32</sub>
Offset	Offset compensation of the respective	±32767	Num	0x2F∟
	analogue inputs			0xD7L
Cutoff	Zero zone of the respective analogue	032767	Num	0x50
	setpoints			0x53
Scale	Scaling factor of the respective analogue	±7.999	Num	0x2F <sub>H</sub>
	inputs			0xD7 <sub>H</sub>
Filter	Filter of the respective analogue inputs	0127.5	Num	0x60
Mode <sup>7</sup>	Input level selection of the respective	Selection field		0x36 <sub>Bit 54</sub>
(Analog)	analogue inputs			0x36 <sub>Bit 98</sub>

# <sup>6</sup> Parameters – Analog Command Format (Ain1 + Ain2)

Format: Ain1		ID address:
Off	Disabled	$0x36_{Bit 10} = 0$
+Cmd	Setpoint command normal	0x36 <sub>Bit 10</sub> = 1
-Cmd	Setpoint command inverted	0x36 <sub>Bit 10</sub> = 2
sq(Cmd)	Square reference setpoint command	0x36 <sub>Bit 10</sub> = 3
N limit	Speed limitation 0 100 % via Ain1	0x36 <sub>Bit 15</sub>
	(with digital setpoint input (position, speed)). This corresponds to 100 % of	
	the max. physical speed defined in <b>N-100%</b> (0xC8).	

Format:	Format: Ain2	
Off	Disabled	0x36 <sub>Bit 32</sub> = 0
+Cmd	Setpoint command normal (Ain2 is added to Ain1)	0x36 <sub>Bit 32</sub> = 1
-Cmd	Setpoint command invertet (Ain2 is subtracted from Ain1)	0x36 <sub>Bit 32</sub> = 2
*Cmd	Setpoint command normal (Ain2 is multiplied by Ain1)	0x36 <sub>Bit 32</sub> = 3
l limit	Current limitation 0100 % via Ain2	0x36 <sub>Bit 14</sub>
	(for all digital, analogue setpoints).	
	This corresponds to 100 % of the unit peak current I max pk (0xC4).	

# <sup>7</sup> Parameters – Analog Mode (Ain1 + Ain2)

Symbol:	Function:	ID address:
		0x36 <sub>Bit 54</sub>
-10+10V	Setpoint plus-minus max. 10 V	0 dec
0+10V	Setpoint plus max. 10 V	1 dec
420mA	Setpoint 4 to 20 mA at 500 Ohm	2 dec
+1+9V	Setpoint 1 to max. 9 V	3 dec



#### Parameter – Current controller

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x1C
Ti	Reset time (integral time constant)	37510000	ms	0x1D
TiM	Maximum value from integral memory Ti	0300	%	0x2B
xKP2	Proportional amplification in case of actual	0, 100500	%	0xC9
	current greater than current limit			
Kf	Current feed forward	0167	Num	0xCB
Ramp	Ramp adjustment set current	12532000	μs	0x25

#### **Parameter – Current limits**

Symbol:	Function:	Range:	Unit:	ID address:
l max pk	Devices Peak current [A]	0100	%	0xC4
l con eff	Devices Continuous current [Arms]	0100	%	0xC5
T-peak <sup>2</sup>	Permitted overcurrent time above continuous current limit (degradation 5 times longer)	140	S	0xF0
I lim dig <sup>3</sup>	Current reduction in % when Logic input I limit (dig.) is activated	0100	%	0x46
I-red-N	Current reduction via the actual speed	0100	%	0x3C
I-red-TD	Start of current reduction via the output stage temperature	032767	Num	0x58
I-red-TE	End of current reduction via the output stage temperature	032767	Num	0x4C
l-red-TM	Start current reduction via the Motor temperature	032767	Num	0xA2
l lim inuse	Current limit	032767	Num	0x48
<sup>2</sup> Only active if current reduction based on the output stage temperature is not activated ( $0x40_{Bit 23}$ (Ird-TI) = 0) <sup>3</sup> Reference is maximum unit neak current (I max pk ( $0xC4$ ) = 100 %)				

#### Parameters – Output stage voltages

Symbol:	Function:	Range:	Unit:	ID address:
Vemf	Current Vemf voltage share	±4096	Num	0x29 <sub>н</sub>
	(feed forward Back EMF)			
Vq	Current Vq voltage share	±4096	Num	0x29
Vd	Current Vd voltage share	±4096	Num	0x2A
Vout	Current output voltage	±4096	Num	0x8A
V-red	Voltage reference value in % of Vout	0100	%	0x8B
	(V-red $\neq$ 0, 100 % $\rightarrow$ activation field weakening control)			
	Recommendation: 6080 %			
V-kp	Proportional amplification of the field weakening	065535	Num	0x8C
	control			
V-Ti	Integral time of the field weakening control	065535	Num	0x8D
Vdc bus	DC link voltage	032767	Num	OxEB

Symbol:	Function:	Range:	Unit:	ID address:
Ain 1 scaled	Analogue setpoint setting - Input Ain1	±32767	Num	0xD5 <sub>H</sub>
Ain 2 scaled	Analogue setpoint setting - Input Ain2	±32767	Num	0xD6 <sub>H</sub>
N set (dig.)	Digital setpoint setting of the speed	±32767	Num	0x31
M set (dig.)	Digital setpoint setting from Iq current	±32767	Num	0x90
N cmd (int)	Speed setpoint used (internal)	±32767	Num	0x5D
N cmd (ramp)	Speed setpoint after ramp	±32767	Num	0x32
N actual	Speed actual value signal for the control	±32767	Num	0x30
N act (filt)	Actual speed signal for the display	±32767	Num	0xA8
N error	Control error Speed actual value	±32767	Num	0x33

# Parameter – Speed -setpoint, -actual value

# Parameters – Limitation, ramps for speed and torque setting

Symbol:	Function:	Range:	Unit:	ID address:
N R-Acc	Speed - Acceleration ramp	030000	ms	0x35∟
N R-Dec	Speed - Brake ramp	030000	ms	0xED <sub>L</sub>
M R-Acc	Moment - Acceleration ramp	04000	ms	0x35 <sub>H</sub>
M R-Dec	Moment - mining ramp	04000	ms	0xED <sub>H</sub>
M R-Rcp	Moment - Recuperation Ramp (0xCD <sub>Bit 4</sub> )	04000	ms	0xC7 <sub>H</sub>
R-Lim	Emergency stop, limit switch ramp	01000	ms	0xC7L
N-100%	Physical reference value for the internal	10050000	rpm	0xC8
	resolution of the speed to 16 Bit (±32767)			
N-Lim	Speed limitation for positive and negative	0100	%	0x34
	direction of rotation			
N-Lim+	Limitation for positive direction of rotation (if	0100	%	0x3F
	logic input N clip(neg&pos) is activated)			
N-Lim-	Limitation for negative direction of rotation (if	0100	%	0x3E
	logic input N clip(neg&pos) is activated)			
Filter	Filter speed actual value	010	Num	0x5E

#### Parameter – Speed controller

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x2C
Ti	Reset time (integral time constant)	010000	ms	0x2D
Td	Derivative time (differentiation part)	0100	ms	0x2E
TiM	Maximum value from integral memory Ti	0100	%	0x3B



#### Parameter – Position controller reference run

Symbol:	Function:	Range:	Unit:	ID address:
Speed 1	Speed to limit switch	032000	Num	0x76∟
	The limit switch is overrun depending on the			
	speed			
Speed 2	Reverse speed back to zero pulse	02000	Num	0x77L
	(loop speed)			
Reso Edge	Expected switching edge	065536	Num	0x75
Ref soft	Selection of the ramp during homing between N	DEC / LIM		0x5A <sub>Bit 5</sub>
	R-Acc and R-Lim			
The calibration	on run is used to determine the zero point of the incre	emental mea	suring syste	m

# Parameter – Position controller (Pos $\rightarrow$ Speed)

Symbol:	Function:	Range:	Unit:	ID address:
Кр	Proportional gain	0200	Num	0x6A
	Determines the steepness of the deceleration ramp			
Ti	Integration reset time (depending on Kp)	010000	ms	0x6B
Td	Derivative time (differential share)	01000	ms	0x6C
TiM	Maximum value from integral memory Ti	0100	%	0x71
The amplified position error forms the speed setpoint				
Position control is deactivated when Kp = 0				
The dynamic control gains Ti are only effective in the target range				

#### **Parameter – Position Parameter**

Symbol:	Function:	Range:	Unit:	ID address:
Tol-wind	Position tolerance window	02000	Num	0x79
Off.Ref.	Mechanical zero offset		Num	0x72
ND-Scale	NDrive position display factor	32 Bit - 1	Num	0x7C
ND-Offset	NDrive Position Display Offset	32 Bit - 1	Num	0x7D
Pos dest	Preset target position	±32 Bit - 1	Num	0x6E
Pos cmd	Target position used (internal)	±32 Bit - 1	Num	0x91
Pos actual	Actual position value	±32 Bit - 1	Num	0x6D
Pos error	Control error Position actual value	±32 Bit - 1	Num	0x70
				•
Inc-ext	Resolution increments 2nd encoder		Inc/Rev	0xCF <sub>L</sub>
Factor-ext	Encoder factor 2nd encoder	416	Num	0x7E
Inc-Out	Increments output resolution		Inc/Rev	0xCF <sub>H</sub>
$\begin{array}{l} 32 \text{ Bit - } 1 \rightarrow 2^{32} - 1 = 4.294.967.295 \\ \pm 32 \text{ Bit - } 1 \rightarrow \pm 2^{32 - 1} - 1 = \pm 2.147.483.647 \end{array}$				



Symbol:	Function:	Range:	Unit:	ID address:
FU Start				
T dc	Premagnetisation time	102000	ms	0x07L
	Delay between switching on and starting the frequency			
V dc	Premagnetisation DC voltage value	020	%	0x08L
V min	Minimum voltage (boost) when the motor is at a	0100	%	0x0A <sub>L</sub>
	standstill			
	$\rightarrow$ U/F characteristic curve is raised			
	Recommended: V min = V dc			
F min	Minimum frequency when the motor is at a standstill	0100,0	Hz	0x0BL
V corner	Maximum output voltage at the cut-off frequency	0100,0	%	0x0CL
F corner	Cut-off frequency for maximum output voltage	11000,0	Hz	0x0DL
F-sh <sup>8</sup>	Shape of the characteristic curve (linear, half-square,	03	Num	OxOF <sub>Bit 21</sub>
	square)			

# Parameters – Frequency inverter setting Parameters of the frequency inverter characteristic curve

# <sup>8</sup> Parameters – F-sh (FU Start)

Symbol:	Function:	ID address:
		<b>0x0F</b> <sub>Bit 2 1</sub>
linear	(currently only linear usable)	0 dec
quad/2		1 dec
quad		2 dec
opt		3 dec



# Parameter – Logic Bit

Symbol:	Function:	ID address:
		0xD8
LMT1	Digital input limit 1	Bit 0
LMT2	Digital input limit 2	Bit 1
IN2	Digital input Din 2	Bit 2
IN1	Digital input Din 1	Bit 3
RUN (FRG)	Digital input of the software rotary field enable RUN	Bit 4
RFE	Digital input of the hardware rotary field enable RFE	Bit 5
	rsvd	Bit 6
	rsvd	Bit 7
OUT1	Digital output Dout 1	Bit 8
OUT2	Digital output Dout 2	Bit 9
RDY (BTB)	Hardware relay output BTB-Rdy	Bit 10
GO	State of internal enable GO	Bit 11
OUT3	Digital output Dout 3	Bit 12
OUT4	Digital output Dout 4	Bit 13
	rsvd	Bit 14
BRK1	State of excited Brake	Bit 15

# Parameter – Logic output comparison variable

Symbol:	Function:	Range:	Unit:	ID address:
0	Logic signal zero	1/0	Logic	
1	Logic signal one	1/0	Logic	
Var1		±32767	Num	0xD1
Var2				0xD2
Var3				0xD3
Var4				0xD4
Ain1	Analogue value input Ain1	±32767	Num	
Ain2	Analogue value input Ain2	±32767	Num	

# Measured values and parameters



#### Parameter – CAN bus interface

Symbol:	Function:	Range:	Unit:	ID address:
NBT	CAN transmission rate (see list)	00xFFFE	hex	0x73 <sub>Bit 110</sub>
Rx ID	CAN ID - Receive address	00x7EE	hex	0x68
Tx ID	CAN ID - Transmit address	00x7EE	hex	0x69
T-Out	CAN timeout time	060000	ms	0xD0
Axis	Axis designation (freely writable)	4 characters	ASCII	0xF8

#### Parameter – CAN Bus NBT possibilities

Transmission rate NBT:	Setting value in NBT (0x73):	Cable length max.:
1000 kBaud	0x4002	20 m
625 kBaud	0x4014	70 m
500 kBaud	0x4025 (default)	70 m
250 kBaud	0x405C	100 m
125 kBaud	0x4325	100 m
100 kBaud	0x4425	100 m



#### Parameter – Error Mask

Error		ID-Adresse:	Servo
in NDrive:		0x8F∟	Display:
NOREPLY- No RS232 COM reply	RS232 interface not plugged in or disturbed		
0: Eprom Read Error	Reading from Eprom defective	Bit 0	0
1: HW Fault detected	Critical hardware error detected	Bit 1	1
2: RFE input not present	Safety circuit not present	Bit 2	2
	(With RUN input active)		
3: CAN TimeOut Error	CAN TimeOut Time exceeded	Bit 3	3
4: Feedback Signal Error	Bad or missing feedback signal	Bit 4	4
5: Mains Voltage Min. Limit	Power voltage missing (digital)	Bit 5	5
	or below DC-Bus min limit (analogue)		
6: Motor-Temp. Max. Limit	Motor temperature too high	Bit 6	6
7: IGBT-Temp. Max. Limit	Output stage temperature too high	Bit 7	7
8: Mains Voltage Max. Limit	Power voltage > 1.8 x UN (digital)	Bit 8	8
	or above DC-Bus max limit (analogue)		
9: Critical AC Current	Overcurrent or strong oscillating current	Bit 9	9
	detected		
A: Race Away detected	Spinning (without setpoint, wrong direction)	Bit 10	А
B: ECode TimeOut Error	Bad or missing ECode protocol	Bit 11	В
C: Watchdog Reset	CPU Reset because of Watchdog detected	Bit 12	С
D: I Offset problem	AC Current Offset detection fault	Bit 13	D
E: Internal HW voltage problem	Error beacuse of internal Voltage problem	Bit 14	E
F: Bleed resistor overload	Only certain motor controllers	Bit 15	F


### Parameter – Warning Mask

Warnung		ID-Adresse:	Servo
in NDrive:		0x8F <sub>H</sub>	Anzeige:
0: Parameter conflict detected	Parameters are from different device type	Bit 16	0
1: Special CPU Fault	RUN input with jitter or EMI problems	Bit 17	1
2: RFE input not present	Safety circuit not present	Bit 18	2
	(without RUN input active)		
3: Auxiliary Voltage Min. Limit <sup>1</sup>	Auxiliary Voltage is too low	Bit 19	3
4: Feedback Signal problem <sup>2</sup>	Bad or missing feedback signal	Bit 20	4
	(Feedback supervision deactivated)		
5: Warn. 5		Bit 21	5
6: Motor-Temperature (>87%)	T-motor > (I-red-TM oder 93 % von M-	Bit 22	6
	Temp)		
7: IGBT Temperature (>87%)	T-igbt > 87 % vom Limit	Bit 23	7
8: Vout Saturation Max. Limit	Limit of existing voltage output reached	Bit 24	8
9: Warn. 9		Bit 25	9
A: SpeedActual resolution Limit	Resolution range of the speed	Bit 26	Α
	measurement exceeded		
B: Check ECode ID: 0x94	Error with an ECode information at ID	Bit 27	В
	Register 0x94 detected		
C: Tripzone Glitch detected	Tripzone triggered unintentional	Bit 28	С
D: ADC Sequencer problem	Problem of the ADC Sequencer channels	Bit 29	D
E: ADC Measurement problem	Problem of internal ADC voltages	Bit 30	E
F: Bleeder resistor load (>87%) <sup>1</sup>	Ballast circuit > 87 % overloaded	Bit 31	F
<sup>1</sup> Only certain motor controllers			

Feedback supersion is deactivated. Warning indicates that a Problem is present



# Parameter – Status display

Symbol:	Function:	ID address:
		0x40
Ena	Drive enabled	Bit 0
	(Combination hardware RFE and software RUN)	
NcR0	Speed limited to zero (last setpoint still active)	Bit 1
Lim+	Limit switch plus active	Bit 2
Lim-	Limit switch minus active	Bit 3
ОК	Drive in order	Bit 4
	(no uncontrolled reset)	
Icns	Current limit reduced to continuous current	Bit 5
T-Nlim	Speed-limited while in torque control	Bit 6
P-N	Position control active	Bit 7
N-I	Speed control active	Bit 8
<n0< td=""><td>Actual speed less than 0.1 % (standstill)</td><td>Bit 9</td></n0<>	Actual speed less than 0.1 % (standstill)	Bit 9
Rsw	Reference switch tripped	Bit 10
Cal0	Calibration run in progress	Bit 11
Cal	Calibration run completed (position calibrated)	Bit 12
Tol	Position within tolerance window	Bit 13
Rdy	Ready for operation (BTB/RDY contact closed)	Bit 14
Brk0	Brake not excited with motor active	Bit 15
SignMag	Setpoint inverted	Bit 16
Nclip	Speed limitation activated (N-Lim < 90 %)	Bit 17
Nclip+	Speed limitation positive via switch	Bit 18
Nclip-	Speed limitation negative via switch	Bit 19
Ird-Dig	Current limitation via switch	Bit 20
luse-rchd	Current reduction limit reached	Bit 21
Ird-N	Current reduction via speed	Bit 22
Ird-TI	Current reduction via output stage temperature enabled	Bit 23
Ird-TIR	Current reduction to continuous current via output stage temperature is	Bit 24
	active	
Ird-10Hz	Current reduction at a rotation frequency smaller than 10 Hz	Bit 25
Ird-TM	Current reduction via motor temperature	Bit 26
Ird-Ana	Current reduction via analogue input (if ≤ 90 %)	Bit 27
lwcns	Current peak warning	Bit 28
RFEpulse	Pulsed RFE input monitoring active	Bit 29
Fiwe Acv	Fieldweakening active	Bit 30
HndWhl	Handwheel input selected	Bit 31



### Parameter – Settings Switch for special functions (Mode Bits)

Symbol:	Function:	ID address:
		<b>0x51</b> <sub>Bit 90</sub>
Reserve		Bit O
SPEED = 0	Drive stop speed setpoint = 0	Bit 1
ENABLE OFF	Drive disabled Enable internally switched off	Bit 2
CANCEL CAL-CYCLE	Calibration run stopped	Bit 3
d(status) → CAN		Bit 4
I-clip on	Current limit in % of type current active	Bit 5
N-clip on	Speed limitation (positive and negative)	Bit 6
Mix ana on	Speed setpoint digital plus analogue	Bit 7
Allow sync		Bit 8
HndWhl	2. Feedback as handwheel	Bit 9

#### Parameters – Parameters on the Monitor page

Symbol:	Function:	Range:	Unit:	ID address:
N cmd (ramp)	Speed setpoint after ramp and limit	032767	Num	0x32
N actual	Speed actual value	032767	Num	0x30
lq cmd	Active current (Iq) Setpoint (internal)	±2000	Num	0x26
I act (filt)	Actual current value after display filter	±2000	Num	0x5F
Id actual	Current reactive current (Id)	±2000	Num	0x28
lq actual	Current active current (Iq)	±2000	Num	0x27
lxt	Capacity utilisation lxt	04000	Num	0x45∟
Power	Motor power (do not use!)	04000	Num	0xF6
Vdc-Bus (dir)	DC link voltage	032767	Num	OxEB
Regen. energy	Ballast power	04000	Num	0x45 <sub>н</sub>
T-motor	Current engine temperature	032767	Num	0x49
T-igbt	Current power stage temperature	032767	Num	0x4A
T-air	Current air temperature in the servo	032767	Num	0x4B
l lim inuse	Current limit	02000	Num	0x48
Vout	Current output voltage	04000	Num	0x8A
M out	Actual active current (Iq) standardised	±32767	Num	0xA0



# Parameters – Device Options (Do not modify!)

Symbol:	Function:	ID address:
		0x5A
Vdc comp	Analogue DC link measured value influences Uout	Bit O
Rregen-ext	External ballast resistor	Bit 1
TJ spec	Encoder monitoring activation	Bit 2
Coast	Free run-out (do not use an emergency stop ramp)	Bit 3
lact inv	Actual current polarity inverted	Bit 4
	(factory setting active for DS450, BAMO-D3)	
Ref soft	Reversal ramp set to "Dec" during calibration run from limit.	Bit 5
Rdy - Run	BTB signal also with undervoltage error message	Bit 6
Vdc ana	Analogue DC link measurement	Bit 7
lact 1 ena	Current measurement I1 activated	Bit 8
Hall inv	Sequence Hall signals inverted	Bit 9
H.2 inv	Hall signal 2 inverted	Bit 10
OL comp	Over Loop current limit or slip compensation Enable	Bit 11
MotorType: .0	Motor selection	Bit 1312
.1		
ana Oup	Measuring range of the Vdc bus voltage at the processor pin	Bit 14
	(1 = 0 5V) or (0 = 2.5 5V)	
low baud	Interface RS232 uses 9600 baud	Bit 15
s-ramp	S-ramp selection active	Bit 16
4-ramp	Selection 4 Ramps active	Bit 17
mot brk	Selection with brake active	Bit 18
ad dc	AC or DC power supply	Bit 19
PWM freq: .0	PWM clock frequency setting	Bit 2220
.1		
.2		
ntc	IGBT NTC Temperature Sensor	Bit 23
star-del	Motor phases triangle	Bit 24
dc 1Q	DC 1quadrant, direct voltage setting PWM	Bit 25
dc field	DC field controller	Bit 26
dead x2	Deadband *2	Bit 27
block	Block current for ROT Feedback	Bit 28
dc 1Qmv	DC 1quadrant, minimal switching losses	Bit 29
dc 1Q3p	DC 1quadrant, no high-side , -UB switch parallel	Bit 30
Frd<10Hz	Switching to 4 kHz at n < 10 Hz (no derating)	Bit 31